

PART NUMBER INDEX

This index is listed in the following sequence.

GENERAL PARTS

EXAMPLE

- ① Model/Type
Third, in the sequence of model/types (1st-4th digits)
- ② Group
First, in the sequence of group (5th & 6th digits)
- ③ Part
Second, in the sequence of part (7th-9th digits)

INDEX DES NOMBRES DE PIÈCES

Cet index a été composé selon la séquence suivante.

PIÈCES GÉNÉRALES

EXEMPLE

- ① Modèle/type
Troisièmement, séquence du modèle/type (1er à 4ème chiffres)
- ② Groupe
Premièrement, séquence du groupe (5ème et 6ème chiffres)
- ③ Pièce
Deuxièmement, séquence de la pièce (7ème à 9ème chiffres)

NUMERO INDICE DE PIEZA

Este indice se ordena en la siguiente secuencia.

PIEZAS GENERALES

EJEMPLO

- ① Tipo de modelo
Tercero, en la secuencia de tipo de modelo (entre las cifras 1ro-4to lugar)
- ② Grupo
Primero, en la secuencia de grupo (las cifras en 5to y 6to lugar)
- ③ Pieza
Segundo, en la secuencia de pieza (entre las cifras 7mo-9no lugar)

TEILENUMMERN

Die Teilenummern setzen sich wie folgt zusammen.

ALLGEMEINE TEILE

BEISPIEL

- ① Modell/Typ
Angabe des Modells bzw. Typs (1. bis 4. Ziffer)
- ② Baugruppe
Angabe der Baugruppe (5. und 6. Ziffer)
- ③ Teil
Angabe des Teils (7. bis 9. Ziffer)

① ② ③
┌───┬───┬───┐
B A 0 1 6 0 3 5 0

STANDARD PARTS

Standard Parts are listed in numerical sequence after General Parts.
(Note: Those parts which do not have D-Code are not listed in the index.)

PIÈCES STANDARD

Les pièces standard sont énumérées selon une séquence numérique après les pièces générales.
(Remarque: Les pièces qui ne possèdent pas de code D ne sont pas mentionnées dans cet index.)

PIEZAS NORMALES

Las piezas normales se numeran secuencialmente después de las Piezas generales.
(Nota: Las piezas que no tienen un código D no están en el índice.)

STANDARDTEILE

Die Standardteile sind nach den allgemeinen Teilen mit fortlaufender Numerierung aufgeführt.
(Hinweis: Teile ohne D-Code sind nicht aufgeführt.)

PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

N3A4-20-341	1-K5	BV40-21-1A3	1-E10	MA10-22-510	2-D3	1243-26-671	2-G3	PA01-27-431	2-M3	FD15-32-380	2-K4	FD01-34-17X	2-F5		
N3A5-20-341	1-K5	BV11-21-1A4	1-E10	MA10-22-520	2-D3	FA18-26-680	2-H3	*****		FD15-32-411	2-I4	FD01-34-180C	2-F5		
N318-20-341A	1-I5	BV11-21-1A5	1-E10	MA10-22-530	2-D3	B462-26-694	2-H3	*****		FD01-32-450	2-K4	FD01-34-19X	2-F5		
N3A1-20-342	1-K5	BV56-21-1A5	1-F10	MA10-22-540	2-D3	FD01-26-699	2-H3	*	28-000	*	FD02-32-450	2-K4	FD15-34-200	2-C5	
N3A2-20-342	1-K5	BV11-21-1A6	1-F10	MA10-22-550	2-D3	FD01-26-71X	2-G3	*		*	FD01-32-480F	2-L4	FD01-34-213	2-C5	
N3A3-20-342	1-K5	BV11-21-1A7	1-F10	BV65-22-900	1-J11	FD01-26-731	2-H3	*****		*****	FD02-32-480	2-K4	8871-34-222	2-C5	
N3A5-20-342	1-K5	BV11-21-1B1	1-F10	*****		FD01-26-800	2-H3				FD01-32-490D	2-L4		2-C6	
N3A1-20-343A	1-L5	BV11-21-1B4	1-F10	*****		FD01-26-810	2-H3				BR71-32-503	2-L4		2-F4	
N3A2-20-343B	1-L5	BV12-21-1B5	1-F10	*	23-000	H001-26-812	2-H3	FD15-28-011B	2-C4	FD15-32-600A	2-L4	FD15-34-250	2-F5		
N3A3-20-343A	1-L5	BV11-21-1B7	1-F10	*		GJ25-26-812	2-H3	FD01-28-012	2-C5	GA2A-32-607	2-L4	FD15-34-300	2-C5		
N3A4-20-343	1-L5	BV45-21-1B8	1-F10	*		FD01-26-851	2-H3	F801-28-091A	2-N3	EA03-32-610	2-L4	H260-34-313	2-D5		
FE4J-20-344	1-L5	BV11-21-1B9	1-F10	*****		D613-26-861	2-H3	FB15-28-110A	2-N3	G211-32-618A	2-L4	FD15-34-350	2-D5		
N3A1-20-344A	1-L5	BV11-21-1C1	1-F10		8871-23-180	1-N3	2-I7	FD01-28-114	2-E4	FD01-32-620B	2-L4	FD01-34-420	2-D5		
N3A2-20-344A	1-L5	BV40-21-1C1	1-F10		N236-23-356	1-D5		FD01-26-982	2-H3	FD01-32-682E	2-L4	FD01-34-460B	2-D5		
N3A3-20-344	1-L5	BV11-21-1C2	1-F10		HE19-23-610	1-N4		FD01-26-980A	2-H3	FD01-32-683A	2-L4	FD01-39-461	2-D5		
N3A4-20-344	1-L5	BV11-21-1C3	1-F10		HE19-23-610	1-N4		FD01-26-992	2-I3	FD01-32-750	2-H4	FD01-34-470A	2-D5		
N3A1-20-345	1-L5	BV11-21-1C4	1-F10		*****			FD01-26-990A	2-H3	FD01-32-81X	2-H4	FD01-34-471A	2-D5		
N3A2-20-345A	1-L5	BV45-21-1C5	1-G10		*****			FD01-26-990A	2-H3	FD01-32-810	2-H4	FD01-34-473	2-D5		
N3A4-20-345	1-L5	BV11-21-1D1	1-G10		*****			FD01-26-998	2-I3	FD15-32-850	2-I4		2-F4		
N3A1-20-346	1-L5	BV45-21-1D1	1-G10		*****										
N3A2-20-346	1-L5	BV11-21-1D2	1-G10	*	24-000	*		FD01-28-155A	2-D4	FD01-32-980D	2-H4	FD01-34-480A	2-D5		
N3A3-20-346A	1-L5	BV40-21-119	1-G10	*		*	27-000	FD15-28-156A	2-D4	FD01-32-980E	2-H4	FD01-34-610A	2-F4		
N3A1-20-348	1-L5	BV11-21-121	1-G10	*****		*****		FD01-28-170B	2-D4	FD03-32-980D	2-H4		2-F5		
N3A1-20-361A	1-L5	BV45-21-121	1-G10		8599-24-720	1-L8		FD01-28-180B	2-D4	FD03-32-980E	2-H4	FD15-34-700A	2-E5		
N3A2-20-361A	1-M5	BV11-21-125	1-G10		8599-24-722	1-L8		FD01-28-2A0B	2-E4			FD16-34-700A	2-E5		
N3A4-20-361	1-L5	BV11-21-148	1-G10		8599-24-743	1-M8		FD01-28-300B	2-E4	*****		FD01-34-701B	2-D5		
N3A1-20-362	1-M5	BV11-21-149	1-G10		8599-24-752	1-M8		H266-28-312	2-E4	*	33-000	*		2-F3	
N3A2-20-362	1-M5	BV30-21-149	1-G10		*****			FD15-28-380A	2-C5	*		*	FD01-34-710A	2-E5	
N3A4-20-362	1-M5	BV40-21-155	1-G10		*****				2-N3	*		*	FD01-34-711A	2-D5	
N3A2-20-363	1-M5	BV40-21-156	1-G10		*	P062-27-110	2-J3	FD01-28-42Y	2-E4	*****		FD01-34-800G	2-F5		
N3A2-20-370A	1-M5	BV11-21-173	1-G10		*	P044-27-120B	2-J3	FD01-28-450B	2-E4	*****		FD01-34-800H	2-F5		
N3A1-20-371	1-M5	BV11-21-193	1-G10		*	P045-27-120A	2-J3	FD01-28-457	2-E4	FD15-33-021	2-M4	FD15-36-900A	2-E5		
N3A2-20-371A	1-M5	BV11-21-2A1	1-F9		*****	R005-27-150	2-J3	FD01-28-458	2-E4	FD15-33-031	2-M4	FD16-34-900A	2-E5		
N3A1-20-372A	1-M5	BV11-21-2A2	1-F9		*****	R003-27-153	2-J3	FD01-26-460	2-E4	LA01-33-042B	2-E3	*****			
N3A1-20-380	1-M5	BV11-21-2A3	1-F9		*****	R001-27-165	2-J3	FD01-28-461	2-F4			*****			
N3A1-20-41YA	1-M5	BV11-21-2A5	1-H10		PF03-25-100	2-C3		FD15-28-50X	2-F4	B455-33-062	2-F3				
N3A1-20-410C	1-M5	BV12-21-2A5	1-H10		PF04-25-100	2-C3		FD16-28-50X	2-F4	JOY9-33-062	2-M4	*	37-000	*	
J501-20-442	1-M5	BV11-21-2A6	1-H10		P011-25-123	2-C3		FD01-28-664	2-F4	FD23-33-232	2-M4	*		*	
N3A1-20-490	1-J4	BV11-21-2A7	1-H10		1368-25-124	2-C3		FD15-28-700A	2-C4	FD01-33-25X	2-M4	*****			
N3A1-20-500	2-D6	BV11-21-2A8	1-H10		MA10-25-500	2-D3		FD16-28-700A	2-C4	FD01-33-261B	2-M4	*****			
*****					*****							*****			
N3A2-20-500	2-D6	BV35-21-2A9	1-H10		*	8051-27-235	2-K3	FD01-28-710A	2-F4	FD01-33-271B	2-M4	B002-37-160	2-G5		
N3A1-20-600	2-D6	BV65-21-2K1	1-M9		*	8051-27-236	2-K3	FD01-28-8C0A	2-F4	FD01-33-61XA	2-M4	FD01-37-191B	2-G5		
N3A2-20-600	2-D6	BV11-21-216	1-H10		*	P043-27-238	2-K3	FD15-28-80XB	2-F4	F805-33-651A	2-M4	FD01-37-790A	2-H5		
N3A1-20-660	1-M5	BV40-21-241	1-H10		*****	R005-27-320	2-K3	FD01-28-890A	2-F4	B001-33-691	2-I3	FD01-37-810	2-H5		
N3A1-20-661	1-M5	BV40-21-243	1-H10		*****	M005-27-326A	2-K3	*****		0233-33-691	2-I3	*****			
N250-20-725	1-E5	BV30-21-247	1-H10		0730-26-060	2-J3		*		0259-33-691	2-G6	*****			
N304-20-725	1-F5	BV56-21-249	1-H10		GA2A-26-071	2-M4		*		F805-33-693	2-M4	*	39-000	*	
N3A1-20-751	1-N4	BV11-21-252	1-H10		FD01-26-112	2-E3		*	32-000	0259-33-693	2-G6	*		*	
N3A3-20-752	1-E5	BV11-21-253	1-H10		J001-26-114	2-E3		*		1316-33-693	2-I3	*		*	
ESD5-20-810	1-F9	BV40-21-283	1-H10		FD01-26-121A	2-E3		*****		FD01-33-696	2-H4	*****			
N3A2-20-840B	2-D6	BV11-21-381	1-M9		FD01-26-122	2-E3		FD01-32-049	2-H4	FD01-33-697	2-H4				
N3A1-20-850A	2-D6	BV65-21-381	1-M9		FD01-26-122	2-E3		FD03-32-049	2-H4	FD01-33-71XA	2-H4	B001-39-037B	2-D4		
N3C2-20-850	2-D6	BV11-21-382	1-M9		FD01-26-132	2-E3		FD01-32-090A	2-I4	FD13-33-982	2-H4		2-D5		
N3B7-20-870B	2-D6	BV11-21-383	1-M9		FD01-26-132A	2-E3		B455-32-099	2-I4	FD13-33-980B	2-H4		2-F4		
*****		BV11-21-384	1-I10			2-E4		FD15-32-099	2-I4	FD13-33-992	2-H4		2-F5		
*****		BV11-21-384	1-M9		FD01-26-133B	2-E3		FD15-32-100	2-I4	FD13-33-990B	2-H4		2-F5		
*****		BV45-21-387	1-M9		FD01-26-137	2-M4		FD01-32-11X	2-J6			FD01-39-040C	2-C6		
*	21-000	BV11-21-389	1-M9		FD01-26-139A	2-E3		FD15-32-110A	2-J6	*****		FD01-39-050A	2-C6		
*		BV40-21-3C1	1-M9		GASS-26-15X	2-M4		FD15-32-110B	2-J6	*	34-000	*	FD01-39-065	2-C6	
*****		BV65-21-3Z	1-J9		J001-26-151	2-E3		FD01-32-112	2-J6	*		*	FD01-39-066	2-C6	
					*****								FD01-39-070B	2-C6	
BV11-21-J03	1-D10	BV65-21-391	1-M9		H001-26-205	2-G3		FD01-32-119	2-J6	*****		FD01-39-10C	2-C6		
BV11-21-J04	1-D10	BV12-21-671	1-H11		FD01-26-220	2-F4		FD01-32-119A	2-J6	*****		FD01-39-723	2-C6		
BV50-21-0J1	1-D10	BV11-21-672	1-H11		FD01-26-230	2-E4		FD01-32-120	2-J6	*****		FD01-39-730A	2-F4		
BV11-21-0J5	1-E10	BV11-21-675	1-H11		FD01-26-233	2-G3		FD01-32-123	2-J6	FD01-34-003	2-C5				
BV11-21-0J7A	1-E10	BV65-21-5H1	3-I6		FD04-26-241	2-E3		F110-32-123	2-J6						
BV56-21-0J7	1-E10	BV65-21-5H2	3-I6		FD01-26-25X	2-E3		FD01-32-124	2-J6	FD01-34-011	2-E5	*****			
BV11-21-0J8	1-E10	BV01-21-677	1-F9		FD01-26-250	2-E4		FD01-32-125A	2-J6	FD01-34-011	2-E5	*	40-000	*	
BV11-21-031	1-F9	BV65-21-678	1-E9		FD01-26-261	2-E3		FD02-32-125A	2-J6	*		*		*	
BV11-21-032	1-L9	BV40-21-776	1-I10		FD01-26-281	2-G3		FD01-32-132	2-J6	H380-34-034A	2-C5	*****			
BV11-21-033	1-L9	BV11-21-782	1-I10		FD01-26-285A	2-G3		FD01-32-133	2-J6						
BV11-21-035	1-M9	BV11-21-784	1-I10		FDV1-26-43Z	2-G3		FD01-32-168	2-I4	LA01-34-038	2-M4	N3A1-40-D20F	2-D6		
BV11-21-037	1-E10	BV11-21-786	1-I10		FDV1-26-46Z	2-G3		B001-32-169A	2-I4	B455-34-091	2-F4	FE20-40-061	2-E6		
BV11-21-092	1-E10	BV35-21-793	1-I10		FD04-26-471	2-E3		FD01-32-180	2-J6	FD15-34-110A	2-C5	N3A1-40-061C	2-E6		
BV11-21-093	1-E10	*****			GASS-26-471	2-M4		FD01-32-186	2-J6	FD15-34-110B	2-C5	N3A1-40-061D	2-E6		
BV35-21-094	1-E10	*****			FD01-26-61X	2-G3		FD01-32-202	2-K4	FD01-34-120	2-C5	N3A2-40-061A	2-E6		
BV11-21-095	1-E10	*			B462-26-662	2-G3		H380-32-230	2-I4			N3A1-40-080A	2-E6		
BV56-21-095	1-E10	*	22-000		B462-26-663	2-G3		FD01-32-240	2-K4	FD01-34-151A	2-F5	N3A2-40-080	2-E6		
BV11-21-096	1-E10	*			B462-26-664	2-G3		FD01-32-260A	2-K4	FD01-34-155	2-F5	N3C1-40-100A	2-E6		
BV65-21-1A1	1-E10	*****			FD01-26-668	2-G3		B455-32-279	2-K4	FD01-34-156	2-F5	N3C2-40-100A	2-E6		
BV11-21-1A3	1-E10	*****			FD01-26-669	2-G3		8AB2-32-280	2-K4	FD01-34-160D	2-F5	N3A1-40-190	2-E6		

N3A1-40-290	2-E6	FD01-42-720	2-M6	NA23-43-7A2	2-L7	NA20-45-920B	2-K7	FB01-50-133C	2-K7	FD01-51-SC0D	2-E11	FD07-51-40XB	2-J10
RF36-40-305	2-E6	B455-42-761	2-L6	NA23-43-7A3	2-L7	FD01-45-930	2-D8	FB01-50-144	2-F10	FD01-51-SD0D	2-E11	FD07-51-400B	2-J10
N378-40-307	2-E6	FD01-42-761	2-M6	NA23-43-7A4	2-L7	FD01-45-940A	2-D8	3597-50-152	2-H12	FD01-51-SE1A	2-D11	3972-51-402	2-J10
N3A1-40-354	2-E6	FD01-42-762	2-L6	NA23-43-7A6	2-L7	FD01-45-95X	2-D8	FD01-50-170B	2-E10	FD01-51-SE2A	2-D11	FD07-51-403A	2-J10
JE10-40-355	1-G4	B529-42-763	2-N6	NA23-43-7A7	2-L7	FD01-45-960	2-D8	FD01-50-221B	2-H10	FDY2-51-SM1	2-D11	LA01-51-440A	2-E12
	2-E6	FD01-42-763	2-N6	NA23-43-7A8	2-L7	H002-45-961	2-C7	D001-50-222	2-F10	FDY2-51-SM2	2-D11	G225-51-441	2-E12
JE11-40-355	2-E6	FD01-42-767	2-M6	FD04-43-7A9A	2-M7		2-M13	D002-50-228	3-J10	FD01-51-SL1A	2-D11	FD01-51-5E0B	2-H11
N3A8-40-356	2-E6	FD01-42-768	2-N6	NA23-43-7B3	2-M7		3-N8	FD01-50-231	2-H10	FD01-51-SL2A	2-D11	FD01-51-5E1B	2-H11
B545-40-815	2-F6	FD01-42-790	2-M6	FD05-43-70XB	2-M7	F048-45-964B	2-K7	BF82-50-233A	2-F10	FD01-51-S08A	2-D11	H380-51-5E2	2-H11
N3C1-40-860	2-F6	J001-42-910A	2-M6	F051-43-708A	2-M7	FD01-45-970	2-D8	FD01-50-260A	2-H10	FD01-51-S1Y	2-E11	FD01-51-5F0B	2-H11
N3A1-40-865A	2-F6	BC1M-42-980	2-M6	FD04-43-71YC	2-M7	FD01-45-980	2-D8	FD01-50-3A0	2-H10	FD01-51-0A1	2-N10	FD01-51-5F1B	2-H11
N3A1-40-870B	2-F6	FB01-42-980	2-M6	FD01-43-710A	2-J7	FD01-45-990	2-D8	FD01-50-3B0	2-H10	B455-51-0A6	2-C11	FD01-51-5H0D	2-N11
N3A1-40-872	2-F6	FB01-42-985	2-N6	FD04-43-72YC	2-M7			FD01-50-31X	2-H10	FD01-51-0B7	2-N10	FD01-51-5H1C	2-N11
				FD01-43-720A	2-J7			FD07-50-31Y	2-H10	BR70-51-0E1	2-N10	FD01-51-5H2	2-N11
*****		*****		FD05-43-73XC	2-M7	*****		FD01-50-510E	2-M10	FD01-51-0K0D	2-N10	FD01-51-5H3	2-N11
*		*		FD01-43-740B	2-G7	* 46-000 *		FD01-50-516A	2-M10	FD01-51-0K7	2-N10	FD01-51-5H4	2-N11
* 41-000 *		* 43-000 *		FD01-43-750C	2-M7			FD01-50-530E	2-M10	FD01-51-0K8	2-N10	FD01-51-5J0D	2-N11
*****		*****		FD04-43-780F	2-M7	*****		FD01-50-536A	2-M10	FD01-51-0L0D	2-N10	FD01-51-5J1C	2-N11
				FD04-43-800B	2-G7	FD02-46-AT1	2-E8	FD01-50-538A	2-M10	FD01-51-0L5	2-N10	FD01-51-5J3	2-N11
				FD01-43-810A	2-J7			FD01-50-539A	2-M10	H380-51-013	3-H7	FD01-51-5T0	2-G10
0727-41-023	2-D7	H261-43-028	2-F7	FD01-43-836B	2-H7	FD02-46-030	2-E8	FD01-50-6AXB	2-L10	FD01-51-025	2-N10	FD01-51-5V0	2-G10
0727-41-131	2-D7	FD01-43-041	2-D7	FD01-43-840B	2-H7	FC07-46-040A	2-E8	NA01-50-6B1	2-L10	FD01-51-030D	2-N10	FD01-51-5Z1B	2-N11
0305-41-140	2-D7			F100-43-85Y	2-J7	J001-46-051	2-E8	NA01-50-6B2	2-L10	FC42-51-036	2-C11	FD01-51-577	2-K11
FD01-41-30XA	2-D7	HF23-43-090A	2-F7	B455-43-853	2-J7	FD02-46-058	2-E8	FD01-50-6B0B	2-L10	FD01-51-037	2-N10	FD01-51-58VC	2-N11
H266-41-341	2-G6	H001-43-095	2-M13	FD01-43-86XB	2-J7	FD02-46-10XE	2-E8	FD01-50-615	2-L10	FD02-51-037	2-N10	FD01-51-564A	2-N11
FD01-41-360A	2-I6	HF23-43-099	2-F7	FD01-43-86YB	2-J7	FD02-46-10GC	2-E8	FD01-50-619A	2-L10	FD01-51-040D	2-N10	FD01-51-585	2-K11
FD03-41-370	2-I6	HE01-43-140	2-F7	FD01-43-860E	2-M7	FD02-46-570A	2-E8	FD01-50-640A	2-M10	FD01-51-047	2-N10	FD01-51-589	2-N11
F100-41-370	2-I6			FD01-43-87XA	2-J7	0187-46-683	2-D7	FD01-50-644A	2-M10	FD01-51-056	2-G11	FD01-51-59XA	2-K11
G091-41-412	2-G6	D001-43-152	2-D7	FD01-43-87YA	2-J7	H380-46-684	1-I11	FD01-50-646B	2-M10	FD01-51-057	2-G11	FD01-51-591	2-K11
FD01-41-419	2-G6			FD04-43-920	2-M7	H380-46-689	1-I11	FD01-50-649A	2-M10	FD01-51-06XB	2-G11	FD01-51-594	2-K11
F100-41-421	2-G6	FB02-43-152A	2-E8	NA17-43-902	2-M7			FD01-50-650D	2-M10	FD01-51-060D	2-G11	FD01-51-6A5	2-H11
0813-41-422D	2-G6	F501-43-221A	2-G7	B01C-43-954	2-G7	*****		FD01-50-654A	2-M10	FD01-51-061	2-G11	FD01-51-661A	2-H11
H005-41-424	2-G6	FD04-43-250F	2-I7	FD01-43-980B	2-J7	* 49-000 *		FD01-50-7P0	2-H12	FD01-51-064A	2-G11	FD01-51-668	2-H11
H001-41-443	2-D7	FD04-43-260C	2-I7	*****		* 49-000 *		FB01-50-733	2-H10	B481-51-069	2-K11	FD01-51-669	2-H11
		FD04-43-270B	2-L7	* 44-000 *		*****		FD01-50-741C	2-D11	NA01-51-069	2-G11	FD01-51-671C	2-H11
B312-41-470	2-G6	FD04-43-280D	2-L7	* 44-000 *		*****		G043-50-742	3-E10	FD01-51-07XB	2-G11	FB01-51-665	2-E11
B312-41-522	2-H6	FD01-43-30XA	2-D7	*****		FB05-49-240	2-N4	FD01-50-751C	2-D11	FD01-51-070D	2-G11	NA01-51-669	2-E11
B312-41-532	2-H6	FD02-43-30XA	2-F7			H005-49-460	2-H6	FD01-50-753	2-M13	FD01-51-071	2-G11	FD01-51-671	2-I11
FD01-41-600B	2-J6	FD04-43-311B	2-L7			H005-49-470	2-H6	G043-50-753	3-L10	FD01-51-1E6	2-G11	FD01-51-674	2-I11
FD01-41-660B	2-J6	FD04-43-320D	2-L7					FD01-50-783	2-H12	FD01-51-143	2-L11	FD01-51-676	2-J11
FD01-41-661B	1-C4	FD04-43-360B	2-I7	FD01-44-010G	2-N7	W001-49-510	2-H6	FD01-50-790A	2-H12	FD01-51-144	2-L11	FD01-51-677	2-I11
FD01-41-662B	1-M5	FD04-43-370B	2-I7	FD01-44-150	2-N7	B603-49-580	2-G7	B482-50-792	2-H12	EA02-51-146A	2-K11	FD01-51-678	2-I11
FD01-41-920	2-G6	FD04-43-40Z	2-H7	GA2B-44-375A	2-N7	F100-49-686	2-H7	FD02-50-792	2-K11	EA04-51-146A	2-L11	FD01-51-68YB	2-H11
F100-41-990B	2-G6	GDY1-43-40ZB	2-H7	0118-44-375	2-N7	0839-49-686A	2-H6	FD03-50-792	2-K11	8BFH-51-150	2-L11	FD01-51-680C	2-I11
		B6Y4-43-41Z	2-H7	FD01-44-410	2-N7			FD01-50-793	2-H12	FD01-51-151	2-L11	FD01-51-682	2-H11
*****		FD01-43-443A	2-G7	FD01-44-410A	2-N7	*****		FD01-50-794A	2-H12	FD01-51-152	2-M11	FD01-51-683	2-I11
* 42-000 *		H001-43-443	2-G7	FD01-44-420A	2-N7	* 50-000 *		FD01-50-795	2-H12	FD01-51-153B	2-L11	FD01-51-684A	2-I11
* 42-000 *		B603-43-45XA	2-G7	FD01-44-420B	2-N7	*****		GA7B-50-795	2-H12	FD01-51-155B	2-L11	FD02-51-684	2-I11
*****		FD04-43-58A	2-L7	*****		*****		UB39-50-795	2-E11	FD02-51-159	2-L11	FD01-51-69YB	2-H11
		W023-43-504	2-G6	*****		*****		E016-50-796	2-H12	8BFH-51-160	2-L11	FD01-51-690C	2-I11
B596-42-045	2-K6			* 45-000 *		*****		FD01-50-798	2-H12	FD01-51-161	2-L11	FD01-51-692	2-H11
0866-42-046	2-K6	FD04-43-505	2-L7	*****		FD01-50-AF5	2-H10	FD02-50-798	2-H12	FD01-51-162	2-M11	FD01-51-693	2-I11
FD17-42-11X	2-L6	W023-43-505	2-G6	*****		FD01-50-A21	2-E10	FD01-50-799	2-H10	FD01-51-163B	2-L11	FD01-51-694A	2-I11
HG30-42-11X	2-L6			FD01-45-111	2-C8	FD01-50-CR0	2-E10	FD01-50-8R0B	3-E10	FD02-51-169	2-M11	FD02-51-694	2-I11
FD15-42-110	2-K6			FD01-45-112	2-C8	FD01-50-CS0	2-E10	FD01-50-8S0B	3-E10	FD01-51-17XE	2-L11	FD01-51-695	2-I11
FD15-42-110A	2-K6	NA23-43-515	2-H7	FD01-45-115B	2-C8	EA01-50-EA0	2-K7	FD01-50-803	2-H10	FD01-51-170B	2-L11	FD01-51-696	2-I11
FD17-42-110A	2-K6	FD04-43-540A	2-G7	FD01-45-280C	2-J7	FD01-50-0KXA	2-E10	G158-50-803	2-F10	FD01-51-173	2-L11	FD01-51-711A	2-G12
FD17-42-110B	2-K6	FDY1-43-55X	2-G7	FD01-45-280D	2-J7	FD01-50-0K9A	2-E10	FD01-50-850C	2-K11	FD01-51-18XE	2-M11	FD01-51-721C	2-G12
HG31-42-114	2-K6	G309-43-607	2-G4	FD01-45-320D	2-J7	FD01-50-0K1B	2-E10	EA01-50-891	3-L5	FD01-51-180B	2-L11	FD02-51-731	2-G12
						BR70-50-0Z1	2-E10	EA01-50-891A	3-L5	FD01-51-183	2-M11	FD02-51-741A	2-G12
FD01-42-210A	2-K6			FD01-45-33XC	2-J7	BR70-50-0Z2	2-C14	FD01-50-894	3-L5	FD01-51-24XA	2-M11	FD07-51-810F	2-J10
FD01-42-231A	2-L6	B533-43-62Z	2-H7	FD01-45-36XA	2-J7			FDY2-50-91XB	2-H12	FD01-51-240B	2-M11	FD13-51-811	2-K10
FD01-42-232	2-L6	NA23-43-625	2-H7	FD01-45-36ZA	2-J7	FD01-50-0Z5	2-E10	FD01-50-912	2-I12	FD01-51-241B	2-M11	FD07-51-812B	2-J10
FD01-42-237	2-K6	FD01-43-63XE	2-I7	FD01-45-360B	2-K7	FD01-50-031C	2-E10	FD01-50-913	2-I12	FD01-51-244	2-M11	FD07-51-813A	2-J10
FD01-42-242	2-L6	FD01-43-63XF	2-I7	D001-45-367	2-K7	BF67-50-033	2-E10	FDY2-50-92XB	2-I12	FD01-51-246	2-M11	FD08-51-813A	2-J10
GE40-42-243	2-L6	FD03-43-63XE	2-I7	FD01-45-510D	2-I6	GJ21-50-049	2-E10			FD01-51-248	2-M11	FD09-51-813	2-J10
FD01-42-244	2-L6	FD03-43-63XF	2-I7	HE01-45-540	2-I6	FA01-50-054	2-K7			FD01-51-249	2-M11	FD13-51-820	2-J10
H240-42-245A	2-L6	B604-43-63Z	2-H7	FD01-45-611A	2-C8	FD01-50-070B	2-E10	*****		FD01-51-25XA	2-M11	8D63-51-821	2-N11
UE54-42-250	2-L6	W023-43-635	2-I7	FD01-45-612	2-C8	FD01-50-1AXB	2-F10	* 51-000 *		FD01-51-250B	2-N11	DA14-51-831	2-M13
BF67-42-252	2-M6	0136-43-635	2-I6	FD01-45-711	2-C8	FD01-50-1AYB	2-F10	* 51-000 *		FD01-51-251B	2-N11	B092-51-833	2-M13
D061-42-270	2-L6	FD01-43-64XD	2-I7	FD01-45-712A	2-D8	FD01-50-1B0A	2-F10	*****		BF67-51-261	2-M13	FB03-51-9A1	2-M13
FD01-42-289	2-L6	FD01-43-64XE	2-I7	FD01-45-713	2-D8	FD01-50-1C0A	2-F10			FD01-51-261A	2-D12	FB03-51-9A2	2-M13
FD01-42-298	2-L6	FD03-43-64XD	2-I7	FD01-45-910A	2-D8	FD01-50-1D0	2-F10	B252-51-PJ5A	2-H12	BR70-51-264	2-M13	FD01-51-9B0B	3-L10
FD01-42-41X	2-C7	FD03-43-64XE	2-I7	FD01-45-911	2-D8	FD01-50-1E0	2-F10	FC17-51-PS2A	3-L10	FD01-51-270C	2-D12	FD01-51-9C0B	3-L10
FD01-42-510A	2-M6	FD01-43-640B	2-G7	FB01-45-914	2-K7	FD01-50-1F1	2-F10	FD01-51-PS3	2-I12	G225-51-273	2-D12	FD03-51-966</	

PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

FD01-68-877 02 3-J9	FD01-69-852 3-N5	FD01-70-700B 2-J13	H001-76-714 3-H5	FD05-88-161 18 2-J16	99650-58060 2-H5
GJ21-68-885B00 3-F9	FD01-69-858 3-C6	FD01-70-750C 2-F13	H001-76-717 3-H5	FD05-88-161 33 2-J16	99651-94060 2-H5
	FD01-69-859 3-C6		H001-76-725 3-C5	FD01-88-162 2-J16	99655-90005 2-G5
	FD01-69-861 3-N5	*****	3-E5	FD01-88-174 2-F16	99655-90010 2-G5
UB54-68-885 00 3-C10	FD01-69-864 3-N5	*****	R001-76-734 3-C5	FD01-88-180 02 2-J16	99655-90015 2-G5
UB54-68-885 18 3-C10	FD01-69-865 3-N5	* 71-000 *	3-E5	FD03-88-180 02 2-J16	99655-90020 2-G5
UB54-68-885 82 3-C10	EA05-69-871 3-C6	*****	*****	FD05-88-180 02 2-J16	99655-90025 2-G5
FD01-68-89X 82 3-K9	EA05-69-872 3-C6	*****	*****	FD05-88-180 17 2-J16	99655-90030 2-G5
FD09-68-89X 02 3-K9	EA05-69-873 3-N5	*****	*****	FD05-88-180 18 2-J16	99655-90035 2-G5
FD01-68-911A02 3-F3	F114-69-890A 3-D6	FD01-71-020B 2-G13	* 88-000 *	FD05-88-180 33 2-K16	99655-90040 2-G5
FD01-68-912A02 3-F3	F114-69-893 3-C6	FD01-71-030D 2-G13	*****	FD05-88-180 34 2-K16	99655-90045 2-G5
FD01-68-930A02 3-K5	FB03-69-896A 3-D6	FD01-71-050 2-G13	*****	FD01-88-181 02 2-K16	99655-90050 2-G5
FD01-68-940B02 3-J5	GA28-69-897 3-D6	FD01-71-180A 2-G13	*****	FD03-88-181 02 2-K16	99655-90055 2-H5
FD01-68-950B02 3-J5	G034-69-897 3-D6	FD01-71-1D0 2-G13	FD01-88-005 2-G16	FD05-88-181 02 2-K16	99655-90060 2-H5
FD01-68-960C02 3-K5	FD01-69-9H1 3-C6	FD01-71-1X1 2-H13	FD01-88-006 2-G16	FD05-88-181 17 2-K16	99700-5080 2-E12
*****	FD01-69-9H2 3-C6	FD01-71-11Y 2-G13	FD01-88-062 2-F16	FD05-88-181 18 2-K16	99700-7180 2-K11
* 69-000 *	FD01-69-9H3 3-D6	FD15-71-11Z 2-G13	FD01-88-072 2-F16	FD05-88-181 33 2-K16	99701-3270 2-K11
*****	FD01-69-9H4 3-D6	FDY1-71-110A 2-G13	F100-88-073 2-F16	FD05-88-181 34 2-K16	99701-4278 2-K11
* 69-000 *	FD04-69-920 3-D6	FD01-71-119 2-H13	FD01-88-161 02 2-G16	FD01-88-6D0 02 2-K16	99701-6030 2-E15
*****	FD01-69-921 3-D6	FD01-71-12XB 2-G13	FD01-88-161 17 2-G16		99701-6040 2-M11
UB40-69-C61 3-H10	FDD4-69-922 3-E6	FD01-71-120B 2-G13	FD01-88-161 33 2-G16	FD03-88-6D0 02 2-K16	99701-6049 2-J11
FA03-69-C72A 3-I10	FD01-69-923 3-D6	FD01-71-131A 2-F13	FD01-88-165 02 2-F16	FD05-88-6D0 02 2-K16	99701-6050 2-D12
FD01-69-D21 3-H10	EA05-69-924 3-C6	FD01-71-15XD 2-H13	FD02-88-165 17 2-F16	FD05-88-6D0 17 2-K16	2-F12
FD01-69-D21A 3-H10	F100-69-926A 3-D6	FD01-71-15DE 2-G13	FD01-88-165 33 2-F16	FD05-88-6D0 18 2-K16	2-J11
B001-69-D51 3-H10	KA02-69-925 3-D6	FDY1-71-200 2-G13	FD01-88-1H5 02 2-G16	FD05-88-6D0 33 2-K16	99703-4350 2-G11
KA10-69-D61A 3-H10	GA28-69-927 3-D6	FD01-71-230A 2-G13	FD01-88-1H5 17 2-G16	FD05-88-6D0 34 2-K16	99703-8605 2-N10
FD01-69-D14 3-H10	FD01-69-929 3-D6	FDY1-71-24X 2-H13	FD01-88-1H5 33 2-G16	FD01-88-6D2 02 2-K16	99705-1115 3-E8
N3C1-69-036A 3-I10	FD01-69-960A02 3-C6	FDY1-71-24X 2-H13	FD01-88-1H5 02 2-F16	FD05-88-6D2 02 2-L16	99705-1130 3-L7
N3C2-69-036A 3-I10	FD01-69-970C02 2-F12	FD01-71-24X 2-E13	FD01-88-1H5 17 2-F16	FD05-88-6D2 02 2-L16	3-E8
N3C3-69-036 3-I10	FD03-69-970C02 2-F12	FD01-71-253A 2-E13	FD01-88-1H5 33 2-F16	FD05-88-6D2 17 2-L16	3-L7
N3C4-69-036 3-I10	FD03-69-970D02 2-F12	FD01-71-272B 2-H13	FD01-88-101 2-G16	FD05-88-6D2 18 2-L16	99963-6930 1-17
N3C4-69-036A 3-I10	EA01-69-973 2-F12	FD01-71-274A 2-H13	FD01-88-102 2-G16	FD05-88-6D2 33 2-L16	99963-6940 1-17
NSA1-69-044B 3-I10	EA05-69-973 2-F12	FG01-71-311A 2-H13	FD11-88-103 2-G16	FD05-88-6D2 34 2-L16	99963-6950 1-17
FA01-69-064A 3-I10	FD02-69-973 2-F12	FDY1-71-400B 2-H13	FD01-88-104 2-G16	B456-88-815 2-L16	99963-6960 1-17
HG30-69-065 3-I10	FD05-69-973 2-F12	FD01-71-440B 2-H13	FD15-88-110 02 2-G16	B240-88-818 2-L16	99963-6970 1-17
NA01-69-068A 3-I10	FD01-69-98X 3-F9	FD01-71-490B 2-H13	FD18-88-110 02 2-G16	EA01-88-818 2-L16	*****
FD03-69-074A 3-H10	FD01-69-981A02 3-N5	FD01-71-651A 2-G13	FD18-88-110 17 2-G16	*****	* STANDARD PARTS *
FD04-69-074 3-H10	F114-69-983 3-C6	*****	FD18-88-110 33 2-H16	* 90-000 *	*****
HG30-69-119 3-L5	F114-69-984 3-C6	* 75-000 *	FD18-88-110 34 2-H16	*****	99381-1400 1-H6

FD01-69-123 3-F10	*****	* 75-000 *	F110-88-110 02 2-H16	90620-17636 2-G5	
FD01-69-183 3-F10	* 70-000 *	*****	FD01-88-111 02 2-H16	90622-65726 2-G5	
HG31-69-220C 3-F10	*****	3625-75-139 2-G15	FD03-88-111 02 2-H16	90623-25726 2-G5	
FD01-69-240 MB 3-E10	*****	*****	FD05-88-111 02 2-H16	90623-35726 2-G5	
FD01-69-240 NU 3-E10	FD01-70-020B 2-E13	*****	FD15-88-111 02 2-H16	90623-55726 2-G5	
FD01-69-240 PT 3-E10	FD01-70-030D 2-E13	* 76-000 *	FD18-88-111 02 2-H16	90692-55726 2-H5	
FD01-69-240 PZ 3-E10	FD01-70-050 2-E13	*****	FD18-88-111 17 2-H16	90701-7270 2-G11	
FD01-69-240 3L 3-E10	FD01-70-1X1 2-F13	*****	FD18-88-111 18 2-H16	*****	
HG31-69-240 3-F10	FD01-70-11Y 2-E13	0208-76-071 3-C10	FD18-88-111 33 2-H16	* 99-000 *	
	FD01-69-242 MB 3-F10	FD01-76-120 MB 3-E10	FD18-88-111 34 2-H16	*****	
	FD01-69-242 NU 3-F10	FD01-76-120 NU 3-E10	FD15-88-112 2-H16		
	FD01-69-242 PT 3-F10	FD01-76-120 PT 3-E10	FD01-88-124 2-F16		
	FD01-69-242 PZ 3-F10	FD01-76-120 PZ 3-E10	FD15-88-130 02 2-H16		
	FD01-69-242 3L 3-F10	FD01-76-120 3L 3-E10	FD18-88-130 02 2-H16		
GA5R-69-261 02 3-F10	FD01-70-120B 2-E13	FD01-76-120 3L 3-E10	FD18-88-130 17 2-K16		
GA5R-69-263 02 3-G10	FD01-70-120B 2-E13	FD01-76-120 3L 3-E10	FD18-88-130 18 2-H16	99236-0571 1-J3	
FD01-69-270C02 3-F10	FD01-70-130A 2-F13	FD01-76-120 MB 3-E10	FD18-88-130 33 2-H16	99324-07200 1-M6	
FD03-69-270C02 3-F10	FD01-70-15XC 2-F13	FD01-76-120 NU 3-E10	FD18-88-130 34 2-H16	99324-07400 1-M6	
FD01-69-276A 2-D11	FD01-70-150D 2-E13	FD01-76-120 PT 3-E10	FD19-88-130 02 2-H16	99328-04010 3-D9	
	FDY1-70-200 2-E13	FD01-76-180 MB 3-E10	FD15-88-131 02 2-H16	99340-05540 1-G9	
		FD01-76-180 NU 3-E10			
		FD01-76-180 PT 3-E10			
GA5R-69-277 02 3-G10	FD01-70-230A 2-E13	FD01-76-180 PZ 3-E10	FD18-88-131 02 2-H16	99351-04999 1-E6	
FD15-69-320 02 3-F10	FDY1-70-24X 2-F13	FD01-76-180 3L 3-E10	FD18-88-131 17 2-H16	1-H5	
FD18-69-320 02 3-F10	FDY4-70-24X 2-F13	FD01-76-190 2-C10	FD18-88-131 18 2-H16	99351-06999 1-H5	
B316-69-361 3-M3	FD01-70-242B 2-E13	FD01-76-201 2-C10	FD18-88-131 33 2-H16	2-H6	
FD01-69-44X 00 3-K5	FD01-70-252A 2-F13	FD01-76-202 2-C10	FD18-88-131 34 2-H16	99351-08999 1-H4	
FD01-69-47YA 3-D10	FD01-70-252B 2-F13	FD01-76-208 2-C10	FD19-88-132 02 2-H16	99359-0815 1-C8	
FD01-69-760C02 3-L9	FD01-70-274A 2-F13	FD01-76-210B 2-C10	FD01-88-152 2-H16	99359-0815M 2-C8	
FD01-69-768A02 3-L9	FD01-70-274A 2-F13	FD15-76-250 2-C10	FD01-88-153 2-H16	99359-0819 2-C8	
FD01-69-771A02 3-L9	FDY1-70-400B 2-H13	FD01-76-260 2-C10	FD01-88-155 2-H16	99359-0819 2-C8	
FD01-69-781 02 3-L9	FD01-70-440B 2-F13	FD01-76-290 2-C10	FD01-88-160 02 2-H16	99541-00603 2-H7	
FD01-69-810B 3-N5	FD01-70-490B 2-F13	FD02-76-290 2-C10	FD03-88-160 02 2-H16	99541-01105 1-L3	
F114-69-810B 3-N5	0187-70-491 2-C7	B093-76-605 3-M8	FD05-88-160 02 2-H16	99541-01201 1-T9	
FD01-69-825A 3-D6	FD04-70-600B 2-H13	B002-76-619A 3-F9	FD05-88-160 17 2-H16	99541-01252 1-K4	
F114-69-825 3-D6	FD01-70-601A 2-J13	H043-76-619A 3-M8	FD05-88-160 18 2-H16	99541-01401 2-L4	
FD01-69-840 3-N5	FD01-70-610A 2-D13	B093-76-641 3-C9	FD05-88-160 33 2-H16	99541-01601 1-D6	
FD01-69-842 3-D6	FD01-70-640 2-I13	B094-76-662 3-M8	FD05-88-160 34 2-H16	1-L9	
FD01-69-845 3-N5	*****	B094-76-663 3-M8	FD01-88-161 02 2-H16	99606-23030 1-M6	
FD01-69-846 3-C6	FD01-70-651A 2-E13	8532-76-672 2-J10	FD03-88-161 02 2-H16	99611-1500 2-G6	
FD02-69-846 3-C6	FD01-70-661 2-I13	S084-76-677 3-J8	FD05-88-161 02 2-H16	99636-04130 2-G5	
FD01-69-851 3-N5	FD01-70-700B 2-I13	HA14-76-707 3-H5	FD05-88-161 17 2-H16	99650-28060 2-H5	

ALPHABETICAL INDEX *** ENGLISH ***

***** * A * *****	BEARING, NEEDLE-----	1-K7 1-K10 1-L7 2-J3 1-17 2-E3 1-N6 2-M16 2-M16 2-M16 2-M16 2-M16 1-F8 1-N6 2-D11 2-D11 3-M9 3-K8 3-K8 3-N8 3-K8 3-E8 3-C8 3-L7 3-L8 3-L8 2-D5 2-C5 2-D5 2-C5 2-E4 2-E4 3-N8 3-K8 3-K8 1-J8 1-L8 3-E5 3-N4 3-E7	BEARING, PINION----- BEARING, ROLLER----- BEARING, WHEEL----- BELT, V----- BELT 'A' (L), FRT SEAT----- BELT 'A' (R), FRT SEAT----- BELT 'B' (L), FRT SEAT----- BELT 'B' (R), FRT SEAT----- BELT 'V'----- BEZEL (L), LAMP----- BEZEL (R), LAMP----- BEZEL, OPENER LEVER----- BLADE (L), WIPER-FRONT----- BLADE (R), WIPER-FRONT----- BLADE, WIPER----- BLADE, WIPER-FRONT----- BLOCK, FUSE----- BLOCK, MAIN FUSE----- BLOWER UNIT----- BOARD (C), TRUNK----- BOARD, PARTITION----- BODY & PISTON (L), CALIPER----- BODY & PISTON (R), CALIPER----- BODY (L), FRONT DOOR----- BODY (R), FRONT DOOR----- BODY, FILLER CAP----- BODY, LIFT GATE----- BODY, LWR-CONT. VALVE----- BODY, OIL FILTER----- BODY, THROTTLE----- BODY, UPPER-CONTROL----- BOLT----- 1-C9 1-C10 1-D7 1-D9 1-D10 1-F7 1-F9 1-F11 1-H7 1-H11 1-I9 1-J8 1-K9 1-L9 2-C3 2-C5 2-C6 2-C6 2-C14 2-D5 2-E4 2-E6 3-L4 2-M6 2-M6 1-N8 1-K10 2-M12 3-F10 3-F10 3-F10 3-F10 3-I1 3-D10 1-N6 2-G3 2-K3 2-M4 1-K7 1-N8 1-H8 1-H8 1-I7 1-I7 1-N10 1-C11 1-E11 1-G11 1-J3 1-J7 1-K3	BOLT, COMPRESSOR-AIR CON.- BOLT, CONNECTOR----- 1-D6 1-H6 2-G6 2-G7 2-I7 2-L7 1-D10 1-L9 2-M4 2-L6 1-F8 1-D4 1-K4 2-F3 2-M4 3-E4 3-M6 1-F4 2-C14 2-G6 2-E16 1-C6 3-E5 2-E11 2-M12 2-M13 1-L9 1-J3 2-E3 2-M7 2-K3 1-C6 2-C10 3-D3 3-D3 2-I4 2-H11 2-C13 1-H3 2-N12 2-E4 2-J12 2-D3 2-D3 2-C5 2-L15 1-D8 2-E11 2-J4 2-H4 2-N12 2-M12 1-N8 3-M6 2-H15 2-I15 3-N7 3-L9 3-D10 1-E10 1-F9 1-L6 2-K7 3-N6 2-L7 2-H3 2-F16 2-H13 2-H13 2-I11 3-I9 3-J10 2-H10 3-I7 3-M10 3-N10 3-I7 3-M10 2-H13 3-J9 3-H9 2-H3 2-H3 2-I11 2-H11 2-K11 2-N10	BRACKET (R), LAMP----- BRACKET (R), LOWER-F. SIDE----- BRACKET (R), QUARTER TRIM----- BRACKET (R), RR. BUMPER----- BRACKET (R), SPOILER----- BRACKET (R), TRIM-QTR PANEL----- BRACKET (R), TRUNK SIDE----- BRACKET, A. C. C.----- BRACKET, A. C. C. BOX----- BRACKET, ACCEL CABLE----- BRACKET, ACCEL WIRE----- BRACKET, AIR BAG----- BRACKET, AIR CLEANER----- BRACKET, BOOST SENSOR----- BRACKET, CALLE----- BRACKET, CENTER----- BRACKET, CENTER PANEL----- BRACKET, COMPRESSOR----- BRACKET, CONDENSER----- BRACKET, CONTROL UNIT----- BRACKET, DIFF. MOUNTING----- BRACKET, DIST. MODULE----- BRACKET, DUCT SPEAKER----- BRACKET, ENGINE HARNESS----- BRACKET, EX. MANIFOLD----- BRACKET, FLOOR----- BRACKET, FRONT----- BRACKET, FRONT COMB. LAMP----- BRACKET, HANGER----- BRACKET, HARNESS----- BRACKET, HEAD LAMP----- BRACKET, HOLE-ENG. WIRING----- BRACKET, HOSE----- BRACKET, INTER COOLER----- BRACKET, LICENCE LAMP----- BRACKET, MOTOR----- BRACKET, OIL COOLER----- BRACKET, OVERHEAD CONSOLE----- BRACKET, PIPE----- BRACKET, REAR----- BRACKET, REAR FINISHER----- BRACKET, RELAY----- BRACKET, RR. CONSOLE-NO. 1----- BRACKET, STABILIZER----- BRACKET, STEERING----- BRACKET, STOPPER----- BRACKET, SUN ROOF-FRONT----- BRACKET, TANK----- BRACKET, TRIM----- BRACKET, TUBE----- BRACKET, TUNER----- BRACKET, VACUUM CHAMBER----- BREAKER----- BREATHER----- BREATHER, AIR-T/MISSION----- BRKT SET, DASH POT-THROT----- BRKT (L), STRUT BAR----- BRKT (R), STRUT BAR----- BRKT, FRT SIDE TRIM----- BRKT, JOINT-SPEAKER DUCT----- BRKT, MOTOR-ANTENNA----- BRUSH----- BRUSH, YOKE----- BULB-----	2-N11 3-J6 2-K15 2-D12 2-F12 2-J11 3-E4 3-D7 2-C5 2-H10 2-H10 1-C7 1-C8 1-I11 1-N6 2-D7 2-M6 1-D8 2-F4 2-H6 2-H7 2-G16 3-E9 3-C9 2-E4 2-D5 2-D4 2-E5 2-E4 2-D5 2-F4 1-L8 2-D5 2-H4 2-H4 3-C8 3-D8 3-L7 2-N10 3-C8 2-J7 1-E4 2-D12 2-E11 1-C9 1-I6 3-L7 3-F9 1-F9 1-J8 1-L8 3-E7 2-K11 3-N6 2-L15 2-F5 2-H15 2-C7 3-D6 3-I4 3-K3 1-E10 3-E7 1-I4 3-E8 2-J3 1-C9 1-H7 1-C5 1-I4 2-N12 2-N12 3-H9 3-H7 3-I7 1-H8 1-K8 2-C15 2-E12 2-E15 2-F15 2-G11 2-G15 2-J11 2-K11 2-N10	BULB----- BULB & SOCKET----- BULB, INTERIOR MIRROR----- BULB, MODE CONTROL----- BULB 'B', WARNING UNIT----- BUMPER, BOUND----- BUMPER, REAR----- BUMPER, REAR LOWER----- BUSH----- BUSH SET----- BUSH, CHANGE----- BUSH, DAMPER----- BUSH, ELBOW JOINT----- BUSH, HINGE----- BUSH, INNER----- BUSH, OUTER----- BUSH, FILLER BALL----- BUSH, RUBBER-LWR ARM----- BUSH, STABILIZER-RR----- BUSHING, DAMPER-LOWER----- BUSHING, LOWER ARM----- BUSHING, RUBBER----- BUSHING, RUBBER-FRT----- BUTTON (L), HORN----- BUTTON (R), HORN----- ***** * C * ***** CABLE (L), R.-PARK----- CABLE (R), R.-PARK----- CABLE, APENL----- CABLE, OPENER----- CABLE, PARKING-FRT----- CALIPER (L), FRT BRAKE----- CALIPER (L), PADLESS-FR----- CALIPER (L), PADLESS-RR----- CALIPER (L), RR BRAKE----- CALIPER (L), FRT BRAKE----- CALIPER (R), PADLESS-FR----- CALIPER (R), PADLESS-RR----- CALIPER (R), RR BRAKE----- CAM, FIRST IDLE----- CANISTER----- CAP----- CAP SET, RESERVE TANK----- CAP (L), HOLE-TRUNK TRIM----- CAP (R), HOLE-TRUNK TRIM----- CAP, ASSIST-DOOR TRIM----- CAP, BLEEDER SCREW----- CAP, BLIND----- CAP, BLIND-OIL PAN----- CAP, CENTER----- CAP, DOOR TRIM----- CAP, FILLER----- CAP, HUB----- CAP, OIL FILLER----- CAP, RADIATOR----- CAP, RUBBER----- CAP, SEAL----- CAP, SPRING----- CAP, SUB TANK----- CAP, TANK-----	2-N11 3-J6 2-K15 2-D12 2-F12 2-J11 3-E4 3-D7 2-C5 2-H10 2-H10 1-C7 1-C8 1-I11 1-N6 2-D7 2-M6 1-D8 2-F4 2-H6 2-H7 2-G16 3-E9 3-C9 2-E4 2-D5 2-D4 2-E5 2-E4 2-D5 2-F4 1-L8 2-D5 2-H4 2-H4 3-C8 3-D8 3-L7 2-N10 3-C8 2-J7 1-E4 2-D12 2-E11 1-C9 1-I6 3-L7 3-F9 1-F9 1-J8 1-L8 3-E7 2-K11 3-N6 2-L15 2-F5 2-H15 2-C7 3-D6 3-I4 3-K3 1-E10 3-E7 1-I4 3-E8 2-J3 1-C9 1-H7 1-C5 1-I4 2-N12 2-N12 3-H9 3-H7 3-I7 1-H8 1-K8 2-C15 2-E12 2-E15 2-F15 2-G11 2-G15 2-J11 2-K11 2-N10
-------------------------	----------------------	--	---	---	---	---	--	---

ALPHABETICAL INDEX *** ENGLISH ***

CAP,VANE PUMP TANK-----	2-L4	CLIP,FENDER GRILLE-----	2-I12	CORD,HIGH TENSION (T-1)--	1-F8	COVER,THERMOSTAT-----	1-J6		
CARRIER,DIFFERENTIAL-----	2-J3	CLIP,FLEXIBLE HOSE-----	2-I6	CORD,HIGH TENSION (T-2)--	1-F8	COVER,UNDER-----	1-C9	*****	
CARRIER,FRONT-----	1-C11		2-I7	CORD,LAMP-----	2-N11		1-G7	* * *	
CARRIER,REAR-----	1-D11	CLIP,HARNES-----	1-D10	CORD,SHORT-----	2-J15	COVER,UNDER-FRONT-----	2-C14	* * *	
CARTRIDGE,OIL FILTER-----	1-E6		1-E10		3-J7	COVER,UNDER-MAIN FUSE BLK	3-L7	*****	
CASE(L),BLOWER-----	3-F4		3-H8	CORE,HEATER-----	3-D4	COVER,UNDER-REAR-----	2-C14		
CASE(R),BLOWER-----	3-F4	CLIP,HEATER UNIT-----	3-D4	COVER-----	3-L7	COVER,UNDER-RELAY BOX-----	3-L7		
CASE,CHANGE CONTROL-----	1-D8	CLIP,HOSE-----	1-J4	COVER NO.1,ADJ-FRT-----	2-E16	COVER,VENT-----	1-C7	FACE,FRONT BUMPER-----	2-E10
CASE,HEATER-----	3-D4		1-N4	COVER NO.1,SIDE-F.SEAT-----	2-G16	COVER,WHEEL CORE-----	2-H4	FAN DRIVE-----	1-L6
CASE,LAMP-----	2-C15	CLIP,HOSE-SUB T.& WATER H	1-L6	COVER NO.4,SIDE-F.SEAT-----	2-G16	COVER,WIPER ARM-FRONT-----	3-K8	FAN(L),COOLING-----	1-J6
	2-L15	CLIP,M.OIL TUBE-----	1-H6	COVER SET-----	1-L8	COVER,WIPER ARM-REAR-----	3-C9	FAN(R),COOLING-----	1-J6
CASE,METER-----	2-E15	CLIP,MUD GUARD-----	2-N12	COVER(L),BUMPER-----	2-G10	COVER'A',FRAME-SLIDE ROOF	3-C6	FANNEL-----	3-C9
CASE,RELAY BOX-----	3-L7	CLIP,OIL TUBE-----	1-H6	COVER(L),DECORATION-----	3-C6	COVER'B',FRAME-SLIDE ROOF	3-C6	FASTENER-----	1-E4
CASE,T/MISSION-----	1-F7	CLIP,PARKING CABLE-----	2-N7	COVER(L),DUST-----	2-M4	COVER'L',HYDRAULIC UNIT-----	2-L7		1-N4
	1-Y9	CLIP,PIPE-----	2-D8	COVER(L),FOG LAMP-----	2-I11	COWLING,RADIATOR-----	1-L6		2-C13
CASE,WARNING UNIT-----	2-E15		2-K7	COVER(L),QTR. TRIM-----	3-K10	CUP,SECONDARY-----	2-H7		2-E10
CASE'A',COOLING UNIT-----	3-F5		3-C9	COVER(L),RETRACTOR-----	2-M16	CUSHION(L),FRT SEAT-----	2-I16		2-H12
	3-G5		3-H4	COVER(L),RR COMB-----	2-M11		2-J16		2-I10
CASE'B',COOLING UNIT-----	3-F5	CLIP,PROTECTOR-----	3-K4	COVER(L),SIDE-----	2-J15	CUSHION(R),FRT SEAT-----	2-G16		2-K7
	3-G5	CLIP,RR BRAKE PIPE-----	3-L7	COVER(L),TRUNK SIDE-----	3-J9		2-H16		2-M13
CASE'C',COOLING UNIT-----	3-G5		2-G4	COVER(R),BUMPER-----	2-E10	CUSHION,RUBBER-----	2-G15		2-M15
CASING,HYDRAULIC UNIT-----	2-M7		2-L10	COVER(R),DECORATION-----	2-G10		3-H3		3-C10
CATALYST,THREE WAY-----	2-D6	CLIP,RR WINDOW MOULD-----	2-L10	COVER(R),DUST-----	3-G6		3-L9		3-D10
CD SOFT-----	3-E7	CLIP,SCUFF PLATE-----	3-H9	COVER(R),FOG LAMP-----	2-M6	CYL,CLUTCH MASTER-----	2-G6		3-F3
CEILING,TOP-----	3-F9	CLIP,SLIDE-----	3-J5	COVER(R),FOG LAMP-----	2-I11	CYL,CLUTCH RELEASE-----	2-G6		3-F9
CHAIN,OIL PUMP-----	1-C6	CLIP,SPOILER-----	3-M10	COVER(R),GLOVE-----	2-I15	CYL,TANDEM MASTER-----	2-H7		3-H9
CHAMBER,EXTRACTOR-----	2-I12	CLIP,TOP CEILING-----	3-F9	COVER(R),QTR. TRIM-----	3-K10				3-J3
CHAMBER,VACUUM-----	1-K5	CLIP,TRIM-----	3-F9	COVER(R),RETRACTOR-----	2-M16	*****			3-J5
CHANGE COMPLETE-----	2-E8		3-F9	COVER(R),RR COMB-----	2-L11	* D *			3-J9
CHANNEL(L),GLASS-----	3-E3		3-H9	COVER(R),SIDE-----	2-I15	* *			3-L10
CHANNEL(R),GLASS-----	3-E3		3-J3	COVER(R),TRUNK SIDE-----	2-J15	*****			3-H9
CHARGE,AIR COOLER-----	1-E4		3-J5	COVER,ACTUATOR-----	3-J9				3-N10
CHECKER,DOOR-----	3-G3	CLIP,WASHER HOSE-----	3-K10	COVER,AIR CLEANER-----	1-N4	DAM,AIR-SKIRT-----	3-L10		2-K12
CLAMP-----	2-L4		3-I8	COVER,BEARING-----	1-F7	DAM,FRT.WSHLD GLASS-----	3-L5		3-H9
CLAMP,BATTERY-----	1-N8		3-N8	COVER,BIND-----	1-G7	DAMPER(L),FRONT-----	2-E5	FASTENER,BONNET-----	3-H9
CLAMP,HOSE-----	1-E5		2-J12	COVER,BLIND-EXTENSION HOU	1-H7	DAMPER(R),FRONT-----	2-E5	FASTENER,DUCT PANEL-----	1-G9
	1-H4	CLIP,WIRE-BONNET-----	2-J12	COVER,BOX-BATTERY-----	1-N8	DAMPER(R),REAR-----	2-C4		1-M6
	1-M4	CLIP'A',BELTLINE MOULD-----	2-M10	COVER,CASE-----	2-G3	DAMPER,GLOVE BOX-----	2-H15		2-N6
	3-C4	CLUTCH-----	1-N10	COVER,CENTER ADAPTER-----	3-G10	DAMPER,PULSATIION-----	1-L4	FASTENER,KEY CYL.-----	2-C10
	2-H5	CLUTCH & ONE WAY-----	1-N10	COVER,CLUTCH-----	1-C7	DAMPER,REAR-----	2-C4	FASTENER,LAMP-----	2-N10
CLAMP,SPARE TIRE-----	2-H5	CLUTCH,HIGH-----	1-L10	COVER,COLUMN-LOWER-----	2-C15	DASH POT-----	1-D5	FASTENER,REAR BUMPER-----	2-F10
CLAMP,WATER HOSE-----	1-K6	CLUTCH,MAGNET-----	3-E5	COVER,COLUMN-UPPER-----	2-C15	DIFFERENTIAL-----	2-K3	FASTENER,SEAL-TRIM-----	2-I10
CLIP-----	1-F7		3-N4	COVER,DAMPER STAY-----	3-I5	DISC,CLUTCH-----	1-C7	FASTENER,TRIM-SLIDE ROOF	3-D6
	1-F9		1-D11	COVER,DUST-----	1-C7	DISPLAY,SECURITY-ALARM-----	2-M15	FASTENER,TRK.S.TRIM-----	2-G10
	1-G9	CLUTCH,ONE WAY-----	1-D11		1-G3	DISTRIBUTOR,FUEL-----	1-K4	FEEER-ANTENNA-----	3-I7
	1-J4	CLUTCH,REAR-----	1-C11		1-N6	DOWEL,TUBULAR-----	1-D3	FELT-----	3-J7
	2-C8	CLUTCH,REVERSE-----	1-L10		2-E3	DRIVING & DIFF-----	2-J3	FILTER,AIR-----	1-J5
	2-C11	COCK,DRAIN-----	1-K6		2-I4	DRUM,HIGH CLUTCH-----	1-L10		1-K5
	2-D3	COIL,FIELD-MAGNET CLUTCH-	3-C5	COVER,F.FOG LAMP-----	2-J11	DRUM,REVERSE-----	1-L10	FILTER,FUEL-----	1-J4
	2-E10		3-E5	COVER,FRONT-----	1-H3	DUCT NO.1(R)-----	2-N15	FILTER,FUEL PUMP-----	2-K6
	2-F16	COIL,IGNITION-LEADING-----	1-E8	COVER,FRONT CLUTCH-----	1-C7	DUCT NO.2(L)-----	2-I15	FILTER,GOVERNOR-----	1-C10
	2-H4	COIL,IGNITION-TRAILING---	1-E8	COVER,FRONT-ALTERNATOR---	1-H8	DUCT NO.3(R)-----	2-N15	FINISHER,REAR-----	2-K11
	2-H12	COLLAR-----	1-E4	COVER,FUSE BLOCK-----	3-E8	DUCT(L),AIR-BRAKE PIPE---	2-I7	FLANGE,COMPANION-----	2-J3
	2-I11	COLLAR,CLUTCH REL-----	1-C7	COVER,GRILLE-----	2-F10	DUCT(L),LAP-----	2-N15	FLANGE,REAR AXLE-----	2-E3
	2-I12	COLLAR,COMP. BRKT-----	1-N6	COVER,HOLE-----	2-K15	DUCT(L),SHOWER-----	3-C4	FOAM(L),ENGV.ABS.-RR BUMP	2-H10
	2-J10	COLLAR,WEDGE-----	1-C7		2-M13	DUCT(L),SIDE DEMIST-----	2-N15	FOAM(R),ENGV.ABS.-RR BUMP	2-H10
	2-L15	COMPRESSOR-----	3-C5		3-E7	DUCT(L),VENTILATOR-----	2-N15	FORK,BRAKE-----	2-D7
	2-N7		3-D5		3-J6	DUCT(R),AIR-BRAKE PIPE---	2-I7		2-D7
	3-C3	COMPRESSOR,AIR CON.-----	3-N4	COVER,HOLE-(C)-----	2-I15	DUCT,AIR-----	3-C4	FORK,CLUTCH-----	2-D7
	3-D6		1-G8	COVER,HOLE-ANTENNA-----	2-N13	DUCT,AIR-INTER COOLER---	1-E4	FORK,CLUTCH RELEASE-----	1-D7
	3-E10	CONDENSER-----	3-H4	COVER,HOLE-BELT-----	3-F9	DUCT,CENTER-----	2-N15	FORK,SHIFT(1ST&2ND)-----	1-C8
	3-G3		3-I4	COVER,HOLE-DOOR BODY-----	3-I3	DUCT,FRESH AIR-----	1-M4	FORK,SHIFT(3RD&4TH)-----	1-C8
	3-H3		3-L4	COVER,HOLE-LIFT GATE-----	3-I3	DUCT,OIL COOLER-----	1-C9	FORK,SHIFT-5TH & REVERSE	1-D8
	3-H4		1-H4		3-C9		1-I6	FRAME(L),REAR SIDE-----	2-K13
	3-H5	CONNECTOR,HOSE-----	1-H4	COVER,HOLE-RR WIPER-----	3-C9	FRAME(L),SIDE-FRONT-----	2-N12	FRAME(L),SIDE-OUTER-----	2-G13
	3-H8	CONNECTOR,OIL COOLER-----	1-I6	COVER,INJECTOR-----	1-K4	FRAME(R),REAR SIDE-----	2-K13	FRAME(R),SIDE-FRONT-----	2-M12
	3-I3	CONNECTOR,SHORT-----	3-F7	COVER,LICENSE LAMP-----	2-D12	FRAME(R),SIDE-OUTER-----	2-E13	FRAME,CENTER-REAR SIDE---	2-K13
	3-I4	CONNECTOR,WATER HOSE-----	3-C4	COVER,LOWER PANEL-----	3-C6	FRAME,POWER PLANT-----	2-C6	FRAME,SLIDING ROOF-----	3-N5
	3-I8	CONSOLE,OVERHEAD-----	2-F12	COVER,MAIN FUSE BLOCK-----	3-C8	FRAME,SUB-----	2-F4		3-D8
	3-I9	CONSOLE,REAR-----	2-L15		3-L7	FUSE(120A)-----	3-D8		3-E8
	3-J5	CONTROL UNIT-----	3-H6	COVER,OIL PUMP-----	1-D9	FUSE(15A)-----	3-E8		3-L7
	3-J7	CONTROL,COOLANT FAN-----	3-M6	COVER,PEEPING HOLE-----	1-C7		3-L7		3-C8
	3-K4	CONTROL,HEATER-----	3-E4	COVER,REAR-----	2-K3	ELEMENT,AIR CLEANER-----	1-N4		3-E8
	3-N5	CONVERTER,CATALYST-----	2-D6	COVER,REAR-ALTERNATOR---	1-H8	END,CONTROL LEVER-----	1-G7		3-C8
	3-N8	CONVERTER,TORQUE-----	1-C9	COVER,RELAY BOX-F.HARNESSE	3-N7	END,S/ROD(1ST&2ND)-----	1-C8		3-E8
	3-G3	COOLER,OIL-----	1-E9	COVER,RELAY BOX-F.HARNESSE	3-N7	END,S/ROD(3RD&4TH)-----	1-C8		3-L7
CLIP (R)-----	3-G3		1-H6	COVER,REAR FINISHER-----	2-N11	END,SHIFT ROD(O/TOP&REV.)	1-C8		3-C8
CLIP KIT,ST. BEAR-----	2-J4	CORD-----	3-H7	COVER,SERVICE HOLE-----	2-N13	ENGINE,SHORT-----	1-C3	FUSE(40A)-----	3-C8
CLIP SET,DRIVE SHAFT-----	2-D3		3-M7	COVER,SOCKET-HEAD LAMP---	2-N18	EVAPORATOR-----	3-F5	FUSE(60A)-----	3-M7
CLIP,AIR BAG-----	2-K7		3-M7	COVER,SUN VISOR-----	3-G10		3-G5		
	3-C3	CORD SET,HI.TENSION-----	1-F8		2-C14				
CLIP,BELTLINE MOULD-----	2-M10	CORD,EARTH-----	3-I7						
CLIP,C.S.D. WIRE-----	2-D7	CORD,EARTH-RADIO-----	3-J7						
CLIP,COOLING UNIT-----	3-G5	CORD,HIGH TENSION-----	1-F8						
CLIP,DRAIN HOSE-REAR-----	3-D6	CORD,HIGH TENSION (L-1)---	1-F8						
CLIP,DRAIN HOSE-SUN ROOF-	3-D6	CORD,HIGH TENSION (L-2)---	1-F8						

ALPHABETICAL INDEX *** ENGLISH ***

KEY----- 1-C6
 LENS NO.3(L),RR COMB.LAMP 2-L17
 LENS NO.3(R),RR COMB.LAMP 2-C10
 LENS(L),FOG LAMP----- 2-C10
 LENS(L),FRT COMB.----- 2-C10
 LENS(L),RR COMB.----- 2-C10
 LENS(R),FRT COMB.----- 2-C10
 LENS(R),RR COMB.----- 2-C10
 LENS,COLUMN COVER----- 2-C10
 LENS,FRONT FOG LAMP----- 2-C10
 LENS,LICENCE LAMP----- 2-D10
 LENS,OVERHEAD CONSOLE----- 2-D10
 LENS,REAR FINISHER----- 1-K3
 LENS,WARNING----- 2-C10
 LEVER----- 1-J7
 LEVER SET,THROTTLE BODY----- 1-J7
 LEVER(L),OPERATING----- 1-J3
 LEVER(R),OPERATING----- 3-E4
 LEVER,CHANGE----- 2-F16
 LEVER,CONTROL----- 2-F16
 LEVER,OPENER----- 3-E7
 LEVER,PARKING BRAKE----- 3-E7
 LEVER,SELECT----- 1-D8
 LEVER,THROTTLE----- 2-E8
 LID(L),ARM REST-TRIM----- 1-C5
 LID(L),LAMP----- 1-C5
 LID(L),OUTER-STRAGE BOX----- 3-K3
 LID(L),TRUNK SIDE----- 2-D11
 LID(R),LAMP----- 3-L9
 LID(R),OUTER-STRAGE BOX----- 2-F16
 LID(R),TRUNK SIDE----- 2-F16
 LID,FUEL FILLER----- 2-M4
 LIGHTER,CIGAR----- 2-G16
 LINK SET,MODE----- 2-M4
 LINK SET,TEMP----- 2-M4
 LINK(L),FRONT STABILIZER----- *
 LINK(R),FRONT STABILIZER----- *
 LINK,CONNECTING----- *
 LINK,CONTROL----- *
 LINK,CONTROL-STAB----- *
 LINK,LOWER-FRONT----- *
 LINK,RECYCLE & FRESH----- *
 LINK,TOE CONTROL----- *
 LINK,WIPER----- *
 LOCK(L),DOOR----- *
 LOCK(R),DOOR----- *
 LOCK,BONNET----- *
 LOCK,GLOVE LID----- *
 LOCK,LIFT GATE----- *
 LOUVER(R),VENT.GRILLE----- *
 LOUVER,LAP-LOWER PANEL----- *

 * L *

 LABEL,ANTI THEFT-AUDIO----- 3-H10
 LABEL,BATTERY----- 3-I10
 LABEL,BURGLAR ALARM----- 3-H10
 LABEL,CAUTION----- 3-H10
 LABEL,EMISSION----- 3-I10
 LABEL,FUEL WARNING----- 3-H10
 LABEL,GASOLINE----- 3-I10
 LABEL,IG COIL----- 1-E8
 LABEL,OIL----- 3-H10
 LABEL,TEMPORARY TIRE----- 3-H10
 LABEL,TIRE----- 3-H10
 LABEL,UNLEADED FUEL----- 3-H10
 LABEL,VAC. DIAPHRAGM----- 3-I10
 LABEL,VEHICLE INFORMATION----- 3-H10
 LABEL'A',CAUTION-A/B----- 3-C3
 LAMP----- 3-H10
 LAMP SET(L),RR.COMB.----- 2-L11
 LAMP SET(R),RR.COMB.----- 2-L11
 LAMP(L),BACK UP----- 2-N11
 LAMP(L),F.FOG----- 2-I11
 LAMP(L),FRT.COMB.----- 2-G11
 LAMP(L),HEAD----- 2-N10
 LAMP(L),SIDE TURN----- 2-H11
 LAMP(L),SIDE TURN-RR----- 2-M11
 LAMP(R),BACK UP----- 2-M11
 LAMP(R),F.FOG----- 2-I11
 LAMP(R),FRT.COMB.----- 2-G11
 LAMP(R),HEAD----- 2-N10
 LAMP(R),SIDE TURN----- 2-H11
 LAMP(R),SIDE TURN-RR----- 2-M11
 LAMP,CARGO ROOM----- 2-E12
 LAMP,GLOVE BOX----- 2-G15
 LAMP,LICENCE----- 2-D12
 LENS & BODY(L)----- 2-E12
 LENS & BODY(L),BACK UP----- 2-H11
 LENS & BODY(L),F.COMB.----- 2-G11
 LENS & BODY(L),RR.COMB.----- 2-L11
 LENS & BODY(L),RR SIDE TU----- 2-N11
 LENS & BODY(R)----- 2-H11
 LENS & BODY(R),BACK UP----- 2-M11
 LENS & BODY(R),F.COMB.----- 2-G11
 LENS & BODY(R),RR.COMB.----- 2-L11
 LENS & BODY(R),RR SIDE TU----- 2-N11
 LENS & BODY,REAR FINISHER----- 2-K11
 LENS NO.2(L),RR.COMB.----- 2-M11
 LENS NO.2(R),RR.COMB.----- 2-M11

LENS NO.3(L),RR COMB.LAMP 2-L11
 LENS NO.3(R),RR COMB.LAMP 2-L11
 LENS(L),FOG LAMP----- 2-I11
 LENS(L),FRT COMB.----- 2-G11
 LENS(L),RR COMB.----- 2-L11
 LENS(R),FRT COMB.----- 2-G11
 LENS(R),RR COMB.----- 2-L11
 LENS,COLUMN COVER----- 2-C15
 LENS,FRONT FOG LAMP----- 2-I11
 LENS,LICENCE LAMP----- 2-D12
 LENS,OVERHEAD CONSOLE----- 2-F12
 LENS,REAR FINISHER----- 2-K11
 LENS,WARNING----- 2-F15
 LEVER----- 1-J8
 LEVER SET,THROTTLE BODY----- 1-L8
 LEVER(L),OPERATING----- 1-C5
 LEVER(R),OPERATING----- 2-H3
 LEVER,CHANGE----- 1-D8
 LEVER,CONTROL----- 1-G7
 LEVER,OPENER----- 2-C7
 LEVER,PARKING BRAKE----- 2-N7
 LEVER,SELECT----- 1-H11
 LEVER,THROTTLE----- 2-E8
 LID(L),ARM REST-TRIM----- 1-C5
 LID(L),LAMP----- 3-K3
 LID(L),OUTER-STRAGE BOX----- 3-L9
 LID(L),TRUNK SIDE----- 2-D11
 LID(R),LAMP----- 3-L9
 LID(R),OUTER-STRAGE BOX----- 2-C7
 LID(R),TRUNK SIDE----- 3-J6
 LID,FUEL FILLER----- 3-D4
 LIGHTER,CIGAR----- 3-D4
 LINK SET,MODE----- 3-D4
 LINK SET,TEMP----- 3-D4
 LINK(L),FRONT STABILIZER----- 2-F5
 LINK(R),FRONT STABILIZER----- 2-F5
 LINK,CONNECTING----- 1-J9
 LINK,CONTROL----- 2-C3
 LINK,CONTROL-STAB----- 2-D4
 LINK,LOWER-FRONT----- 2-F4
 LINK,RECYCLE & FRESH----- 2-D4
 LINK,TOE CONTROL----- 2-E4
 LINK,WIPER----- 3-K8
 LOCK(L),DOOR----- 2-E4
 LOCK(R),DOOR----- 2-E6
 LOCK,BONNET----- 2-F4
 LOCK,GLOVE LID----- 2-F5
 LOCK,LIFT GATE----- 2-G7
 LOUVER(R),VENT.GRILLE----- 2-M4
 LOUVER,LAP-LOWER PANEL----- 3-C3

 * M *

 MAGNET----- 1-F7
 MANIFOLD(R),EXTENSION----- 1-F7
 MANIFOLD,EXHAUST----- 1-R9
 MANIFOLD,INLET----- 1-C4
 MASCOT,FRONT----- 1-D4
 MASCOT,REAR----- 2-G12
 MAT,FLOOR----- 2-G12
 MAT,TRUNK ROOM----- 3-N9
 MEMBER NO.3,CROSS----- 3-N9
 MEMBER NO.4,CROSS----- 2-K13
 MEMBER NO.5,CROSS----- 2-K13
 MEMBER,CROSS PAD----- 2-G15
 MEMBER,CROSS----- 2-C13
 MEMBER,A',TUNNEL----- 2-F5
 MEMBER,B',TUNNEL----- 2-L12
 MEMBER,C',TUNNEL----- 2-C6
 METAL,ROTOR----- 2-C6
 METAL,STATIONARY GEAR----- 1-M3
 METER SET----- 2-E15
 METER,FUEL----- 2-F15
 METER,TEMP.-OIL----- 2-F15

MIRROR(L),DOOR----- 3-E10
 MIRROR(R),DOOR----- 3-E10
 MIRROR,INTERIOR----- 3-F10
 MODULE,AIR BAG----- 3-C3
 MODULE,AIR BAG PASSENGER----- 3-C3
 MODULE,POWERTRAIN CONTROL----- 3-I6
 MODULE,PWT.CONTROL----- 3-I6
 MOTOR----- 3-N8
 MOTOR(L),RETRACTABLE HEAD----- 2-D11
 MOTOR(R),RETRACTABLE HEAD----- 2-D11
 MOTOR,FAN-BLOWER UNIT----- 3-F4
 MOTOR,SLIDING ROOF----- 3-C6
 MOTOR,WIPER----- 3-K8
 MOULD(L),BELTLINE----- 2-M10
 MOULD(L),DRIP----- 2-M10
 MOULD(R),BELTLINE----- 2-M10
 MOULD(R),DRIP----- 2-M10
 MOULD(UP),FRT.WINDOW----- 2-L19
 MOULD,RR.WINDOW----- 2-L10

 * N *

 NOZZLE(L),SIDE-DEMISTER----- 2-G15
 NOZZLE(L),WASHER----- 3-J8
 NOZZLE(R),SIDE-DEMISTER----- 2-G15
 NOZZLE(R),WASHER----- 3-I8
 NOZZLE,DEFROSTER----- 3-M15
 NOZZLE,WASHER----- 2-J10
 NUT----- 1-C4
 NUT----- 1-C5
 NUT----- 1-D10
 NUT----- 1-Q4
 NUT,PROTECTOR-HARNES----- 1-15
 NUT,REAR SEAT----- 1-J9
 NUT,ROOF----- 2-C3
 NUT,ROOF----- 2-C3
 PAN,FLOOR-CENTER----- 2-C5
 PAN,FLOOR-FRONT----- 2-C6
 PAN,FLOOR-REAR----- 2-D4
 PAN,OIL----- 2-D5
 PAN,OIL----- 2-E3
 PANEL(L),COWL SIDE----- 2-E4
 PANEL(L),FENDER-FRT----- 2-E6
 PANEL(L),FENDER-REAR----- 2-F4
 PANEL(L),FLOOR SIDE----- 2-F5
 PANEL(L),OUT.-FRT DOOR----- 2-G7
 PANEL(L),REAR PILLAR----- 2-M4
 PANEL(L),RECESS----- 3-C3
 PANEL(L),SHROUD-SIDE----- 3-K4
 PANEL(L),SIDE SEAL----- 3-N8
 PANEL(L),SIDE-CRASH PAD----- 1-H8
 PANEL(L),SWITCH----- 3-B6
 PANEL(L),WHEEL APRON----- 2-F19
 PANEL(L),WHEEL HOUSE----- 2-H10
 PANEL(L),WHEEL HOUSE----- 2-K7
 PANEL(R),COWL SIDE----- 2-M12
 PANEL(R),FENDER-FRT----- 2-E13
 PANEL(R),FENDER-REAR----- 2-M12
 PANEL(R),FLOOR SIDE----- 2-H13
 PANEL(R),FLOOR SIDE----- 2-F13
 PANEL(R),OUT.-FRT DOOR----- 3-D3
 PANEL(R),REAR PILLAR----- 2-E13
 PANEL(R),RECESS----- 3-J3
 PANEL(R),SHROUD-SIDE----- 2-M12
 PANEL(R),SIDE SEAL----- 2-K13
 PANEL(R),SIDE-CRASH PAD----- 2-J15
 PANEL(R),WHEEL APRON----- 2-M12
 PANEL,R,CENTER----- 3-E4
 PANEL,CONSOLE----- 2-K15
 PANEL,COWL----- 2-D13
 PANEL,DASH-LOWER----- 2-D13
 PANEL,DASH-UPPER----- 2-D13
 PANEL,LOWER----- 2-I15
 PANEL,REAR END----- 2-F13
 PANEL,ROOF----- 2-I13
 PANEL,ROOF----- 2-J13
 PANEL,SLIDING ROOF----- 3-N5
 PANEL,SWITCH----- 2-L15
 PARTS KIT,INN.-BRAKE----- 2-H7
 PARTS KIT,INN.-CLUTCH----- 2-H6

NUT,WIPER LINK----- 3-K8

 * O *

 OIL,COMPRESSOR----- 3-D5
 ORNAMENT,CAR NAME-REAR----- 2-G12
 ORNAMENT,MAKER NAME-REAR----- 2-G12
 ORNAMENT,STEREO----- 3-E7

 * P *

 PAD----- 2-I15
 PAD NO.1,GARNISH-UPPER----- 2-M6
 PAD NO.2,GARNISH-UPPER----- 3-I3
 PAD SET,FRT CALIPER----- 2-H15
 PAD SET,RR CALIPER----- 2-N4
 PAD(L),CUSHION-FRT----- 2-G3
 PAD(L),TIRE HOUSE----- 2-J16
 PAD(R),CUSHION-FRT----- 3-M9
 PAD(R),TIRE HOUSE----- 2-H16
 PAD,CRASH BOOT----- 4-M9
 PAD,CHANGE----- 2-L15
 PAD,CRASH----- 2-G15
 PAD,FUEL TANK----- 2-L6
 PAD,FUEL TANK----- 2-M6
 PAD,FUEL TANK----- 2-N6
 PAD,PEDAL----- 2-F7
 PAD,PROTECTOR-HARNES----- 3-M7
 PAD,REAR SEAT----- 3-M9
 PAD,ROOF----- 3-F9
 PAN,FLOOR-CENTER----- 2-K13
 PAN,FLOOR-FRONT----- 2-K13
 PAN,FLOOR-REAR----- 2-K13
 PAN,OIL----- 1-H3
 PAN,OIL----- 1-L9
 PANEL(L),COWL SIDE----- 2-G13
 PANEL(L),FENDER-FRT----- 2-M12
 PANEL(L),FENDER-REAR----- 2-H13
 PANEL(L),FLOOR SIDE----- 2-H13
 PANEL(L),OUT.-FRT DOOR----- 3-D3
 PANEL(L),REAR PILLAR----- 2-G13
 PANEL(L),RECESS----- 3-J3
 PANEL(L),SHROUD-SIDE----- 2-N12
 PANEL(L),SIDE SEAL----- 2-L13
 PANEL(L),SIDE-CRASH PAD----- 2-J15
 PANEL(L),SWITCH----- 3-J3
 PANEL(L),WHEEL APRON----- 2-M12
 PANEL(L),WHEEL HOUSE----- 2-N12
 PANEL(L),WHEEL HOUSE----- 2-G13
 PANEL(R),COWL SIDE----- 2-E13
 PANEL(R),FENDER-FRT----- 2-M12
 PANEL(R),FENDER-REAR----- 2-H13
 PANEL(R),FLOOR SIDE----- 2-F13
 PANEL(R),FLOOR SIDE----- 3-D3
 PANEL(R),OUT.-FRT DOOR----- 2-E13
 PANEL(R),REAR PILLAR----- 3-J3
 PANEL(R),RECESS----- 2-M12
 PANEL(R),SHROUD-SIDE----- 2-K13
 PANEL(R),SIDE SEAL----- 2-J15
 PANEL(R),SIDE-CRASH PAD----- 2-M12
 PANEL(R),WHEEL APRON----- 2-M12
 PANEL,R,CENTER----- 3-E4
 PANEL,CONSOLE----- 2-K15
 PANEL,COWL----- 2-D13
 PANEL,DASH-LOWER----- 2-D13
 PANEL,DASH-UPPER----- 2-D13
 PANEL,LOWER----- 2-I15
 PANEL,REAR END----- 2-F13
 PANEL,ROOF----- 2-I13
 PANEL,ROOF----- 2-J13
 PANEL,SLIDING ROOF----- 3-N5
 PANEL,SWITCH----- 2-L15
 PARTS KIT,INN.-BRAKE----- 2-H7
 PARTS KIT,INN.-CLUTCH----- 2-H6

PARTS KIT,INNER----- 2-H6
 PARTS SET----- 3-E9
 PARTS SET,ST. WHEEL----- 3-M8
 PARTS SET,ST. WHEEL----- 2-H4
 PASS,OIL----- 1-H7
 PAWL,PARKING----- 1-H11
 PEDAL,ACCEL----- 2-J6
 PEDAL,BRAKE----- 2-D7
 PEDAL,BRAKE----- 2-F7
 PEDAL,CLUTCH----- 2-D7
 PELLET,THERMO-ECCENTRIC----- 1-J3
 PIECE,DISTANCE----- 2-K3
 PIECE,SIDE----- 1-M3
 PIECE,2ND-APEX SEAL----- 1-M3
 PILLAR(L),FRT.-INNER----- 2-H13
 PILLAR(L),HINGE----- 2-G13
 PILLAR(R),FRT.-INNER----- 2-F13
 PILLAR(R),HINGE----- 2-E13
 PILLAR'C'(L),REAR-INNER----- 2-G13
 PILLAR'C'(R),REAR-INNER----- 2-E13
 PIN----- 1-H11
 PIN----- 1-K9
 PIN----- 2-D7
 PIN,CHECKER----- 3-G3
 PIN,DOWEL----- 1-G3
 PIN,DRIVEN GEAR----- 1-D6
 PIN,GUIDE----- 2-I3
 PIN,GUIDE-F.SIDE TRIM----- 3-I9
 PIN,INTER LOCK----- 1-C8
 PIN,LOCATOR----- 3-L3
 PIN,LOCK----- 2-H3
 PIN,LOCK----- 2-H3
 PIN,PAD-FRONT BRAKE----- 2-D7
 PIN,SNAP----- 2-D7
 PIN,SNAP----- 2-E8
 PIN,SNAP----- 2-F7
 PIN,SNAP----- 2-N6
 PIN,SPRING----- 1-D3
 PIN,STOPPER----- 1-D3
 PIN,TUBULAR----- 1-G3
 PINTON----- 1-K8
 PIPE----- 1-N4
 PIPE----- 2-J10
 PIPE NO.1,BRAKE-A.B.----- 2-I7
 PIPE NG.1,COOLER----- 3-H4
 PIPE NG.1,COOLER----- 3-K4
 PIPE NO.2,BRAKE-A.B.----- 2-I7
 PIPE NO.2,COOLER----- 3-H4
 PIPE NO.2,COOLER----- 3-K4
 PIPE NO.3,BRAKE-A.B.----- 2-L7
 PIPE NO.3,COOLER----- 3-H4
 PIPE NO.3,COOLER----- 3-K4
 PIPE NO.4,BRAKE-A.B.----- 2-L7
 PIPE NO.4,COOLER----- 3-H4
 PIPE NO.5,COOLER----- 3-H4
 PIPE NO.5,COOLER----- 3-K4
 PIPE(L),BRAKE REAR----- 2-I7
 PIPE(L),BRAKE-FRONT----- 2-J7
 PIPE(R),BRAKE-FRONT----- 2-J7
 PIPE(R),BRAKE-REAR----- 2-I7
 PIPE,AIR----- 1-E5
 PIPE,AIR----- 1-H4
 PIPE,AIR----- 2-D6
 PIPE,AIR INTAKE----- 1-E4
 PIPE,AIR INTAKE----- 1-H4
 PIPE,AIR INTAKE----- 1-I5
 PIPE,AIR INTAKE-INT.COOLE----- 1-H4
 PIPE,AIR-B.A.C.V.8A.I.H.----- 1-I5
 PIPE,AIR-VALVE ACTUATOR----- 1-M5
 PIPE,BRAKE-FRT----- 2-I7
 PIPE,BRAKE-FRT----- 2-J7
 PIPE,BRAKE-REAR----- 2-J7
 PIPE,BRAKE-REAR----- 2-K7
 PIPE,CLUTCH----- 2-I6
 PIPE,COOLER-HIGH----- 3-K4
 PIPE,COOLING UNIT----- 3-F5
 PIPE,COOLING UNIT----- 3-G5
 PIPE,RAIN-ANTENNA----- 3-H7
 PIPE,EVAPORATION----- 2-C8
 PIPE,EVAPORATOR----- 2-D8
 PIPE,FILLER----- 2-K6
 PIPE,FILLER NO.2----- 2-L6
 PIPE,FUEL----- 2-M6
 PIPE,FUEL-MAIN----- 2-C8
 PIPE,FUEL-RETURN----- 2-C8
 PIPE,H/L CLEANER----- 2-J10

ALPHABETICAL INDEX *** ENGLISH ***

PIPE, HEATER-----	3-C4	PLATE, DRIVEN-REV. PISTON--	1-C11	PROTECTOR(R), FENDER-----	2-D11	REINF. (R), REAR PILLAR IN.	2-E13	RING, SEAL-----	1-G11
PIPE, HEATER UNIT-----	3-D4	PLATE, EARTH-MOTOR ANTENNA	3-H7	PROTECTOR(R), RETRA H/L-----	2-D11	REINF. (R), ROOF RAIL-----	2-F13	RING, SNAP-----	1-C6
PIPE, INNER-----	2-K6	PLATE, GUARD-CALIPER BRAKE	2-G3	PROTECTOR(R), RR. COMB-----	2-L11	REINF. (R), SIDE SILL-----	2-F13		1-C11
PIPE, JOINT-----	1-L6	PLATE, HOLDER-BRUSH-----	3-E9	PROTECTOR, CONVERTER-----	2-F6	REINF. (R), SUSPENSION HSG-----	2-E13		1-F11
PIPE, GIL-----	1-E9		3-M8	PROTECTOR, COVER-----	2-N11	REINF. (R), WHL. APRON-----	2-M12		1-17
	1-F9	PLATE, LOCK-----	3-L9	PROTECTOR, COWL GRILLE-----	2-H12	REINF. (R), ROOF-----	2-I13		1-K7
	1-G4	PLATE, LOCKING-----	3-G6	PROTECTOR, DOOR SWITCH-----	3-C7	REINFORCEMENT, BUMPER-----	2-E10		1-K10
PIPE, OIL FILLER-----	1-E3	PLATE, LOGO-STRUT BAR-----	2-C13	PROTECTOR, FENDER GRILLE-----	2-I12	RELAY-----	2-H10		1-M7
PIPE, OIL LEVEL GAUGE-----	1-D3	PLATE, MANUAL-----	1-H11	PROTECTOR, FILLER HOSE-----	2-L6		3-F4		1-M10
PIPE, OIL OUTLET-F. COVER-----	1-G4	PLATE, MIDDLE-----	1-C6	PROTECTOR, FUEL TANK-----	2-M6	RELAY & BRACKET, NORMAL OP	2-J10		3-C5
PIPE, OIL-OILPUMP-----	1-E9	PLATE, RETAINING-----	1-C11	PROTECTOR, HARNESS-----	3-H7	RELAY, FUEL PUMP-----	3-H6	RING, SNAP-MAGNET CLUTCH--	3-C5
PIPE, PRESSURE-----	2-K4		1-G11	PROTECTOR, HOSE-SUB TANK-----	1-L6	RELAY, MAIN-----	3-H6		3-E5
PIPE, REAR WASHER-UPPER-----	3-N8		1-I10	PROTECTOR, HO. PLATE-----	2-F10	RELAY, MOTOR-HYD. UNIT-----	3-L7	RING, SNAP-PISTON STEM LOW	1-F11
PIPE, RELIEF-----	1-M4		1-M10	PROTECTOR, PIPE-----	2-D8	RELAY, N. O.-----	3-L4		1-K9
PIPE, RETURN-----	2-K4		1-N10	PROTECTOR, SPORGE-----	1-F4		3-M6		1-M9
	2-L4		2-D11		1-J5		3-M6		1-K9
PIPE, SCREEN WASHER-----	3-L8	PLATE, RETRACTABLE-----	3-G6	PROTECTOR, VACUUM PIPE-----	1-L5		3-M6	RING, SNAP-PISTON STEM UP-	2-H3
PIPE, VACUUM-----	1-M5	PLATE, SENSOR-----	3-G6	PROTECTOR, VACUUM TUBE-----	1-J4		3-N6	RING, SNAP-RR CALIPER-----	1-D3
	2-H7	PLATE, SEPARATOR-----	1-C10	PROTECTOR 'A' (L), BELTLINE	2-M10		3-N5	RING, SQUARE-----	1-D3
	2-D9	PLATE, STABILIZER-----	2-F5	PROTECTOR 'A' (R), BELTLINE	2-M10	RELAY, SLIDE ROOF-----	3-M6	RING, SQUARE-OUTER-----	1-D3
PIPE, VINYL-----	3-18	PLATE, STABILIZER-RR-----	2-D4	PROTR. MOULD-FRT WINDOW-----	2-L10	RELAY, TRANSFER-----	3-N6	RING, STOP-----	1-D5
PIPE, WASHER-FRONT WIPER-----	1-F4	PLATE, THRUST-----	1-K3	PULLEY-----	1-H8	RELAY, VALVE-HYD. UNIT-----	2-L7	RING, SYNCHRONIZER-----	1-J7
PIPE, WATER-----	1-F4	PLATE, WINDOW-----	2-F15	PULLEY, CRANKSHAFT-----	1-J3	RESISTOR-----	3-E4		1-M7
PIPE, WATER IN T/C-----	1-F4	PLATE 'E', SIDE-----	1-H10	PULLEY, IDLE-----	1-N6	RESISTOR, BLOWER UNIT-----	3-F4	RING, THRUST WASHER-----	1-M7
PISTON, ACCUMULATOR-----	1-I10	PLAYER, COMPACT DISC-----	3-E7	PULLEY, MAGNET CLUTCH-----	3-C5	RESISTOR, INTERLOCK-----	3-M6	RING, WIRE-----	1-C7
	1-M9	PLUG-----	1-H7		3-E5	REST, FOOT-----	2-D7	RING 'O'-----	2-M7
PISTON, BAND SERVO-----	1-J9		1-H10	PULLEY, VANE PUMP-----	2-L4		2-D7	RIVET-----	2-D12
PISTON, CALIPER-FRT-----	2-N4		1-I3	PULLEY, WATER PUMP-----	1-J6		2-F7		2-E11
PISTON, CLUTCH-----	1-L10		1-I9	PUMP KIT-----	2-K10	RET, ACCUM-----	1-M9	RIVET, BLIND-----	3-G6
PISTON, FLOATING-----	2-H7		2-N13	PUMP, AIR-----	1-E5	RETAINER-----	1-C11	RIVET, MUD GUARD-----	2-E10
PISTON, HIGH CLUTCH-----	1-M10	PLUG SET, SPARK-----	1-F8	PUMP, FUEL-----	2-K6		1-E9	RIVET, SEAL PLATE-SHROUD--	2-C13
PISTON, LOW & REVERSE-----	1-F11	PLUG, BLIND-----	1-G3	PUMP, FUEL-SUB-----	2-K6	RETAINER, CHAMBER-EXTRACTO	2-I12	ROD, PARKING-----	1-H11
PISTON, O. W. VALVE-----	2-G6	PLUG, CAP-----	1-C8	PUMP, METERING OIL-----	1-D6	RETAINER, FASCIA-----	2-E10	ROD, PUSH-----	2-D7
PISTON, PRIMARY-----	2-H7	PLUG, COMPRESSOR-----	3-D5	PUMP, OIL-----	1-C6	RETAINER, LOCK CYL-----	3-H3		2-G6
PISTON, REVERSE-----	1-M10		3-N4		1-D9	RETAINER, SERVO-----	1-J9	ROD, RETRACTABLE-----	2-D11
PIVOT, ROLLER-----	1-E9	PLUG, CORNER SEAL-----	1-M3	PUMP, VANE-----	2-L4	RETAINER, SPRING-----	1-M9	ROD, SELECTOR-REAR-----	2-E8
PLATE-----	1-D11	PLUG, DRAIN-----	1-H3	PUMP, WASHER-----	2-J10	RETAINER, SPRING-CLU. ONE W	1-F11	ROD, SHIFT (1ST&2ND)-----	1-C8
	1-I10		2-K6		2-K10	RETAINER, SPRING-CLU. ONE W	1-C11	ROD, SHIFT (3RD&4TH)-----	1-C8
	1-K3		2-M13		3-C9	RETAINER, SPRING-PSTN STEM	1-K9	ROD, SHIFT-OVER TOP & REVE	1-C8
	2-F7		2-N12	PUMP, WATER-----	3-J8	RING-----	1-K6	ROTOR-----	1-C6
PLATE NO. 1(L), SET-F.-----	2-F10		3-G3		1-I6	RING SET-KEY CYLINDER-----	2-C15		1-18
PLATE NO. 1, PRINT-----	2-E15		3-N8		1-J6	RING SET, 'O'-----	1-C3		1-N3
PLATE NO. 1, SET-F. BUMPER-	2-F10	PLUG, DRAIN-LIFT GATE UP.-	2-N13			RING, 'O'-----	1-C5	ROTOR, SENSOR-RR A. B. S.---	2-E3
PLATE NO. 2(L), SET-F. BUMPE	2-F10	PLUG, HOLE-----	2-M13				1-C5		2-M4
PLATE NO. 2(R), SET-F. BUMPE	2-F10	PLUG, HOLE-F. SIDE FRAME---	2-M13				1-D3	RUBBER(C), CUSHION-BONNET--	2-J12
PLATE NO. 3(L), SET-F. BUMPE	2-F10	PLUG, HOLE-FLAP-----	2-M13				1-D6	RUBBER(L), ENGINE MT-----	2-C6
PLATE NO. 3(R), SET-F. BUMPE	2-F10	PLUG, JET-----	1-D3				1-E10	RUBBER(L), SEAL-SIDE PANEL	2-J15
PLATE NO. 4(L), SET-F. BUMPE	2-F10	PLUG, MAGNET-----	1-F7				1-F3	RUBBER(R), ENGINE MT-----	2-C6
PLATE NO. 4(R), SET-F. BUMPE	2-F10		2-J5				1-F9	RUBBER(R), SEAL-SIDE PANEL	2-J15
PLATE SET, SEAT BELT-----	2-M16		1-F7	RACE, BEARING-----	1-D11		1-G3	RUBBER, BLADE-FRONT-----	3-K8
PLATE(L), CLOSING-QTR PANE	2-H13	PLUG, MAGNET DRAIN-----	1-F7		1-E11		1-G7		3-N8
PLATE(L), CLOSING-R. FENDER	2-L13	PLUG, OIL JET-----	1-J5		1-E11		1-H5	RUBBER, CUSHION-BONNET FRT	2-J12
PLATE(L), CORNER-----	2-H13	PLUG, OUTER HANDLE-----	3-G3		1-F11		1-H5		2-K12
PLATE(L), FRONT SCUFF-----	3-I9	PLUG, OUTER HANDLE-----	3-G3	RACE, INNER-----	1-F11		1-J9	RUBBER, HANGER-----	3-E6
PLATE(L), GUIDE-----	3-D6	PLUG, REGULATOR-----	1-C10		1-J7		1-K4	RUBBER, INSULATOR-----	3-I4
PLATE(L), POSITION-S. ROOF	3-C6	PLUG, SERVICE COVER-----	2-N13	RACE, OUTER-----	1-D11		1-K9		3-L4
PLATE(L), STRUT BAR-----	2-F13	PLUG, SPARK-----	1-E8	RACK, STEERING GEAR-----	2-J4		1-L3	RUBBER, MOUNT-----	1-K6
PLATE(R), CLOSING-QTR PANE	2-F13		1-F8	RADIATOR-----	1-K6		1-L9	RUBBER, MOUNT -DIFF. CASING	2-F4
PLATE(R), CLOSING-R. FENDER	2-L13	PLUG, SQUARE HEAD-----	1-G10	RAIL(L), GUIDE-----	3-N5		2-L4	RUBBER, MOUNT-HYD. UNIT---	2-L7
PLATE(R), CORNER-----	2-F13	PLUG, STOPPER-----	1-H10	RAIL(L), RAIN-----	2-H13		3-D4	RUBBER, MOUNTING-----	1-C9
PLATE(R), FRONT SCUFF-----	3-I9		2-M13	RAIL(L), ROOF-INNER-----	2-G13		3-G6		1-H4
PLATE(R), GUIDE-----	3-D6	PLUG 'A', BLIND-S. SPOILER--	2-M13	RAIL(R), GUIDE-----	3-N5	RING, 'O'-ACCUM. CLUTCH---	1-L9		1-H6
PLATE(R), POSITION-S. ROOF	3-C6	PLUG 'B', BLIND-S. SPOILER--	2-M13	RAIL(R), RAIN-----	2-F13	RING, 'O'-ACCUM. FOR CLUT	1-M9		2-C5
PLATE(R), STRUT BAR-----	2-C13	PLUNGER, CONTROL-----	1-C6	RAIL(R), ROOF-INNER-----	2-E13	RING, 'O'-FUEL PUMP-----	2-K6		2-F4
PLATE, ABSORBER-----	1-F4		1-H3	RECTIFIER-----	1-H8	RING, 'O'-INJECTOR-----	1-K4		2-F5
PLATE, BACKING-----	1-C9	POCKET(L), QTR. TRIM-----	3-J10	REFRIGERANT DRUM-----	3-I4	RING, 'O'-INLET MANIFOLD---	1-H4		2-J4
PLATE, BAFFLE-----	1-I9	POCKET(R), QTR. TRIM-----	3-J10	REGULATOR(L), WINDOW-----	3-H3	RING, 'O'-INNER-----	1-M3		2-N3
	2-K3	POLE, ANTENNA-----	3-I7	REGULATOR(R), WINDOW-----	3-H3	RING, 'O'-MASTER CYL-----	2-H7	RUBBER, REAR-ET/ED COMBI.-	3-E7
	2-D5	PRESSURE RG., FUEL-----	1-L4	REGULATOR, PRESSURE-----	1-C6	RING, 'O'-NO. 1-----	3-M4	RUBBER, SEAL-----	1-H7
	2-F4	PROTECTOR-----	1-J4	REGULATOR, VOLTAGE-----	1-H8	RING, 'O'-NO. 3-----	3-G5		3-L7
PLATE, CAUTION-----	3-I10		2-C8	REINF. (L), BELT LINE-C.PIL	2-F13	RING, 'O'-OIL LEVEL SENSOR	3-G6	RUBBER, SEAL-FRESH AIR DUC	1-M4
PLATE, CLAMP-----	2-J4	PROTECTOR(L), COWL GRILLE--	2-H10	REINF. (L), COWL SIDE-----	2-G13	RING, 'O'-OUTER-----	1-M3	RUBBER, SEAL-RR LOWER ARM-	2-E4
PLATE, CRANKSHAFT PULLEY---	1-J3	PROTECTOR(L), DRIP MLDG-----	2-M10	REINF. (L), F. PILLAR INNER	2-E13	RING, 'O'-PRESSURE REGU.---	1-L4	RUBBER, SEAL-SIDE PANEL---	2-J15
PLATE, DISC-----	2-E3	PROTECTOR(L), FENDER-----	2-D11	REINF. (L), FLOOR SIDE-----	2-G13	RING, 'O'-TENSION BOLT-----	1-G3	RUBBER, STAB-FRT-----	2-F5
	2-M4	PROTECTOR(L), RETRA. H/L-----	2-D11	REINF. (L), HINGE-----	2-G13	RING, 'O'-UP. ACCUM 2ND PIS	1-L9	RUBBER, STOPPER-----	3-H3
PLATE, DISHED-----	1-L10	PROTECTOR(L), RR. COMB-----	2-M11	REINF. (L), REAR PILLAR IN.	2-G13	RING, 'O'-WATER THERMO SW.	3-G6		
PLATE, DRAIN PLUG-UNDER C.	1-G7	PROTECTOR(R), COWL GRILLE--	2-H12	REINF. (L), ROOF RAIL-----	2-H13	RING, BACKUP-----	1-D3		
PLATE, DRIVE-----	1-C9	PROTECTOR(R), DRIP MLDG-----	2-M10	REINF. (L), SIDE SILL-----	2-H13	RING, ILLUMINATION-----	3-J6		
	1-D11	PROTECTOR(R), FENDER-----	2-D11	REINF. (L), SUSPENSION HSG-	2-G13	RING, RETAINING-----	1-C8		
	1-M10	PROTECTOR(R), RETRA. H/L-----	2-D11	REINF. (R), WHL. APRON-----	2-H12		1-L7		
PLATE, DRIVEN-----	1-F11	PROTECTOR(R), RR. COMB-----	2-M11	REINF. (R), BELT LINE-C.PIL	2-F13		2-E3		
	1-G11	PROTECTOR(R), COWL SIDE-----	2-M11	REINF. (R), COWL SIDE-----	2-E13	RING, RETAINING-BALL BEARI	1-K7		
	1-L10	PROTECTOR(R), COWL GRILLE--	2-H12	REINF. (R), F. PILLAR INNER	2-E13	RING, SEAL-----	1-D9	SCREEN(L), FRONT DOOR-----	3-I3
	1-N10	PROTECTOR(R), DRIP MLDG-----	2-M10	REINF. (R), HINGE-----	2-E13		1-E9	SCREEN(R), FRONT DOOR-----	3-H3
PLATE, DRIVEN-FRONT-----	1-D11								

CAT. AUFA05-03

E-005

3-F12

ALPHABETICAL INDEX *** ENGLISH ***

*****		WASHER, SPEAKER-----	3-M7
* V *		WASHER, SPRING-----	2-G3
* * *		WASHER, STOP-----	2-I4
*****		WASHER, THRUST-----	1-D9
			1-G11
			1-J7
			1-K3
			1-K7
			1-M7
VACUUM POWER ASSIST-----	2-G7	WASHER, THRUST LOCK-OVER T	1-M7
VALVE-----	1-G10	WASHER, THRUST-REVERSE IDL	1-L7
VALVE, ACCUMULATOR-----	1-C10	WASHER, TOOTHED-----	3-M8
VALVE, AIR-----	2-G5	WASHER, TRUST-----	1-K10
VALVE, AIR BYPASS-----	1-I4	WASHER, WAVE-CHANGE CONT.C	1-D8
	1-N4	WAX, THERMO-----	1-C5
VALVE, AIR CONTROL-----	1-E5	WEATHERSTRIP(L), DOOR-----	3-F3
VALVE, CHECK-----	1-E5	WEATHERSTRIP(L), DOOR-LOW.	3-E3
	1-J5	WEATHERSTRIP(L), INN.-----	3-J3
	2-D6	WEATHERSTRIP(R), DOOR-----	3-F3
	2-M6	WEATHERSTRIP(R), DOOR-LOW.	3-E3
	3-I8	WEATHERSTRIP(R), INN.-----	3-J3
VALVE, CONTROL-----	1-C10	WEATHERSTRIP, BONNET-REAR-	2-K12
	1-I4	WEATHERSTRIP, S/ROOF-----	3-D6
VALVE, CONVR RELIEF-----	1-G10	WEDGE, LIFTGATE-----	3-I5
VALVE, DUTY SOLENOID-----	1-C4	WEIGHT, BALANCE-----	1-K3
VALVE, E. G. R.-----	1-K5	WEIGHT, COUNTER-----	1-K3
VALVE, EXPANSION-----	3-F5	WEIGHT, DISC WHEEL-ALUMI--	2-G5
	3-G5		2-H5
VALVE, EXTRACT CHAMBER----	2-I12	WELT(L), SEAMING-----	3-F3
VALVE, FUEL VAPOR-----	2-M6	WELT(R), SEAMING-----	3-F3
VALVE, IDLE AIR CONTROL----	1-M5	WELT, SEAMING-----	3-N5
VALVE, LOCK UP CONTROL-----	1-H10	WHEEL, DISC-ALUMI.-----	2-H5
VALVE, MANUAL-----	1-C10	WHEEL, FLY-----	1-J3
VALVE, MODIFIER-----	1-C10	WHEEL, SPROCKET-----	1-C6
VALVE, NON RETURN-----	2-L6	WIRE-----	2-H5
VALVE, ORIFICE CHECK-----	1-C10	WIRE, A. C. C.-----	3-D7
VALVE, P. B.-----	2-M7	WIRE, EARTH-----	3-D8
VALVE, P. C. V.-----	1-J5	WIRE, EARTH-FILLER PIPE----	2-L6
VALVE, RELIEF-----	3-D5	WIRE, EARTH-HYD. UNIT-----	2-M7
	3-N4	WIRE, EARTH-REAR DEFFOGGER-	3-L7
VALVE, SHIFT-----	1-F10	WIRE, RELEASE-----	2-G16
	1-G10	WIRE, RELEASE-BONNET-----	2-J12
VALVE, SOL.-AIR BLEED EXTE	1-I5	WIRING, ENGINE-----	3-C8
VALVE, SOLENOID-----	1-E5	WIRING, FLOOR-----	3-8B
	1-F5	WRENCH, HUB NUT-----	3-D10
	1-J5	WTHSTP, LIFT GATE-----	3-I5
VALVE, SOLENOID-A. C. VALVE	1-E5	WTHSTP(L), GLASS-F. DOOR---	3-F3
VALVE, SPOOL-----	1-H10	WTHSTP(R), GLASS-F. DOOR--	3-E3
VALVE, ST. GEAR-----	2-K4		
VALVE, 3RD LOCK UP-----	1-H10	*****	
VALVE, 3WAY-----	1-I5	* Y *	
		* * *	
*****		*****	
* W *		YOKE-----	1-J8
* * *			1-L8
*****		YOKE SET, SUPPORT-ST. GEAR	2-J4
WALL(L), SIDE-----	2-K15		
WALL(R), SIDE-----	2-K15		
WARNING, HEAT-----	2-K15		
WASHER-----	1-D10		
	2-D11		
	2-E8		
	2-F6		
	2-G16		
	2-J3		
	2-J4		
	3-C5		
	3-E5		
	3-M8		
WASHER SET-----	1-J8		
	1-L8		
WASHER, HYD. UNIT-----	2-L7		
WASHER, LOCK-PUMP FILTER--	2-K6		
WASHER, PLAIN-----	1-F11		
	1-J9		
	1-L9		
	2-E3		
WASHER, PLAIN-LOWER ARM---	2-M6		
WASHER, PLAIN-REAR BRAKE--	2-E3		
WASHER, SEAL-----	1-H3		
WASHER, SETTING-----	3-D3		
WASHER, SLEEVE-REAR BRAKE-	2-C5		
	2-E3		
	2-E4		

MODEL IDENTIFICATION

This parts catalog has been compiled to cover the following models.

(1/1)

Model No.	Specifications of vehicles																			VIN (Chassis No.)						
	Basic spec.	Engine	Turbo	T/mission	Speed		Body	Roof			Suspension		Diff.	Brake	Airbag	Production period		Model year	U.S.A.			Guam & Saipan				
	U.S.A.	RE 13B	Turbo	Manual Transmission	Automatic Transmission	4 speed	5 speed	Coupe	W/O sun roof	Steel sun roof	Glass sun roof	Normal suspension	Hard suspension	Limited slip diff.	Antilock brake system	Air bag	From	To	1994		Production for U.S.A.	Grade	Production for Guam & Saipan	Grade	Grade	
	(US)	(13)	(TR)	(MT)	(AT)	(4S)	(5S)	(CP)	(W/O SR)	(ST)	(GS)	(NS)	(HS)	(LS)	(AL)	(AB)					Yes	(BS)	(R2)	(TR)	(BS)	(R2)
FD15	US	13	TR	MT		5S	CP	W/O SR			NS	LS	AL	AB	Aug '93	Jul '94	→	→	Yes	BS		Yes	BS		FD333+ - 300001-310000	
FD16	US	13	TR	MT		5S	CP	W/O SR			HS	LS	AL	AB	Aug '93	Jul '94	→	→	Yes		R2	Yes		R2	FD333+ - 300001-310000	
FD17	US	13	TR		AT	4S	CP	W/O SR			NS	LS	AL	AB	Aug '93	Jul '94	→	→	Yes	BS		Yes	BS		FD333+ - 300001-310000	
FD18	US	13	TR	MT		5S	CP			GS	NS	LS	AL	AB	Aug '93	Jul '94	→	→	Yes			TR	Yes		TR	FD333+ - 300001-310000
FD19	US	13	TR		AT	4S	CP			GS	NS	LS	AL	AB	Aug '93	Jul '94	→	→	Yes			TR	Yes		FD333+ - 300001-310000	
FD30	US	13	TR	MT		5S	CP		ST		NS	LS	AL	AB	Aug '93	Jul '94	→	→	Yes	BS		Yes	BS		FD333+ - 300001-310000	

AUFA05

BODY PAINTS AND INTERIOR COLORS

THIS LIST SHOWS COMBINATION OF BODY PAINT AND INTERIOR COLOR. USING THIS LIST YOU WILL BE ABLE TO FIND OUT NECESSARY COLOR CODE OF PART YOU NEED IN THE TEXT.

BODY PAINT		INTERIOR COLOR CODE		
NAME	CODE			
Brilliant black	PZ	F E 5	F E 6	F E 7
Vintage red	NU	F E 5	F E 6	
Silver stone metallic	3L	F E 5		F E 7
Montego blue metallic	M8	F E 5	F E 6	
Chaste white	PT	F E 5	F E 6	F E 7

NOTE:
COLORS OF INTERIOR CODES
ARE AS FOLLOWS.

FE5	Black
FE6	Tan
FE7	Red

AUFA05

COMPLETE ASSEMBLY PARTS NUMBERS

Engine

Specifications of vehicles		Parts number
T/mission	Suspension	
Manual T/mission	Normal suspension	N3C5 - 02 - 000
	Hard suspension	N3C1 - 02 - 000
Automatic T/mission	※	N3C2 - 02 - 000

T/mission

(1/1)

Specifications of vehicles	Parts number
T/mission	
Manual T/mission	R564 - 03 - 000
Automatic T/mission	BV65 - 19 - 090H

Cabin


Specifications of vehicles		Parts number
Roof	Suspension	
W/O sunroof	Normal suspension	FD15 - 07 - 000
	Hard suspension	FD16 - 07 - 000
Steel sunroof	※	FD30 - 07 - 000
Glass sunroof		FD18 - 07 - 000

The ※ mark in the above chart does not affect on part number selection.
Complete assemblies are available and manufactured in accordance with current production specifications only.

AUFA05

VEHICLE IDENTIFICATION SYSTEM FOR RX-7 SERIES (1994)

VIN (= Vehicle Identification Number) for RX-7series (1994 - Year Model) consists of WMI(= World Manufacturer Identifier), VDS(= Vehicle Description Section) and VIS(= Vehicle Identification Section). VDS consisting of six alphanumeric characters denotes the "MODEL SERIES". VIS consisting of eight alphanumeric characters denotes the serial unit number of vehicle and is sequentially numbered within each VDS.




* Check digit is included as a VIN security feature to permit law enforcement verification of the authenticity of a suspected illegal VIN plate. This single digit number is determined, based upon a complex mathematical formula which is applied to each vehicle's VIN number.

** Miscellaneous Identification Code identifies major components such as engine, brake system, cab type, etc.

LOCATION OF VIN PLATE

The plate is attached to the top ledge of the dash panel under the bonnet(engine hood), refer to the illustration shown right.



[Note]

If the VIN(Chassis) reference number in the PCM(Parts Catalog Microfiche) appeared as:

FD333 * - 300001

...the vehicle's VIN would be e.g. JM1FD333*R0300001.

ABBREVIATIONS

The following abbreviations are used throughout Mazda Microfiche parts catalog: in the illustration, text, section number index, alphabetical index.

Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition
1ST	First	B.S.V.	Bleed Solenoid Valve	DIFF.	Differential	H	Head	L/EM	Less Emission Controls	..P	Panel
2ND	Second	BTHR	Breather	DISC/B	Disc Brake	HARN.	Harness	L.H.D.	Left Hand Drive	(P)	Primary
2D.	2-Door	BUMP.	Bumper	DIST	Distributor	H.A.C.	High. Altitude Compensator	L.H. SIDE	Left Hand Side	PARK or PARKG	Parking
2-SEAT	2-Seater	BURG.	Burglar	DMPR	Dumper	H.A.COMPENSATOR	High. Altitude Compensator	LKOUT	Lock-out	PASS.	Passenger
3D.	3-Door	BY.A.C.V.	Bypass Air Control Valve	DOHC	Double Overhead Camshaft	HB	Hatchback	L. NOSE	Long Nose	P.B.	Proportioning Brake
3PD	Third	[C]	Center	D.P.	Dual Proportioning	H.B. RE	Hatchback Release	L/NVGT. CPU	Less Navigation computer	P.C.V.	Positive Crankcase Ventilation
3-SP	3-Speed	C. or (C)	Center	DRUM/B	Drum Brake	HC-A/T	Hydro Control Automatic T/Mission	L.O.	Low	PHLPPNS	Philippines
4D.	4-Door	CALIF.	California	D/TIRE or D.TIRE	Double Tire	H/DUTY	Heavy Duty	L.S. VALVE	Load Sensing Valve	PILR.	Pillar
4-SP or 4-SPD	4-Speed	C/AREA	Cold Area	D.T. TOP	Detachable Top	HEA. or HEAT.	Heater	L/PARTITION	Less Partition	PV	Pivot
4S-SP	4-Speed/5-Speed	CAN.	Canada	DUMP.	Dump Truck	H/L	High -	L.P.G.	L.P. Gas (-Liquefied Petroleum Gas)	PKG.	Package
4TH	Fourth	CARB.	Carburetor	DX.	Deluxe	H/LT	High Altitude	L.S.D. or L.S. DIFF	Less Slip Differential	PNEUMA.	Pneumatic
5D.	5-Door	CAT	Catalyst	D. YLW	Dark Yellow	H/LTI	Head Injury Criteria	..L.T.	..Liter(s) Tank	PNL	Panel
5-LINK	5-Link Suspension	C.DISC	Compact Disc	[E]	Economic Commission for Europe	HIGHT	High-Tension	L/TAILGATE	Less Tailgate	PNT	Point
5-SP or 5-SPD	5-Speed	CE	Conventional Engine	ECE	Economic Commission for Europe	H/L or H.L. or H/LAMP	Head Lamp	LVR	Lever	POS.	Position
10TH-ANNIV.	10th-Anniversary	C.G.R.	Constant Gear Ratio	ECON.	Economy	H.KONG	Hong Kong	LWR	Lower	POSIT.	Positive
[A]	..Ampere	CH	Coach	E.C.P.S. SYS	Electric Control Power Steering System	HNGR	Hanger	LX-P	LX with Performance Package	POW. WINDOW	Power Window
A.A.S. or A.A.SUSP	Automatic Adjusting Suspension	CHG	Change	EGI	Electric Gasoline Injection	..HP	..Horsepower(s)	[M]	..Meter(s)	P.P.	Polypropylene (Plastics)
ABS	Absorber	CHMBR	Chamber	EGR.	Exhaust Gas Recirculation	H.P.R.	High Penetration	..M	..Miles	PRESS	Pressure
A.B.S.	Anti lock Brake System	CHK	Check	ELECT.	Electric	HSG	Housing	MA. CYL	Master Cylinder	PROTN	Protection
A.B.S.V.	Air Bleed Solenoid Valve	CLG.	Cooling	E.M.	Emission Controls	HT. N/T or H/TOP	Hardtop	MAINT.	Maintain or Maintenance	PROTR	Protector
A.C.	Air Conditioner	CLNR	Cleanse.	ENEGY or ENGY	Energy	H/W	Hawai	MAP	Manifold Absolute Pressure	PORTGL	Portugal
A.C.C.	Automatic Cruise Controls	CLTR	Cigarette Lighter	ENGL	Engine	[I]	..Inch	MA. SUSP	Multi-Adjustable Suspension	P.S.	Power Steering
ACCEL	Accelerator	CLU	Clutch	ENGY	Engine	ID.	Inner Diameter	MA. EAST	Middle East	P-SOUND	Premium Sound
ACTR	Actuator	C.MEMBER	Crossmember	ENQZ	Equalizer	IG or IGN.	Ignition	MAP	Multi-Adjustable Suspension	PTC	P - above Temperature Co-efficient
A.C.V.	Air Control Valve	CNTNR	Container	EQIP.	Equipment	ILUM.	Illumination	M/EAST	Middle East	P.T.O.	Po.ner Take Off
ADJ.	Adjuster or Adjustable or Adjusting	COMB.	Combination	EX.	Exhaust	ILUM.	Illumination	MFR	Maintenance Free	PU	Pickup
ADJ.SUSP	Adjustable Suspension	COMP.	Companion	EXC.	Except	IN.	Inlet	M/LD. or MLDG.	Moulding	P/W or P. WINDOW	Power Window
AIR P.	Air Pipe	COMPR	Compressor	EXC.10TH-ANNIV.	EXC.10th-Anniversary	IND.	Indicator	..MBS	..Miles	PWRGT LIFTR	Power Gate Lifter
AIR CON.	Air Conditioner	COMPS.	Compass	EXT.	Extension	INHIB.	Inhibitor	M.P.	..Miles	PWT.	Powertrain
ALTN	Alternator	CONDNSH	Condenser	EXTRACT.	Extractor	INH.	Injection	M.P.C.	Multi-point	[Q]	Quarter
ALUM.	Aluminum	CONN.	Connector or Connecting	[F]	Front-	INS.	Insulation	MPL	Multiple	QTY	Quantity
AMP.	Amplifier	CONTS.	Console	..F	..Foot	INSP.	Inspection	MRFN	Maroon	[R]	Final Gear Ratio
ANALOG	Analogue	CONT.	Control	FED.	Federal	INST.	Instrument	MT. & MTG.	Mounting	R	... R or (R)
ANNIV.	10th Anniversary	CONV.	Conventional	FINS	Finisher	INT.	Interior	MT	Manual Transmission	..R or (R)	... Right
ANT	Antenna	CONVR	Converter	F.I.P.	Fuel Injection Pump	INT.COOLER	Inter Cooler	[N]	Number of Teeth	RAD.	Radiator
ARG	Argent	COVR.	Cover	FLEX	Flexible	INTER	Intermittent	N-	Narrow	RE	Rotary Engine
A.S. ABSORBER	Adjust Shock Absorber	CPE	Coupe	F.I.MIXER	Fuel Injection Mixer	INTMT. or INTERMIT.	Intermittent	NARR.	Narrow	RECIPRO	Reciprocating Engine (-Conventional Engine)
ASH.	Ashtray	CPT.	Complete Assembly	FDX.	Folding	I.R.S. or I.R. SUSP	Independent Rear Suspension	N.C.	Normal Close	REFRIGER.	Refrigerator Van
ASSY	Assembly	CPU	Computer	F.LID	Filler Lid	I.S.C.	Idle Speed Control	N.O.	Normal Open	REG. or REGU.	Regular
AT	Automatic Transmission	C.P.UNIT	Central Processing Unit	F.LID	Filler Lid	IVRY	Ivory	NON-SP.	Non-Special Equipment	REG. GAS	Regular Gasoline
ATT	Attachment	CRK	Crank	F.L.DECK	Full Logic Deck	[K]	..Kilogram(s)	NON-TILT	Non-Tilting	REGUL.	Regulator
AUS	Austria	CRUST	Cruster	FOLD.	Folding	..KG	..Kilogram(s)	NOR.	Normal	REL.	Release
AUST.	Australia	C/SHIFT	Column Shift	FRA	France	..KM	..Kilometer(s)	NOZ.	Nozzle	REM. CON.	Remote Controlled
AUTO.	Automatic	CTR.	Center	FRT	Front	..KW	..Kilowatt(s)	N.S.W.	New South Wales (Aust.)	RET.	Return
[B]	Balance	CUSH.	Cushion	F/SHIFT	Fully Controlled	[L]	Left	NVGT. CPU	Navigation Computer	RETAIN.	Retaining
BAL.	Battery	CYL	Cylinder	FULL CON.	Fully Controlled	L or (L)	Length =	REV.	Reverse	RETRACT	Retractable
BAT	Body Color	D. or DR	Door	[G]	..Gram(s)	L =	..Liter(s)	R.H.D.	Right Hand Drive	REV.	Reverse
B.COLOR	Body Color	D=.	Double...	GARN	Garnish	..L	..Liter(s)	RICO	Pneumatic	R.H. SIDE	Right Hand Side
B/DOOR	Back Door	DBL CAB	Double Cab (-Crew Cab)	GAS.	Gasoline	..L.T.	..Liter(s) Tank	RENF.	Reinforcement	RL or RR.	Rear
BDY	Body	D. BLUE	Dark Blue	GASOH	Gasohol	L.	Less. (-Without.)	R.F.	Over Head	[S]	..Side
BELT.	Beltline	D. BRN	Dark Brown	GEN	General	L/A.A. SUSP	Less Automatic Adjusting Suspension	R.H. SIDE	Right Hand Side	..S.	..Secondary
BLK	Black	DE	Dark Green	G.NATCH	Glass Hatch	L/A.C.	Less Air Conditioner	REIN.	Reinforcement	(S)	Safety
BLU	Blue	DEF	Diesel Engine	G.L.D. M	Gold Metallic	L/BODY	Long Body	R.F.	Over Head	S. AFRICA	South Africa
BLU/GRY	Blue Metallic	DEFG	Defroster	GLS	Less	L/BOX	Long Box	RENF.	Reinforcement	S.AUDI	Saudi Arabia
BLU. M	Blue Metallic	DES	Design	GOV.	Governor	L/COMP	Luggage Compartment	R. or RR.	Rear	S/BODY	Short Body
BLVA	Bolivia	DEMS.T.	Demister	GRN	Green	L.C.DISPLAY	Liquid Crystal Display	[P]	Panel	S/BOX	Short Box
BRG.	Bearing	D. GRAY	Dark Gray	GRY	Gray	LEGI	Less Electric Gasoline Injection				
BRKT.	Bracket	DIAPH	Diaphragm	[H]	..Horsepower(s)						

Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition
SDN	Sedan	U. LONG	Ultra Long		
SDUTY	Standard Duty	UND	Under		
SELECT.	Selective Use	UP	Upper		
SEN.	Sensor	URETANE	Urethane Rubber		
SERV.	Service	U.S.	Undersize		
S.FORK	Shift Fork	[V]			
S.G., SGN or SIG.	Signal	.V	..Volt(s)		
SHFT	Shift	.V.	Valve		
SHRD	Shroud	VAC.	Vacuum		
SHTR	Shutter	V.CHAMBER	Vacuum Chamber		
SILV. M or SILVER M.	Silver Metallic	Vent.	Ventilator or Ventilation		
SING	Singapore	V.G.R.	Variable Gear Ratio		
SILEN	Silencer	VNL	Vinyl		
SLDG	Sliding	[W]			
SLN	Skoon	.W	..Watt(s)		
SML	Small	W. or WIND	Window		
S. NOSE	Short Nose	W-	Width-		
SOL	Solenoid	W/.	With. or Use with		
SP.	Speed	W/L S. VALVE	W/O Load Sensing		
SPEC.	Specification	VALVE	Valve		
SPEEDO.	Speedometer	W/O OIL CONSUMP.	W/O Oil Consumption		
SPG.	Spring	W/O P.T.O.	W/O Power Take-Off		
SPK.	Speaker	WARN.	Warning		
	(-Loud-speaker)	WAS.	Washer		
SPLR	Spoiler	W/AUTO BELT	With Automatic		
ST.	Steering		Shoulder Belt		
STAB.	Stabilizer	W/CHASSIS	Windshield Chassis		
STD.	Standard	WAT	Water		
S/TIRE or S. TIRE	Single Tire	WGN	Wagon		
STYL	Styled	WHL	Wheel		
SUB-TRNS	Sub-transmission	WHT	White		
SUN SHLD	Sun Shield	WIND.	Window		
SURGT.	Surge Tank	WIP.	Wiper		
SUP. GAS	Super Gasoline	W/O AUTO BELT	Without Automatic		
SUSP	Suspension		Shoulder Belt		
S.V.	Solenoid Valve	W/O.	Without.		
SW.	Switch	WOOF.	Woofer		
S. WASHER	Screen Washer	W. PUMP	Water Pump		
	(Windshield Washer)	WSHLD or WNDSHLD	Windshield		
SWD.	Sweden	WSTR or WT:STP	Weatherstrip		
SYNC.	Synchronizer	W/T	With Tube (Tire)		
[T]		[Y]			
.T	..Ton(s)	YLW	Yellow		
T..	Thick - see..	YLW/GRN	Yellowish Green		
TACH. & TACHOM.	Tachometer	YLW/WHT	Yellowish White		
T.ADJUST	Time Adjusting	[Z]			
TACHOZ TACHOM.	Tachometer	Z.TEMP	Zone Tempered		
T.BELT	Timing Belt				
T/CEILING	Top Ceiling				
TEMP.	Temperature				
T/F	Transfer				
TH.	Throttle				
THAI	Thailand				
THERM.	Thermostat				
THROT.	Throttle				
T/L	Tubeless				
T/MISSION	Transmission				
TRD CLMT	Torrid Climates				
TRK	Truck				
TRO. GLIDE	Torque Glide				
T. TOBAGO	Trinidad and Tobago				
TURB.	Turbocharge				
TWIN	Twin				
[U]					
U.K.	The United Kingdom				