

### PART NUMBER INDEX

This index is listed in the following sequence.

### GENERAL PARTS

EXAMPLE

- ① Model/Type  
Third, in the sequence of model/type (1st-4th digits)
- ② Group  
First, in the sequence of group (5th & 6th digits)
- ③ Part  
Second, in the sequence of part (7th-9th digits)

### INDEX DES NOMBRES DE PIÈCES

Cet index a été composé selon la séquence suivante.

### PIÈCES GÉNÉRALES

EXEMPLE

- ① Modèle/type  
Troisièmement, séquence du modèle/type (1er à 4ème chiffres)
- ② Groupe  
Premièrement, séquence du groupe (5ème et 6ème chiffres)
- ③ Pièce  
Deuxièmement, séquence de la pièce (7ème à 9ème chiffres)

### NUMERO INDICE DE PIEZA

Este índice se ordena en la siguiente secuencia.

### PIEZAS GENERALES

EJEMPLO

- ① Tipo de modelo  
Tercero, en la secuencia de tipo de modelo (entre las cifras 1ro-4to lugar)
- ② Grupo  
Primero, en la secuencia de grupo (las cifras en 5to y 6to lugar)
- ③ Pieza  
Segundo, en la secuencia de pieza (entre las cifras 7mo-9no lugar)

### TEILENUMMERN

Die Teilenummern setzen sich wie folgt zusammen.

### ALLGEMEINE TEILE

BEISPIEL

- ① Modell/Typ  
Angabe des Modells bzw. Type (1. bis 4. Ziffern)
- ② Baugruppe  
Angabe der Baugruppe (5. und 6. Ziffer)
- ③ Teil  
Angabe des Teils (7. bis 9. Ziffer)

①            ②            ③  
┌───┬───┬───┐  
B A 0 1    6 0    3 5 0

### STANDARD PARTS

Standard Parts are listed in numerical sequence after General Parts.  
(Note: Those parts which do not have D-Code are not listed in the index.)

### PIÈCES STANDARD

Les pièces standard sont énumérées selon une séquence numérique, après les pièces générales.  
(Remarque: Les pièces qui ne possèdent pas de code D ne sont pas mentionnées dans cet index.)

### PIEZAS NORMALES

Las piezas normales se numeran secuencialmente después de las Piezas generales.  
(Note: Las piezas que no tienen un código D no están en el índice.)

### STANDARDTEILE

Die Standardteile sind nach den allgemeinen Teilen mit fortlaufender Numerierung aufgeführt.  
(Hinweis: Teile ohne D-Code sind nicht aufgeführt.)

PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

*****	NSA1-10-400A	1-H3	*****	NSA2-13-247	1-34	1480-13-730	1-E5	NSA1-14-260	1-F4	NSA1-15-183	1-J6
*****	NE03-10-604	1-H3	*****	NSA3-13-247	1-L4	NF01-13-735	1-E5	NSA1-14-270A	1-F4	NSA1-15-184A	1-J6
* C2-000	NSA1-10-416	3-H6	* 13-000	NSA1-13-249	1-L4	*****	1-E4	NSA1-14-273A	1-F3	NSA1-15-185	1-K6
*****	8542-10-417	1-E3	*****	NSA1-13-250	1-J4	NSA1-13-735	2-L4	0839-14-274	1-F3	NSA1-15-185A	1-K6
*****	NSA1-10-620B	1-E3	*****	NSA2-13-250	1-J4	NSA4-13-75X	1-L4	NSA1-14-280A	1-F4	NSA1-15-186	1-K6
*****	NSA1-10-424	1-E3	*****	N326-13-253A	1-T9	NSA3-13-750A	1-L4	NSA2-14-290A	1-F4	NSA1-15-200A	1-K6
NSA1-02-200	NSA1-10-424A	1-E3	NS350-13-896	8574-13-253	1-J4	NSA4-13-752	1-L4	NSA2-14-290A	1-F4	NSA2-15-200A	1-K6
NSA2-02-200	NS3VA-10-427	1-H3	NSA2-13-C60	NF01-13-257A	1-K4	NSA3-13-752A	1-E5	NSA1-14-295	1-F4	NSA2-15-211B	1-K6
*****	NS318-10-441	1-D3	NSA2-13-C61	NSA1-13-257	1-K4	NSA4-13-752	1-L4	NSA2-14-295	1-F4	NSA2-15-211B	1-K6
*****	NSA1-10-430A	1-E3	NSA1-13-C80A	NSA1-13-280	1-K4	NSA3-13-752	1-E5	B6Y1-14-302	1-D6	NSA2-15-211B	1-K6
*****	0839-10-455	1-H3	NSA2-13-C80C	N253-13-282	1-K4	NSA4-13-754A	1-E5	NSA1-14-310A	1-D6	NSA2-15-211B	1-K6
*****	NSA1-10-470	3-H6	NSA1-13-C87A	NSA1-13-300A	1-T9	NSA1-13-760	1-J5	NSA2-14-600	1-D6	NSA2-15-211B	1-K6
* 09-000	NSA1-10-481	1-E3	NSA1-13-M6X	F201-13-302A	1-L4	NSA1-13-761A	1-J5	NSA2-14-602	1-D6	NSA2-15-211B	1-K6
*****	NSA1-10-498	1-H3	NSA2-13-M6X	NSA1-13-320	1-L4	NSA1-13-765	1-H4	N236-14-603B	1-D6	NSA2-15-211B	1-K6
*****	NSA1-10-500	1-E3	NSA1-13-M6X	F251-13-329	1-D4	NSA1-13-766	1-H4	NSA1-14-604	1-H6	NSA2-15-211B	1-K6
*****	NSA1-10-502	1-L3	NSA2-13-M6X	NSA1-13-329	1-D4	NSA1-13-767	1-H4	NSA2-14-604	1-D6	NSA2-15-211B	1-K6
*****	NSA1-10-507	1-H3	NSA1-13-M6X	NSA1-13-33X	1-D4	NSA2-13-768	1-H4	NSA2-14-604	1-D6	NSA2-15-211B	1-K6
FD01-09-010C02	NSA1-10-507	1-H3	NSA2-13-M6X	NSA1-13-330	1-L5	NSA1-13-785	1-L4	NSA2-14-604	1-D6	NSA2-15-211B	1-K6
FD01-09-010D	0813-10-555A	1-F3	NSA1-13-M64	NSA1-13-352	2-L6	NSA3-13-786	1-M4	NSA1-14-622	1-H6	NSA2-15-211B	1-K6
FD01-09-010D02	1668-10-556A	1-F3	NSA1-13-M68	NSA1-13-352	2-L6	NSA3-13-786	1-M4	0813-14-623	1-D6	NSA2-15-211B	1-K6
FD02-09-010C02	NSA1-10-560A	1-H3	NS390-13-350	NS390-13-350	2-L6	NSA3-13-810	1-E5	0820-14-625A	1-D6	NSA2-15-211B	1-K6
FD02-09-010D	NSA1-10-560B	1-H3	NS390-13-M69	NS390-13-M69	1-C5	NSA4-13-810	1-E5	NS318-14-631	1-D6	NSA2-15-211B	1-K6
FD02-09-010D02	NSA1-10-566	1-H3	NSA1-13-W7X	NSA1-13-W7X	1-C5	NSA1-13-812	1-E5	NS326-14-633	1-D3	NSA2-15-211B	1-K6
*****	8871-10-631A	1-H3	NSA1-13-W70	NSA1-13-W70	1-C5	F51-13-563	1-D4	NSA1-14-660	1-D6	NSA2-15-211B	1-K6
*****	*****	*****	NSA1-13-W76	NSA1-13-W76	1-C5	NF01-13-563	1-D4	NSA1-14-667	1-H6	NSA2-15-211B	1-K6
* 10-000	*****	*****	NSA1-13-W8Y	NSA1-13-W8Y	1-C5	NS318-13-563	1-D4	NSA1-14-668	1-H6	NSA2-15-211B	1-K6
*****	*****	*****	NSA1-13-W80	NSA1-13-W80	1-C5	0222-13-563	1-H6	NSA1-14-670	1-D6	NSA2-15-211B	1-K6
*****	*****	*****	NSA1-13-W86	NSA1-13-W86	1-C5	NF01-13-564	1-C9	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
*****	*****	*****	NSA1-13-W87	NSA1-13-W87	1-C5	NS318-13-563	1-D4	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
*****	*****	*****	NSA1-13-W89	NSA1-13-W89	1-C5	NF01-13-564	1-H6	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS326-10-806	NS3YA-11-810	1-M3	FE17-13-ZE1	FE17-13-ZE1	2-L6	NF01-13-564	1-H6	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-810	NSA1-11-811	1-L3	FEH2-13-ZE4	FEH2-13-ZE4	2-L6	NF01-13-566	1-N3	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-850	NSA2-11-811	1-L3	PEP2-13-ZE5	PEP2-13-ZE5	2-L6	NSA1-13-580	1-E4	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS326-10-871A	NSA3-11-811	1-L3	JE48-13-ZG1	JE48-13-ZG1	1-J4	NSA1-13-585A	1-E4	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS326-10-872	NSA3-11-811	1-L3	NS390-13-ZG1	NS390-13-ZG1	1-L4	NSA1-13-588A	1-E4	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-873	NS51-11-C00	1-L3	NF01-13-ZG3	NF01-13-ZG3	1-J4	NSA3-13-885	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-C00B	NS326-11-C02A	1-L3	NSA1-13-ZG3	NSA1-13-ZG3	1-J4	NSA3-13-885A	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-C00C	NS326-11-C03A	1-L3	NF01-13-ZG4	NF01-13-ZG4	1-J4	NSA1-13-887	1-F4	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-C06	NS326-11-C04A	1-L3	NSA3-13-ZG7	NSA3-13-ZG7	1-J4	NSA2-13-887A	1-J5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-C08	NS326-11-C06A	1-L3	NSA4-13-ZG7	NSA4-13-ZG7	1-J4	NSA3-13-887	1-J5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS326-10-C15	NSY1-11-C11	1-M3	NSA1-13-ZLY	NSA1-13-ZLY	1-E4	NSA4-13-887	1-M4	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS3YA-10-C50B	NF01-11-C17	1-L3	NSA2-13-421	NSA2-13-421	2-F8	NSA3-13-888	1-M4	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS3YA-10-C50C	NS326-11-C20A	1-L3	NS326-13-428A	NS326-13-428A	1-L4	NSA4-13-888	1-M4	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS3YB-10-C50B	NS326-11-C22A	1-L3	NS326-13-447	NS326-13-447	2-F8	NSA1-13-889A	2-F8	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS3YB-10-C50C	NF01-11-C24	1-L3	NSA1-13-447	NSA1-13-447	1-C4	NSA3-13-889	1-M4	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS350-10-C85	NSA1-11-D00	1-J3	NSA3-13-447	NSA3-13-447	1-N3	NSA1-13-890	1-J5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-C86	NSA2-11-D00	1-J3	NS390-13-453A	NS390-13-453A	1-E4	NSA3-13-890	1-J5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-D00	NS326-11-D03	1-J3	NS391-13-456	NS391-13-456	1-C4	NSA3-13-890	1-J5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-D10	NS326-11-D11	1-J3	E5B6-13-461B	E5B6-13-461B	1-E4	NSA1-13-891	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS3YA-10-E00	NS326-11-D15	1-J3	NSA1-13-461	NSA1-13-461	1-C4	NSA1-13-891	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E04	NS326-11-D17	1-J3	NSA1-13-468A	NSA1-13-468A	1-C4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E05	NF01-11-D51	1-J3	NSA1-13-111	NSA1-13-111	1-C3	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E06	NF01-11-D51	1-J3	8AF7-13-111	8AF7-13-111	1-C3	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E07	NS390-11-D52	1-K3	NSA1-13-112	NSA1-13-112	1-N3	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E08	NF01-11-D53	1-K3	NSA1-13-150	NSA1-13-150	1-J4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E09	NF01-11-D54	1-K3	NSA2-13-150	NSA2-13-150	1-J4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS3YA-10-E10	NF01-11-D54	1-K3	86B1-13-157	86B1-13-157	1-I4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS3YA-10-E10A	NF01-11-D55	1-K3	8574-13-157	8574-13-157	1-I4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E22	NF01-11-D56	1-K3	NS326-13-158	NS326-13-158	2-F8	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E23	NF01-11-D57	1-K3	NSA1-13-162	NSA1-13-162	1-G4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E24	NF01-11-D58	1-K3	NS350-13-164	NS350-13-164	1-C4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS3YA-10-E25	NF01-11-D59	1-K3	NSA3-13-170	NSA3-13-170	1-G4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NF01-10-E26	NSA7-11-D61	1-K3	NSA1-13-200	NSA1-13-200	1-N3	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS350-10-E50A	NSA8-11-D61	1-K3	NS326-13-200	NS326-13-200	1-L4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS350-10-E51B	NS326-11-D75	1-K3	NSA1-13-203	NSA1-13-203	1-L4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS350-10-E56	0820-11-341	1-L3	NSA1-13-220	NSA1-13-220	1-L4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS350-10-E61A	8341-11-343	1-L3	NSA1-13-221A	NSA1-13-221A	1-L4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NSA1-10-S60	N225-11-351	1-M3	NSA1-13-23XB	NSA1-13-23XB	1-N3	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
NS326-10-T11	1011-11-353A	1-M3	NSA1-13-230	NSA1-13-230	1-G4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
1757-10-111	N225-11-361	1-M3	NSA1-13-231	NSA1-13-231	1-G4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
N231-10-174	1011-11-363A	1-M3	NSA1-13-232	NSA1-13-232	1-G4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
0839-10-203	NSA1-11-400A	1-J3	NSA1-13-24X	NSA1-13-24X	1-G4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
8562-10-205	1881-11-404	1-J3	NSA1-13-240A	NSA1-13-240A	1-G4	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
1757-10-207A	NS390-11-406	1-J3	1480-13-240A	1480-13-240A	1-T5	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
N249-10-219	0839-11-412	1-J3	1481-13-240A	1481-13-240A	1-T5	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6
4767-10-244	NS318-11-500	1-J3	1482-13-240A	1482-13-240A	1-T5	NSA1-13-892	1-E5	NSA1-14-670	1-H6	NSA2-15-211B	1-K6

PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

R507-17-221	1-J7	0221-17-441A	1-D8	PN16-18-W27	1-I8	8BF1-18-140A	1-G8	BV65-19-090G	1-E9	BV11-19-400	1-L9	BV45-19-561	1-E11
0317-17-225	1-J7	1011-17-443	1-G7	NSA1-18-W35	1-J8	JF03-18-141A	3-K8	BV65-19-100	1-E9	BV11-19-405	1-L9	BV45-19-561A	1-E11
R527-17-230	1-J7		1-J9	NS36-18-W36	1-I8	NSA1-18-180A	1-G8	BV11-19-201	1-E9	BV11-19-406	1-L9	BV11-19-567	1-E11
R523-17-240	1-J7	R514-17-450	1-G7	NSA1-18-W45	1-I8	NSA1-18-190A	1-G8	BV11-19-202	1-E9	BV11-19-429	3-J6	BV46-19-570	1-E11
F401-17-243A	1-J7	R514-17-450A	1-G7	NSA1-18-W50	1-I8	NSA1-18-211	3-H6	BV11-19-203	1-E9	BV11-19-431	1-J11	BV45-19-571	1-E11
R535-17-250	1-K7	R504-17-455	1-G7	NSA1-18-W51	1-I8	NSA1-18-221	3-H6	BV11-19-204	1-E9	BV11-19-434	1-J11	BV11-19-572	1-C11
R503-17-26Y	1-K7	R522-17-461	1-G7	NSA1-18-W60	1-I8	NSA1-18-222	3-H6	BV11-19-205	1-E9	BV11-19-437	1-L9	BV11-19-572A	1-D11
F504-17-26Y	1-K7	R522-17-461A	1-G7	JE48-18-W70	1-I8	NSA1-18-251	1-G8	BV11-19-206	1-E9	BV65-19-437	1-L9	BV11-19-573	1-D11
R523-17-260	1-K7	Q398-17-462A	1-E8	B3C7-18-W77	1-I8	NSA1-18-300A	1-I8	BV11-19-207	1-E9	BV65-19-440	1-J11	BV11-19-573A	1-D11
W501-17-263A	1-K7	R504-17-470	1-E8	NSA1-18-W80	1-J8	NSA1-18-360B	1-G8	BV65-19-210	1-E9	BV65-19-443	1-J11	BV45-19-580	1-E11
G401-17-264	1-K7	R504-17-470A	1-E8	NF01-18-X00A	1-L8	NSA1-18-381	1-G8	BT40-19-216	1-E9	BV65-19-444	3-J6	BV11-19-587	1-E11
R501-17-264	1-K7	M501-17-474	1-G7	NSA1-18-X00	1-L8	NSA2-18-381	1-H8	BV56-19-220	1-E9	BV65-19-444A	3-J6	BV11-19-590	1-E11
M502-17-265C	1-K7	Q303-17-474	1-E8	E356-18-X01	1-M8	NSA1-18-397	1-H8	BV60-19-221	1-E9	BV11-19-450	1-J11	BV11-19-593	1-E11
R503-17-265B	1-K7	R503-17-475	1-H7	F210-18-X01	1-M8	NF01-18-400B	1-L8	BV65-19-221	1-E9	BV11-19-451	1-M10	BV11-19-595	1-E11
R514-17-265B	1-K7	R513-17-476	1-H7	NF01-18-X05	1-M8	NSA1-18-400	1-L8	BV56-19-240	1-E9	BV11-19-453	1-M10	BV11-19-603	1-E11
R507-17-268	1-K7	M513-17-480A	1-E8	NS326-18-X05	1-M8	JE15-18-51X	3-T6	BV11-19-241	1-E9	BV11-19-454	1-C11	BV11-19-603	1-E11
R513-17-270A	1-K7	R503-17-481	1-E8	G401-18-X06	1-N8	KL01-18-51X	3-T6	BV11-19-242	1-E9	BV11-19-454A	1-D11	BV11-19-603	1-E11
0884-17-274	1-K7	G5A0-17-482B	1-H7	NF01-18-X10	1-N8	AM15-18-520A	1-C9	BV11-19-247	1-E9	BV11-19-456	1-C11	BV11-19-604	1-F11
0884-17-275B	1-K7	M505-17-482	1-E8	NSA1-18-X10	1-N8	E364-18-520B	1-C9	BV11-19-255	1-F9	BV11-19-456A	1-D11	BV11-19-605	1-F11
3648-17-275A	1-K7	R507-17-495	1-H7	NF01-18-X20	1-M8	N251-18-520B	1-C9	BV50-19-255	1-D10	BV11-19-457	1-C11	BV11-19-606	1-F11
0839-17-276	1-K7			NS18-18-X20	1-L8			BV11-19-256	1-F9	BV11-19-457A	1-D11	BV11-19-607	1-F11
0839-17-277	1-L7	R507-17-510A	1-E8	NS327-18-X20	1-M8	FE50-18-522	1-C9	BV11-19-257	1-F9	BV11-19-458	1-C11	BV46-19-6F1	1-F11
0839-17-278	1-L7	R503-17-515	1-E8	NS18-18-X25	1-N8	NSA1-18-591D	1-C9	BV11-19-381	1-L10	BV11-19-458A	1-D11	BV65-19-6M6	1-G11
R505-17-281	1-L7	R503-17-520A00	1-E8	NS26-18-X30	1-L8	NSA1-18-591E	1-C9	BV41-19-382	1-G11	BV11-19-459	1-C11	BV45-19-601	1-G11
R502-17-283	1-L7	R501-17-523	1-H7	NF01-18-X35	1-M8	NSA1-18-593B	1-C9	BV45-19-384	1-L10	BV11-19-459A	1-D11	BV65-19-601	1-G11
0839-17-287	1-L7	M501-17-530A	1-H7	NF01-18-X40	1-M8	NSA2-18-593A	1-C9	BV11-19-385A	1-L10	BV11-19-475	1-L9	BV11-19-603	1-F11
0839-17-288	1-L7	0884-17-530	1-O9	NS26-18-X40	1-M8	NSA1-18-701	3-L6	BV11-19-386	1-L10	BV11-19-476	1-L9		1-H11
R501-17-295	1-L7	R505-17-540	1-H7	NF01-18-X50	1-M8	F285-18-741	1-J5	BV11-19-387	1-J9	BV11-19-480	1-M10	BV11-19-605	1-F11
R501-17-299	1-L7	R507-17-540	1-H7	F225-18-X56	1-L8	NSA1-18-741	1-F5	BV11-19-387	1-J9	BV11-19-484	1-M10	BV35-19-605	1-F11
R525-17-301	1-L7	M501-17-543A	1-H7	NF01-18-X56	1-L8	NSA7-18-741	1-J5	BV11-19-387	1-J9	BV11-19-497	1-M10	BV45-19-609	1-H11
R504-17-302A	1-L7	R505-17-543	1-H7	NS26-18-X57	1-N8	NS90-18-741	1-J5	BV11-19-388	1-J9	BV11-19-498	1-M10	BV56-19-610	1-H11
0821-17-303	1-L7	R503-17-550	1-H7	F214-18-X60A	1-L8	NSA1-18-744	1-K5	BV65-19-380	1-M10	BV45-19-499	1-M10	BV11-19-613	1-H11
R501-17-304	1-L7	R502-17-551	1-H7	NF01-18-X60A	1-L8	JE16-18-811	3-L6	BV11-19-383	1-K9	BV11-19-580	1-M10	BV45-19-613	1-H11
0839-17-305B	1-L7	R501-17-552	1-E8	NS26-18-X62A	1-L8	NF01-18-821	3-H6	BV11-19-384	1-J9	BV11-19-580A	1-M10	BV65-19-613	1-H11
R502-17-306A	1-L7	R501-17-555	1-H7	NF01-18-X65	1-L8	NF02-18-821A	3-L6	BV11-19-384	1-K9	BV11-19-581	1-M10	BV66-19-613	1-H11
0727-17-306	1-L7	R526-17-570	1-H7	NS26-18-X65	1-L8	NSA1-18-831	3-L6	BV11-19-385	1-F11	BV65-19-5D0	1-M10	BV65-19-615	1-H11
R524-17-308	1-L7	P501-17-575	1-I7	F214-18-X66	1-N8	NSA2-18-831A	3-L6	BV11-19-386	1-F11	BV65-19-5D0A	1-M10	BV65-19-615	1-H11
M501-17-309	1-L7	R523-17-610	1-M7	F214-18-X70	1-N8	NSA1-18-835	3-L6	BV55-19-384	1-F11	BV11-19-5D1A	1-M10	BV11-19-616	1-H11
R505-17-310B	1-M7	R501-17-612	1-M7	JF01-18-X70	1-N8	F202-18-840A	3-L6	BV11-19-385	1-L10	BV11-19-5D1B	1-M10	BV45-19-616	1-H11
0821-17-313	1-M7	R501-17-613	1-M7	NF01-18-X70	1-N8	NF02-18-840	3-L6	BV11-19-386	1-F11	BV11-19-5D2	1-M10	BV65-19-616	1-H11
0884-17-315	1-M7	R504-17-620	1-M7	NS18-18-X71	1-N8	NS370-18-840	3-T6	BV11-19-387	1-F11	BV11-19-5D3	1-N10	BV65-19-617	1-H11
R502-17-316	1-M7	R502-17-621A	1-N7	NS26-18-X71	1-N8	NS91-18-840	1-K4	BV56-19-310	1-J9	BV11-19-5D4	1-N10	BV11-19-618	1-H11
4069-17-323	1-M7	3648-17-629	1-N7	NF01-18-X75	1-L8	NSA1-18-845	3-T6	BV11-19-311	1-L10	BV11-19-5F1	1-I11	BV11-19-620	1-C11
0884-17-325B	1-F7	R501-17-631A	1-N7	NS18-18-X80A	1-M8	NSA1-18-861A	3-T6	BV11-19-322	1-G11	BV11-19-5H0	1-N10	BV11-19-620A	1-C11
0305-17-327	1-M7	R501-17-632A	1-N7	NS26-18-X87	1-N8	ESA1-18-867	3-T6	BV11-19-324	1-G11	BV11-19-5J0	1-N10	BV11-19-622	1-H11
0305-17-328	1-M7	R501-17-633A	1-N7	NF01-18-X90	1-M8	NSA1-18-881	3-T6	BV11-19-331	1-J9	BV11-19-5J1	1-N10	0338-19-622	1-F11
R526-17-330	1-F7	R501-17-634A	1-N7	NS26-18-X91	1-M8	NSA1-18-881A	3-J6	0338-19-331A	1-J9	BV11-19-5J3	1-N10	BV65-19-623	1-H11
R526-17-330A	1-F7	R501-17-635	1-N7	NF01-18-X92	1-L8	NSA2-18-881	3-J6	BV11-19-336	1-G11	BV11-19-5J4	1-N10	BV65-19-625	1-H11
G5A0-17-335	1-F7	R501-17-636	1-N7	NS26-18-X92	1-M8	NSA2-18-881A	3-J6	BV55-19-336	1-G11	BV11-19-5K2	1-N10	BV65-19-626	1-H11
R501-17-335A	1-F7	R506-17-640	3-H6	NS26-18-X93	1-M8	NSA2-18-881B	3-J6	BV11-19-337	1-G11	BV65-19-5K2	1-N10	BV65-19-627	1-H11
R401-17-337A	1-D7	R507-17-640	3-H6	E356-18-X95	1-L8	NSA3-18-881	3-J6	BV11-19-338	1-G11	BV11-19-5K3	1-N10	BV65-19-628	1-H11
R504-17-337	1-F7	R508-17-640	3-H6	NF01-18-X95	1-L8	NSA3-18-881A	3-J6	BV11-19-341	1-J11	BV65-19-5K3	1-N10	BV45-19-651	1-C11
R505-17-337	1-F7	0821-17-641B	1-N7	NSA1-18-09XA	3-F8	NSA4-18-881	3-J6	BV11-19-347	1-J9	BV11-19-5K4	1-N10	BV11-19-655	1-I11
R502-17-338	1-F7	M502-17-651	1-N7	NSA2-18-09XA	3-F8	NSA4-18-881A	3-J6	BV65-19-360	1-L10	BV65-19-5K4	1-N10	BV11-19-669	1-D10
BV41-17-341	1-G11	M502-17-652	1-N7	NSA2-18-09XA	3-F8	NSA4-18-881B	3-J6	BV11-19-361	1-K9	BV11-19-5K5	1-N10	BV45-19-669	1-D10
R502-17-341A	1-M7	M502-17-653	1-N7	NSA1-18-09Y	3-F8	NSA2-18-882	3-J6	BV11-19-363	1-K9	BV65-19-5K5	1-N10	BV45-19-670	1-I11
M501-17-342	1-M7	M502-17-654	1-N7	NSA1-18-05ZC	3-F8	NSA2-18-883	3-J6	BV65-19-363	1-K9	BV11-19-5K6	1-N10	BV56-19-688	1-L9
R501-17-351	1-D8	M502-17-655	1-N7	NSA1-18-05ZD	3-F8	NSA1-18-890	2-D6	BV11-19-379	1-L10	BV65-19-5K6	1-N10	BV11-19-7A1	1-D10
0114-17-351	1-D8	0462-17-660C	1-I7	NSA1-18-05ZE	3-F8	NSA2-18-9E1	3-J6	BV11-19-381	1-K9	BV11-19-5K7	1-N10	BV11-19-7A3	1-L9
R502-17-371	1-G7	W501-17-724	1-N7	NSA2-18-05ZD	3-F8	NSA2-18-9E1A	3-J6	BV11-19-384	1-K9	BV11-19-5K8	1-C11	BV11-19-701	1-F9
R501-17-372	1-G7			NSA2-18-05ZE	3-F8			BV11-19-385	1-K9	BV11-19-5K9	1-C11	BV11-19-704	1-F9
R501-17-373	1-G7	W501-17-725B	1-N7	NSA2-18-05ZF	3-F8	NSA1-18-911	1-D5	BV11-19-386	1-K9	BV45-19-500	1-C11	BV11-19-707	1-J11
0810-17-381A	1-G7	R501-17-732	1-C8	NSA2-18-05ZG	3-F8	NSA2-18-911	1-D5	BV11-19-387	1-J11	BV11-19-503	1-C11	BV65-19-710	1-L9
R501-17-385A	1-G7			NSA3-18-05Z	3-F8	NSA1-18-921	3-J6	BV11-19-388	1-K9	BV11-19-504	1-C11	BV11-19-726	1-F9
BV65-17-400	1-J9			NSA2-18-05A	3-F8			BV11-19-389	1-K9	BV11-19-505	1-C11	BV11-19-732	1-J11
R505-17-400A	1-G7			NSA1-18-100	1-F8			BV11-19-391	1-K9	BV11-19-506	1-C11	BV11-19-733	1-J11
R505-17-400B	1-G7			NSA2-18-100	1-F8			0338-19-395	1-K9	BV11-19-507	1-C11	BV11-19-734	1-K11
R522-17-402	1-D8	* 18-000 *	*	NSA3-18-100	1-F8			BV11-19-397	1-L9	BV11-19-508	1-C11	BV35-19-735	1-M9
R501-17-404B	1-D8			NSA2-18-105A	1-F8			0338-19-397	1-L9	BV45-19-510	1-D11	BV60-19-735	1-M9
R505-17-406	1-E8			NSA1-18-110	1-G8			BV11-19-481	1-L10	BV11-19-520	1-D11	BV12-19-737	1-M9
R522-17-411	1-E8			NSA2-18-110	1-F8			BV11-19-482	1-L10	BV11-19-521	1-D11	BV40-19-737	1-M9
0103-17-411	1-E8	NSA1-18-T09	1-F8	NSA3-18-110	1-F8			BV11-19-483	1-L10	BV11-19-522	1-D11	0338-19-739	1-M9
R502-17-412A	1-D8	F8B5-18-T41	3-H6	NSA4-18-110	1-F8			BV11-19-484	1-G11	BV11-19-523	1-D11	BV65-19-750	1-D10
R505-17-416	1-G7	NSA1-18-T53</											

PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

BV11-19-791	1-D10	NSA1-20-344A	1-L5	BV11-21-1B1	1-G10	MA10-22-540	2-D3	FD01-26-668	2-G3	R001-27-411	2-M3	FD01-32-124	2-I4
BV30-19-881	1-D10	NSA2-20-344A	1-L5	BV11-21-1B4	1-G10	MA10-22-550	2-D3	FD01-26-669	2-G3	R001-27-412	2-M3	FD01-32-125	2-I4
BV56-19-805	1-D10	NSA3-20-344	1-L5	BV11-21-1B5	1-G10	BV40-22-900	1-L11	1243-26-671	2-G3	R001-27-413	2-M3	FD01-32-125A	2-I4
Q338-19-808	1-D10	NSA4-20-344	1-L5	BV12-21-1B9	1-G10	BV65-22-900	1-L11	FA18-26-680	2-G3	R001-27-414	2-M3	FD02-32-125	2-I4
BV40-19-810	1-F10	NSA1-20-345	1-L5	BV11-21-1B7	1-G10			8462-26-694	2-G3	R001-27-415	2-M3	FD02-32-125A	2-I4
BV65-19-815	1-F10	NSA2-20-345A	1-L5	BV45-21-1B8	1-G10	*****		FD01-26-699	2-G3	PA017-27-421A	2-D3	FD01-32-132	2-I4
BV11-19-818	1-F10	NSA4-20-345	1-L5	BV11-21-1B9	1-G10	*	*	FD01-26-71X	2-G3	PA01-27-431	2-M3	FD01-32-133	2-I4
BV11-19-819	1-F10	NSA1-20-346	1-L5	BV11-21-1C1	1-G10	* 23-000	*	FD01-26-731	2-G3	P044-27-431A	2-M3	FB01-32-168	2-H4
BV11-19-831	1-F10	NSA2-20-346	1-L5	BV40-21-1C1	1-G10			FD01-26-800	2-G3			B001-32-169A	2-H4
BV50-19-832	1-F10	NSA3-20-346A	1-L5	BV11-21-1C2	1-G10	*****		FD01-26-810	2-G3	*****		FD01-32-180	2-I4
BV11-19-833	1-F10	NSA1-20-348	1-M5	BV11-21-1C3	1-G10			H001-26-812	2-H3	*	*	FD01-32-186	2-J4
BV56-19-835	1-F10	NSA1-20-348	1-M5	BV11-21-1C4	1-G10	8735-23-180	1-M3	GJ25-26-816	2-H3	* 28-000	*	FD01-32-202	2-J4
BV56-19-835	1-F10	NSA1-20-348	1-M5	BV45-21-1C5	1-H10	8871-23-180	1-M3	FD01-26-851	2-H3	*	*	H380-32-230	2-K4
BV65-19-835	1-F10	NSA4-20-348	1-M5	BV11-21-1D1	1-H10	N236-23-356	1-O5	FD01-26-861	2-H3	*****		FD01-32-240	2-J4
BV65-19-835	1-F10	NSA1-20-348	1-M5	BV45-21-1D1	1-H10	HE19-23-610	1-M4	0613-26-922	2-J7			B455-32-279	2-J4
BV65-19-835	1-F10	NSA2-20-348	1-M5	BV11-21-1D2	1-H10	HE19-23-616	1-N4	FD01-26-98Z	2-H3	FD03-28-011	2-C4	8AB2-32-280	2-J4
BV65-19-835	1-F10	NSA4-20-348	1-M5	BV40-21-119	1-H10			FD01-26-980A	2-H3	FD01-28-012	2-C5	FD01-32-380	2-J4
BV65-19-835	1-F10	NSA1-20-348	1-M5	BV11-21-121	1-H10	*****		FD01-26-99Z	2-I3	FB01-28-091A	2-C6	FD01-32-411	2-H4
BV65-19-835	1-F10	NSA2-20-348	1-M5	BV45-21-121	1-H10	*	*	FD01-26-990A	2-H3	FD01-28-110A	2-N3	FD01-32-411A	2-H4
BV65-19-835	1-F10	NSA2-20-370A	1-M5	BV11-21-125	1-H10	* 24-000	*	FD01-26-998	2-I3			FD01-32-418	2-H4
BV65-19-835	1-F10	NSA1-20-371	1-M5			*****				FD01-28-114	2-E4	FD01-32-450	2-J4
BV65-19-835	1-F10			BV11-21-148	1-H10			*****		FD01-28-116	2-C5	FD02-32-450	2-J4
BV65-19-835	1-F10			BV11-21-149	1-H10			*	*			FD01-32-48YA	2-K4
BV65-19-835	1-F10			BV30-21-149	1-H10	8599-24-720	1-M8	* 27-000	*			FD01-32-480E	2-K4
BV65-19-835	1-F10			BV40-21-155	1-H10	8599-24-722	1-L8	*****		FD01-28-123A	2-C5	FD01-32-480F	2-K4
BV65-19-835	1-F10			BV40-21-156	1-H10	8599-24-743	1-M8			FD01-28-151A	2-E4	FD02-32-480	2-J4
BV65-19-835	1-F10			BV11-21-173	1-H10	8599-24-752	1-N8			FD01-28-155A	2-E4	FD01-32-490D	2-K4
BV65-19-835	1-F10			BV11-21-175	1-H10			0223-27-012	2-J3	FD01-28-156B	2-D4	8R71-32-503	2-K4
BV65-19-835	1-F10			BV11-21-193	1-H10			0223-27-030	2-J3	FD01-28-170B	2-D4	FD01-32-600C	2-K4
BV65-19-835	1-F10			BV11-21-2A1	1-G9	*****		R008-27-100	2-N3	FD01-28-180B	2-D4	FD01-32-611A	2-K4
BV65-19-835	1-F10			BV11-21-2A2	1-H9	*	*	R010-27-100	2-J3	FD01-28-2A0B	2-E4	G211-32-618A	2-K4
BV65-19-835	1-F10			BV11-21-2A3	1-H9	* 25-000	*	R010-27-100A	2-J3	FD01-28-300B	2-E4	FD01-32-620B	2-K4
BV65-19-835	1-F10			BV11-21-2A5	1-H10	*****		P041-27-110	2-J3	H266-28-312	2-E4	FD01-32-682E	2-K4
BV65-19-835	1-F10			BV11-21-2A6	1-H10			P062-27-110	2-J3	FD01-28-380	2-C5	FD01-32-683A	2-K4
BV65-19-835	1-F10			BV11-21-2A7	1-H10	PF03-25-100	2-C3	P044-27-120B	2-J3	FD01-28-42Y	2-E4	FD01-32-750	2-G4
BV65-19-835	1-F10			BV11-21-2A8	1-H10	PF04-25-100	2-C3	P045-27-120	2-J3	FD01-28-450B	2-E4	FD01-32-81X	2-G4
BV65-19-835	1-F10			BV11-21-2A9	1-H10	P011-25-123	2-C3	P045-27-120A	2-J3	FD01-28-457	2-E4	FD01-32-810	2-G4
BV65-19-835	1-F10			BV11-21-2K1	1-N9	1368-25-124	2-C3	R005-27-150	2-K3	FD01-28-458	2-E4	FD01-32-850A	2-H4
BV65-19-835	1-F10			BV40-21-216	1-H10	MA10-25-500	2-D3	R003-27-153	2-K3			GA78-32-911	2-G4
BV65-19-835	1-F10			BV40-21-243	1-H10	*****				FD01-28-460	2-E4	FD01-32-980D	2-G4
BV65-19-835	1-F10					* 26-000	*	R001-27-165	2-J3	FD01-28-461	2-E4	FD03-32-980D	2-G4
BV65-19-835	1-F10			BV30-21-247	1-H10	*****		R004-27-171	2-K3	FD01-28-50X	2-F4	*****	
BV65-19-835	1-F10			BV56-21-249	1-H10			P099-27-2000	2-K3	FD03-28-50X	2-F4	* 33-000	*
BV65-19-835	1-F10			BV11-21-252	1-H10			R008-27-200A	2-K3			*	*
BV65-19-835	1-F10			BV11-21-253	1-H10	0730-26-060	2-J3	R001-27-210	2-K3	FD01-28-700E	2-C4	*****	
BV65-19-835	1-F10			BV11-21-254	1-J10	GA2A-26-071	2-L4	0604-27-220	2-K3	FD03-28-700E	2-C4	*****	
BV65-19-835	1-F10			BV11-21-255	1-J10	FD01-26-112	2-E3	8051-27-235	2-K3	FD01-28-710A	2-F4	FD01-33-021A	2-L4
BV65-19-835	1-F10			BV40-21-283	1-J10	J001-26-114	2-E3	8051-27-236	2-K3	FD01-28-80XA	2-F4	FD01-33-031A	2-L4
BV65-19-835	1-F10			BV65-21-381	1-N9	FB01-26-121A	2-E3	P043-27-238	2-K3	FD01-28-80XH	2-F4	LA01-33-042B	2-L4
BV65-19-835	1-F10			BV11-21-382	1-N9	FD01-26-122	2-E3	R005-27-320	2-K3	FD01-28-890A	2-F4	B455-33-062	2-F3
BV65-19-835	1-F10			BV11-21-383	1-N9	FD01-26-122	2-E3	M005-27-326A	2-K3	FD01-28-900F	2-C4	J00Y-33-062	2-L4
BV65-19-835	1-F10			BV11-21-384	1-J10	FD01-26-132	2-C5	0118-27-350A	2-K3	FD01-28-900G	2-C4	FD23-33-232	2-M4
BV65-19-835	1-F10			BV11-21-386	1-N9	FD01-26-132A	2-E3	R701-27-355	2-K3	FD03-28-900D	2-C4	FD01-33-25X	2-L4
BV65-19-835	1-F10			BV45-21-387	1-N9			R001-27-356	2-E4	FD03-28-900E	2-C4	FD01-33-261B	2-L4
BV65-19-835	1-F10			BV11-21-389	1-N9	FD01-26-133A	2-E4	R001-27-357	2-K3	*****		FD01-33-271B	2-L4
BV65-19-835	1-F10			BV40-21-3C1	1-N9	FD01-26-133B	2-E3	R001-27-358	2-K3	* 32-000	*	FD01-33-61XA	2-M4
BV65-19-835	1-F10			BV65-21-321	1-K9			R001-27-359	2-L3	*	*	B001-33-691	2-M4
BV65-19-835	1-F10			BV11-21-391	1-N9	J001-26-139A	2-E3	R001-27-361	2-L3	*****		0233-33-691	2-I3
BV65-19-835	1-F10			BV11-21-471	1-J11	GA55-26-15X	2-L4	R001-27-362	2-L3	FD01-32-049	2-G4	FB05-33-693	2-M4
BV65-19-835	1-F10			BV11-21-472	1-J11	J001-26-151	2-E3	R001-27-363	2-L3	FD01-32-049	2-G4	1316-33-693	2-I3
BV65-19-835	1-F10									FD01-32-090A	2-H4	FD01-33-696	2-M4
BV65-19-835	1-F10			BV11-21-475	1-J11	H001-26-205	2-G3	R001-27-364	2-L3	B455-32-099	2-H4	FD01-33-697	2-M4
BV65-19-835	1-F10			BV65-21-5H1	3-K6	FD01-26-220	2-E4	R001-27-365	2-L3	FD01-32-100B	2-H4	FD13-33-980A	2-M4
BV65-19-835	1-F10			BV65-21-5H2	3-K6	FD01-26-230	2-E4	R001-27-366	2-L3	FD01-32-100D	2-H4	FD13-33-980B	2-M4
BV65-19-835	1-F10			BV01-21-677	1-H9	FD01-26-233	2-G3	R001-27-367	2-L3	FD01-32-11X	2-I4	FD13-33-990B	2-M4
BV65-19-835	1-F10			BV65-21-678	1-F9	FD04-26-241	2-E3	R001-27-368	2-L3	FD01-32-110B	2-I4		
BV65-19-835	1-F10			BV40-21-776	1-J10	J001-26-241B	2-E3	R001-27-369	2-L3	FD01-32-110D	2-I4		
BV65-19-835	1-F10			BV11-21-782	1-J10	FD01-26-25X	2-E3	R001-27-371	2-L3	FD01-32-112	2-I4		
BV65-19-835	1-F10			BV11-21-784	1-J10	FD01-26-250	2-E4	R001-27-372	2-L3	FD01-32-119	2-I4		
BV65-19-835	1-F10			BV11-21-786	1-J10	FD01-26-251	2-E3	R001-27-373	2-L3	FD01-32-120	2-I4		
BV65-19-835	1-F10			BV35-21-793	1-J10	FD01-26-261	2-E3	R001-27-374	2-L3	FD01-32-123	2-I4		
BV65-19-835	1-F10					FD01-26-281	2-G3	R001-27-375	2-L3	FD01-32-123	2-I4		
BV65-19-835	1-F10					FD01-26-285A	2-G3	R001-27-401	2-L3	FD01-32-123	2-I4		
BV65-19-835	1-F10					FDY1-26-43Z	2-G3	R001-27-402	2-L3	FD01-32-123	2-I4		
BV65-19-835	1-F10					FDY1-26-46Z	2-G3	R001-27-403	2-L3	FD01-32-123	2-I4		
BV65-19-835	1-F10					FD04-26-471	2-F3	R001-27-404	2-L3	FD01-32-123	2-I4		
BV65-19-835	1-F10					GA55-26-471	2-L4	R001-27-405	2-L3	FD01-32-123	2-I4		

PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER INDEX / INDICE DE NUMERO DE PARTES

***** * 34-000 * *****	***** * 39-000 * *****	FD01-41-661A 1-N3 FD01-41-661B 1-N3 FD01-41-662A 1-N5 FD01-41-662B 1-N5 FD01-41-920 2-H6 FD01-41-990A 2-H6 FD01-41-990B 2-H6 F100-41-990B 2-H6	FD04-43-270A 2-N7 FD04-43-270B 2-N7 FD04-43-280B 2-N7 FD04-43-280C 2-N7 FD04-43-280D 2-N7 FD01-43-30X 2-E7 FD01-43-30XA 2-E7 FD02-43-30X 2-E7 FD02-43-30XA 2-E7 FD04-43-311B 2-N7 FD04-43-320C 2-N7 FD04-43-320D 2-N7 FD04-43-360B 2-N7 FD04-43-370B 2-N7 FDY1-43-402B 2-N7 TA04-43-403A 2-N7 BGY4-43-412 2-N7 FD01-43-443 2-N7 FD01-43-443A 2-N7 H001-43-443 2-N7	B455-43-853 2-K7 FD01-43-86XB 2-K7 FD01-43-86YB 2-K7 FD01-43-860B 2-D8 FD01-43-860D 2-D8 FD01-43-860E 2-D8 FD01-43-87XA 2-K7 FD01-43-87YA 2-K7 FD04-43-920 2-D8 NA17-43-902 2-D8 B01C-43-956 2-N7 FD01-43-980B 2-K7	***** * 46-000 * *****	FD02-46-AT1 2-I8 FD02-46-030 2-I8 FC07-46-040A 2-I8 J001-46-051 2-I8 FD02-46-058 2-I8 FD02-46-10XD 2-I8 FD02-46-10XE 2-I8 FD02-46-100B 2-I8 FD02-46-100C 2-I8 FD02-46-570A 2-E7 0187-46-683 2-E7 H380-46-684 1-K11 H380-46-689 1-K11	FD07-50-31Y 2-H10 FD01-50-510E 2-K10 FD01-50-516A 2-K10 FD01-50-530E 2-K10 FD01-50-536A 2-K10 FD01-50-538A 2-K10 FD01-50-539A 2-K10 FD01-50-6AX 2-J10 FD01-50-6AXB 2-J10 FD01-50-6A6 2-J10 FD01-50-6A7 2-J10 NA01-50-6B1 2-J10 NA01-50-6B2 2-J10 FD01-50-600 2-J10 FD01-50-600A 2-J10 FD01-50-600B 2-J10 FD01-50-601A 2-J10 FD01-50-601B 2-J10 FD01-50-615 2-J10
FD01-34-003 2-C5 FD03-34-011 2-L4 FD01-34-034 2-L4 FD01-34-034A 2-C5 H380-34-034 2-C5	B001-39-037B 2-D4 FD01-39-040C 2-D4 FD01-39-050A 2-C6 FD01-39-065 2-C6 FD01-39-066 2-C6 FD01-39-710B 2-C6 FD01-39-723 2-C6 FD01-39-730A 2-F4	***** * 42-000 * *****	FD04-43-320D 2-N7 FD04-43-360B 2-N7 FD04-43-370B 2-N7 FDY1-43-402B 2-N7 TA04-43-403A 2-N7 BGY4-43-412 2-N7 FD01-43-443 2-N7 FD01-43-443A 2-N7 H001-43-443 2-N7	***** * 44-000 * *****	FD02-46-10XD 2-I8 FD02-46-10XE 2-I8 FD02-46-100B 2-I8 FD02-46-100C 2-I8 FD02-46-570A 2-E7 0187-46-683 2-E7 H380-46-684 1-K11 H380-46-689 1-K11	FD01-50-619 2-J10 FD01-50-619A 2-J10 FD01-50-640D 2-K10 FD01-50-644A 2-K10 FD01-50-644B 2-K10 FD01-50-649A 2-K10 FD01-50-650D 2-K10 FD01-50-654A 2-K10 FD01-50-7P0 2-F12 FB01-50-733 2-H10 FD01-50-741B 2-C11 FD01-50-741C 2-C11 G043-50-742 2-K10 3-H10	
FD01-34-151A 2-G5 FD01-34-155 2-G5 FD01-34-156 2-G5 FD01-34-160C 2-G5 FD01-34-160D 2-G5 FD01-34-17X 2-G5 FD01-34-180B 2-G5 FD01-34-180C 2-G5 FD01-34-19X 2-G5 FD01-34-200B 2-C5 FD01-34-213 2-C5 8871-34-222 2-C6	* 40-000 * *****	HG31-42-114 2-L6 FD01-42-210A 2-L6 FD01-42-231 2-M6 FD01-42-231A 2-M6 FD01-42-232 2-M6 FD01-42-237 2-L6 FD01-42-242 2-L6 GE80-42-243 2-M6 FD01-42-244 2-M6 H260-42-245A 2-M6 UE94-42-250 2-M6 BF67-42-252 2-N6 D061-42-270 2-M6 FD01-42-289 2-M6 HG30-42-289 2-M6 FD01-42-298 2-M6 FD01-42-41X 2-D7 FD01-42-510A 2-N6 FD01-42-561 2-N6 FD01-42-544 2-N6	FD04-43-505 2-N7 W023-43-505 2-N6 NA23-43-515 2-N7 FD04-43-540A 2-N7 FDY1-43-55X 2-H7 G309-43-607 2-H12 B533-43-622 2-I7 NA23-43-625 2-I7 FD01-43-63XC 2-J7 FD01-43-63XC 2-J7 FD03-43-63XC 2-J7 FD03-43-63XC 2-J7 B604-43-63Z 2-I7	***** * 45-000 * *****	FD05-49-240 2-N4 W001-49-510 2-H6 B603-49-580 2-H7 FD04-49-686 2-I7 F100-49-686 2-I7 0839-49-686A 2-I6	FD01-44-010C 2-E8 FD01-44-010G 2-E8 FD01-44-150 2-E8 QA28-44-375A 2-E8 0118-44-375 2-E8 FD01-44-410 2-E8 FDU1-44-420A 2-E8	FD01-50-751B 2-C11 FD01-50-751C 2-C11 FD01-50-753 2-M13 G043-50-753 3-D11 FD01-50-783 2-F12
FD01-34-250B 2-C5 FD01-34-300D 2-D5 FD01-34-300E 2-D5 FD01-34-313 2-D5 H260-34-313 2-D5	RF36-40-305 2-F6 NS78-40-307 2-F6 NSA1-40-354 2-F6 JE10-40-355 1-F4	FD01-42-545 2-N6 FD01-42-546 2-N6 FD01-42-710 2-N6 FD01-42-720 2-N6 B455-42-761 2-M6 FD01-42-761 2-N6 FD01-42-762 2-N6 B455-42-763 2-N6 B529-42-763 2-C7 FD01-42-763 2-C7 FD01-42-766 2-N6 FD01-42-767 2-N6 FD01-42-768 2-C7 FD01-42-790 2-C7 J001-42-910A 2-N6 FB01-42-980 2-N6 FB01-42-985 2-C7	W023-43-635 2-J7 0136-43-635 2-J6 FD01-43-64XC 2-N7 FD01-43-64XD 2-N7 FD03-43-64XC 2-N7 FD03-43-64XD 2-N7 FD01-43-640B 2-H7 FD01-43-670B 2-N7 H381-43-676 2-H7 FD01-43-680B 2-K7 B001-43-694A 2-K7 FD04-43-7A0C 2-N7 FD04-43-7A0D 2-N7 NA23-43-7A2 2-N7 NA23-43-7A3 2-N7 NA23-43-7A4 2-C8 NA23-43-7A6 2-C8 NA23-43-7A7 2-C8 NA23-43-7A8 2-C8 FD04-43-7A9 2-C8	***** * 45-000 * *****	FD01-45-111 2-F8 FD01-45-112 2-F8 FD01-45-115A 2-F8 FD01-45-115B 2-F8 FD01-45-280B 2-K7 FD01-45-280C 2-K7 FD01-45-322C 2-L7	FD01-45-320D 2-L7 FD01-45-33XA 2-K7 FD01-45-33XB 2-K7 FD01-45-33XC 2-K7 FD01-45-36XA 2-L7 FD01-45-36Z 2-L7 FD01-45-36Z2A 2-L7 FD01-45-360B 2-L7 D001-45-367 2-L7 FD01-45-510C 2-J6 FD01-45-510D 2-J6 HE01-45-540 2-J6 FD01-45-611A 2-F8 FD01-45-612 2-F8 FD01-45-712 2-G8 FD01-45-713 2-G8 FD01-45-910A 2-G8 FD01-45-911 2-G8 FB01-45-914 2-C7	FD01-50-790A 2-F12 B482-50-792 2-F12 FD02-50-792 2-I11 FD03-50-792 2-I11 FD01-50-793 2-F12 FD01-50-794A 2-F12 FD01-50-795 2-F12 G078-50-795 2-F12 MA01-50-795B 2-F12 UB39-50-795 2-D11 E016-50-796 2-F12 FD01-50-798 2-G12 FD02-50-798 2-F12 FD01-50-799 2-H10 FD01-50-8R0B 2-K10 3-H10 FD01-50-8S0B 2-L10 3-H10 G158-50-803 2-F10
FD01-34-350D 2-D5 FD01-34-350E 2-D5 FD01-34-420 2-D5 FD01-34-460B 2-D5 FD01-34-461 2-D5 FD01-34-470A 2-D5 FD01-34-471A 2-D5 FD01-34-473 2-D5	JE11-40-355 2-F6 NSA2-40-680 2-F6 B545-40-815 2-F6 NSA1-40-860 2-F6 NSA1-40-865A 2-F6 NSA1-40-870B 2-G6 NSA1-40-872 2-G6 F201-40-908 2-F6	***** * 43-000 * *****	FD04-43-7A9A 2-C8 FD05-43-70XB 2-C8 F051-43-708A 2-C8 FD04-43-71YC 2-C8 FD01-43-710A 2-K7 FD04-43-72YC 2-C8 FD01-43-720A 2-K7 FD05-43-73XC 2-C8 FD01-43-740A 2-H7 FD01-43-740B 2-H7 FD01-43-750A 2-C8 FD01-43-750B 2-C8 FD01-43-750C 2-C8 FD04-43-780E 2-C8 FD04-43-780F 2-C8 FD04-43-800B 2-N7 FD01-43-810A 2-K7 FD01-43-836B 2-N7 FD01-43-840B 2-N7 F100-43-85X 2-K7	***** * 44-000 * *****	FD01-45-911 2-G8 FD01-45-912 2-G8 FD01-45-115A 2-F8 FD01-45-115B 2-F8 FD01-45-280B 2-K7 FD01-45-280C 2-K7 FD01-45-322C 2-L7	FD01-50-AF5 2-H10 FD01-50-A21 2-E10 FD01-50-CR0 2-E10 FD01-50-CS0 2-E10 EA01-50-EA0 2-L7 FD01-50-OKXA 2-E10 FD01-50-OK0A 2-E10 FD01-50-OK1B 2-E10 BR70-50-LZ1 2-E10 BR70-50-022 2-C14 2-E10 FD01-50-025 2-E10 FD01-50-031C 2-E10 BF67-50-033 2-E10 GJ21-50-049 2-E10 FA01-50-054 2-M7 FD01-50-070B 2-E10 FD01-50-1AXB 2-F10 FD01-50-1AYB 2-F10 FD01-50-1B0A 2-F10 FD01-50-1C0A 2-F10	FD01-50-850C 2-T11 B455-50-891 3-N5 EA01-50-891 3-N5 B481-50-894 3-N5 FD01-50-894 3-N5 FDY2-50-91X 2-G12 FDY2-50-91XA 2-G12 FDY2-50-91XB 2-G12 FD01-50-912 2-G12 FD01-50-913 2-G12 FDY2-50-92X 2-G12 FDY2-50-92XA 2-G12 FDY2-50-92XB 2-G12
FD01-34-480A 2-D5 FD01-34-610A 2-G5 FD01-34-700B 2-F5 FD03-34-730C 2-F5 FD01-34-701A 2-D5	NSA1-40-866 2-F6 NSA1-40-865A 2-F6 NSA1-40-870B 2-G6 NSA1-40-872 2-G6 F201-40-908 2-F6	***** * 41-000 * *****	FD04-43-7A9 2-C8	***** * 45-000 * *****	FD01-45-911 2-G8 FD01-45-912 2-G8 FD01-45-115A 2-F8 FD01-45-115B 2-F8 FD01-45-280B 2-K7 FD01-45-280C 2-K7 FD01-45-322C 2-L7	FD01-50-100 2-F10 FD01-50-1E0 2-F10 FD01-50-1F1 2-F10 FD01-50-101 2-F10 FD01-50-111 2-H10 NA01-50-101A 2-F16 FB01-50-133C 2-F10 2-H10 FB01-50-144 2-F10 3597-50-152 2-F12 FD01-50-170B 2-E10 FD01-50-221B 2-H10 C001-50-222 2-F10 D002-50-228 3-M10 FD01-50-231A 2-H10 BF82-50-233 2-F10 FD01-50-260A 2-H10 FD01-50-3A0 2-H10 FD01-50-3B0 2-H10 FD07-50-31X 2-H10	FD01-50-803 2-H10 G158-50-803 2-F10
FD01-34-710A 2-F5 FD01-34-711A 2-E5 FD01-34-800G 2-G5	0727-41-023 2-E7 0727-41-131 2-E7 0305-41-140 2-E7 FD01-41-30XA 2-E7 FD01-41-360A 2-J6 FD03-41-370 2-J6 F100-41-370 2-J6 G091-41-412 2-H6 FD01-41-419 2-H6 F100-41-421 2-H6 0815-41-422D 2-H6 H005-41-424 2-H6 H001-41-443 2-E7	***** * 43-000 * *****	FD04-43-7A9 2-C8	***** * 45-000 * *****	FD01-45-911 2-G8 FD01-45-912 2-G8 FD01-45-115A 2-F8 FD01-45-115B 2-F8 FD01-45-280B 2-K7 FD01-45-280C 2-K7 FD01-45-322C 2-L7	FD01-50-222 2-F10 D002-50-228 3-M10 FD01-50-231A 2-H10 BF82-50-233 2-F10 FD01-50-260A 2-H10 FD01-50-3A0 2-H10 FD01-50-3B0 2-H10 FD07-50-31X 2-H10	FD01-50-803 2-H10 G158-50-803 2-F10
FD01-34-900B 2-F5 FD03-34-900C 2-F5	0727-41-023 2-E7 0727-41-131 2-E7 0305-41-140 2-E7 FD01-41-30XA 2-E7 FD01-41-360A 2-J6 FD03-41-370 2-J6 F100-41-370 2-J6 G091-41-412 2-H6 FD01-41-419 2-H6 F100-41-421 2-H6 0815-41-422D 2-H6 H005-41-424 2-H6 H001-41-443 2-E7	***** * 43-000 * *****	FD04-43-7A9 2-C8	***** * 45-000 * *****	FD01-45-911 2-G8 FD01-45-912 2-G8 FD01-45-115A 2-F8 FD01-45-115B 2-F8 FD01-45-280B 2-K7 FD01-45-280C 2-K7 FD01-45-322C 2-L7	FD01-50-222 2-F10 D002-50-228 3-M10 FD01-50-231A 2-H10 BF82-50-233 2-F10 FD01-50-260A 2-H10 FD01-50-3A0 2-H10 FD01-50-3B0 2-H10 FD07-50-31X 2-H10	FD01-50-803 2-H10 G158-50-803 2-F10
***** * 37-000 * *****	0727-41-023 2-E7 0727-41-131 2-E7 0305-41-140 2-E7 FD01-41-30XA 2-E7 FD01-41-360A 2-J6 FD03-41-370 2-J6 F100-41-370 2-J6 G091-41-412 2-H6 FD01-41-419 2-H6 F100-41-421 2-H6 0815-41-422D 2-H6 H005-41-424 2-H6 H001-41-443 2-E7	***** * 43-000 * *****	FD04-43-7A9 2-C8	***** * 45-000 * *****	FD01-45-911 2-G8 FD01-45-912 2-G8 FD01-45-115A 2-F8 FD01-45-115B 2-F8 FD01-45-280B 2-K7 FD01-45-280C 2-K7 FD01-45-322C 2-L7	FD01-50-222 2-F10 D002-50-228 3-M10 FD01-50-231A 2-H10 BF82-50-233 2-F10 FD01-50-260A 2-H10 FD01-50-3A0 2-H10 FD01-50-3B0 2-H10 FD07-50-31X 2-H10	FD01-50-803 2-H10 G158-50-803 2-F10
B002-37-160 2-H5 FD01-37-191A 2-H5 FD01-37-191B 2-H5 FD01-37-790A 2-I5 FD01-37-810 2-I5	0727-41-023 2-E7 0727-41-131 2-E7 0305-41-140 2-E7 FD01-41-30XA 2-E7 FD01-41-360A 2-J6 FD03-41-370 2-J6 F100-41-370 2-J6 G091-41-412 2-H6 FD01-41-419 2-H6 F100-41-421 2-H6 0815-41-422D 2-H6 H005-41-424 2-H6 H001-41-443 2-E7	***** * 43-000 * *****	FD04-43-7A9 2-C8	***** * 45-000 * *****	FD01-45-911 2-G8 FD01-45-912 2-G8 FD01-45-115A 2-F8 FD01-45-115B 2-F8 FD01-45-280B 2-K7 FD01-45-280C 2-K7 FD01-45-322C 2-L7	FD01-50-222 2-F10 D002-50-228 3-M10 FD01-50-231A 2-H10 BF82-50-233 2-F10 FD01-50-260A 2-H10 FD01-50-3A0 2-H10 FD01-50-3B0 2-H10 FD07-50-31X 2-H10	FD01-50-803 2-H10 G158-50-803 2-F10
***** * 37-000 * *****	0727-41-023 2-E7 0727-41-131 2-E7 0305-41-140 2-E7 FD01-41-30XA 2-E7 FD01-41-360A 2-J6 FD03-41-370 2-J6 F100-41-370 2-J6 G091-41-412 2-H6 FD01-41-419 2-H6 F100-41-421 2-H6 0815-41-422D 2-H6 H005-41-424 2-H6 H001-41-443 2-E7	***** * 43-000 * *****	FD04-43-7A9 2-C8	***** * 45-000 * *****	FD01-45-911 2-G8 FD01-45-912 2-G8 FD01-45-115A 2-F8 FD01-45-115B 2-F8 FD01-45-280B 2-K7 FD01-45-280C 2-K7 FD01-45-322C 2-L7	FD01-50-222 2-F10 D002-50-228 3-M10 FD01-50-231A 2-H10 BF82-50-233 2-F10 FD01-50-260A 2-H10 FD01-50-3A0 2-H10 FD01-50-3B0 2-H10 FD07-50-31X 2-H10	FD01-50-803 2-H10 G158-50-803 2-F10
B002-37-160 2-H5 FD01-37-191A 2-H5 FD01-37-191B 2-H5 FD01-37-790A 2-I5 FD01-37-810 2-I5	0727-41-023 2-E7 0727-41-131 2-E7 0305-41-140 2-E7 FD01-41-30XA 2-E7 FD01-41-360A 2-J6 FD03-41-370 2-J6 F100-41-370 2-J6 G091-41-412 2-H6 FD01-41-419 2-H6 F100-41-421 2-H6 0815-41-422D 2-H6 H005-41-424 2-H6 H001-41-443 2-E7	***** * 43-000 * *****	FD04-43-7A9 2-C8	***** * 45-000 * *****	FD01-45-911 2-G8 FD01-45-912 2-G8 FD01-45-115A 2-F8 FD01-45-115B 2-F8 FD01-45-280B 2-K7 FD01-45-280C 2-K7 FD01-45-322C 2-L7	FD01-50-222 2-F10 D002-50-228 3-M10 FD01-50-231A 2-H10 BF82-50-233 2-F10 FD01-50-260A 2-H10 FD01-50-3A0 2-H10 FD01-50-3B0 2-H10 FD07-50-31X 2-H10	FD01-50-803 2-H10 G158-50-803 2-F10







PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

FD01-67-060E	J-D8	FD04-67-501A	J-L8	FD01-68-J30 02	J-M9	FD01-68-450033	J-M3	FD01-68-710A02	J-L9	N3A1-69-036	J-L10	FD01-69-851	J-C6
FD04-67-060C	J-D8	FD05-67-501	J-L8	FD01-68-J30A02	J-M9	FD01-68-450022	J-M3	FD01-68-710A17	J-L9	N3A2-69-036	J-L10	FD01-69-852	J-C6
FD04-67-060D	J-D8	FD01-67-502	J-L8	FD01-68-J40 02	J-M9	FD01-68-450017	J-M3	FD01-68-710A33	J-L9	N3A3-69-036	J-L10	FD01-69-858	J-D6
FD01-67-070E	J-G8	4116-67-502	J-E9	FD01-68-J40A02	J-M9	FD01-68-450F33	J-M3	B456-68-712	J-L9	N3A4-69-036	J-L10	FD01-69-859	J-D6
FD01-67-070G	J-G8	D061-67-505	J-L8	FD01-68-J5Y 02	J-N9	FD05-68-9CX 02	J-C11	FD01-68-720A02	J-L9	N3A1-69-044A	J-L10	FD01-69-861	J-D6
FD01-67-070H	J-G8	LA01-67-505B	J-E9	FD09-68-J5Y 02	J-N9	FD05-68-9CX 17	J-C11	FD01-68-720A17	J-L9	FA01-69-064A	J-L10	FD01-69-864	J-C6
FD01-67-070J	J-G8		J-L8	M001-68-0C0A	J-H9	FD05-68-9CX 33	J-C11	FD01-68-720A33	J-L9	HG30-69-065	J-L10	FD01-69-865	J-D6
FD02-67-070	J-G8	FD01-67-508	J-L8	FD01-68-021	J-H9	FD05-68-9C1 02	J-M10	B216-68-755	J-J3	NA01-49-068A	J-L10	EA05-69-871	J-D6
FD02-67-070A	J-G8	FD01-67-509	J-L8	FD01-68-030B02	J-H9	FD05-68-9C1 17	J-M10	FD01-68-8h2	J-M9	FD03-69-074	J-K10	EA05-69-872	J-D6
F100-67-071E	J-E8	FD02-67-509	J-L8	FD01-68-030B17	J-H9	FD05-68-9C1 33	J-M10	FD01-68-8h7	J-M9	HG30-69-119	J-N5	EA05-69-873	J-C6
F801-67-095	J-E8	FD01-67-510 J9	J-M8	FD01-68-030B33	J-H9	FD01-68-9H0 02	J-M10	FD01-68-8T0A02	J-L9	FD01-69-123	J-L10	FD03-69-896A	J-E6
H115-67-099	J-F8	FD01-67-510 NU	J-M8	FD01-68-030C02	J-H9	FD01-68-9H0 17	J-M10	FD01-68-8T0B02	J-L9	FD01-69-133	J-L10	FD03-69-897	J-E6
H116-67-099	J-F8	FD01-67-510 O3	J-M8	FD01-68-030C17	J-H9	FD01-68-9H0 33	J-M10	FD01-68-8V0A02	J-M9	HG31-69-220 02	J-L10	GA28-69-897	J-E6
J001-67-099	J-G8	FD02-67-510 J9	J-L8	FD01-68-030C33	J-H9	FD05-68-9HX 02	J-C11	FD01-68-8V0B02	J-M9	HG31-69-220A02	J-L10	GA28-69-897	J-E6
FD01-67-100C	J-E8	FD02-67-510 NU	J-L8	FD03-68-030B02	J-H9	FD05-68-9HX 33	J-C11	FD01-68-8V0C02	J-M9	FD01-69-240 J9	J-H10	FD01-69-9H1	J-E6
FD04-67-100C	J-E8	FD02-67-510 O3	J-L8	FD03-68-030B17	J-H9	FD05-68-9N1 02	J-N10	FD01-68-8W0 02	J-E10	FD01-69-240 M8	J-H10	FD01-69-9H2	J-E6
FD04-67-100D	J-E8	FD03-67-510	J-E9	FD03-68-030B33	J-H9	FD05-68-9N1 17	J-N10	1011-68-815	J-N16	FD01-69-240 NU	J-H10	FD01-69-9H3	J-E6
FD04-67-100E	J-E8	B499-67-519	J-F9	FD03-68-030C02	J-H9	FD05-68-9N1 33	J-N10	FD01-68-82X 02	J-F10	FD01-69-240 PZ	J-H10	FD01-69-9H4	J-E6
FD01-67-190C	J-J8	FD01-67-560	J-C7	FD03-68-030C17	J-H9	FD01-68-9W0 02	J-M10	FD01-68-82X 17	J-F10	FD01-69-240 3L	J-H10	FD04-69-920	J-E6
FD01-67-190D	J-J8	FD01-67-560A	J-C7	FD03-68-030C33	J-H9			FD01-68-82X 32	J-F10			FD01-69-921	J-E6
FD01-67-190E	J-J8	FD01-67-580	J-C7	0003-68-032	J-N15	FD01-68-9W0 17	J-M10	FD01-68-83X	J-F10	HG31-69-240	J-N5	FD04-69-922	J-F6
FD04-67-190C	J-J8	FD02-67-580	J-C7	GM09-68-049 02	J-H9	FD01-68-9W0 33	J-M10	FD05-68-83XA	J-F10	FD01-69-242 J9	J-N10	FD01-69-923	J-E6
FD04-67-190D	J-J8	M020-67-6D1	J-C7	GM09-68-049 17	J-H9	FD01-68-905	J-M10	FD01-68-850C02	J-M9	FD01-69-242 M8	J-L10	EA05-69-924	J-D6
FD01-67-200C	J-J8	FD01-67-650	J-C7	GM09-68-049 33	J-H9	FD01-68-909	J-M10	FD01-68-850D02	J-M9	FD01-69-242 NU	J-L10	F100-69-926	J-E6
FD01-67-200D	J-J8	FD01-67-7F0B	J-C7	NA01-68-070	J-G10	FD01-68-91X0	J-N3	FD01-68-857 02	J-M9	FD01-69-242 PZ	J-L10	F100-69-926A	J-F6
FD04-67-200C	J-J8	FD01-67-7F0C	J-C7	FD01-68-151 02	J-D10	FD01-68-91YD	J-N3	BF70-68-865 00	J-F10	FD01-69-242 3L	J-L10	KA02-69-926	J-E6
FD04-67-200E	J-J8	KA32-67-720	J-C7	FD01-68-160E02	J-J9	FD01-68-920D02	J-N10	BF70-68-865 33	J-F10	GASR-69-261 02	J-J10	GA28-69-927	J-F6
FD01-67-240E	J-E8	GE10-67-730	J-C7	FD01-68-165	J-J9	FD01-68-920D17	J-N10	BR70-68-865	J-D4	GASR-69-261 17	J-J10	FD01-69-929	J-E6
F100-67-270A	J-E8	KE10-67-730	J-C7	FD01-68-170E02	J-J9	FD01-68-920D33	J-N10	B040-68-865A00	J-D4	GASR-69-263 02	J-J10	FD01-69-960 02	J-D6
GJ21-67-306	J-N8	H022-67-740	J-D7	GD30-68-213B	J-D10	FD01-68-920E17	J-N10	B040-68-865A18	J-D4	GASR-69-263 17	J-J10	FD01-69-960 17	J-D6
FD01-67-321	J-N8	H270-67-740	J-C7	B100-68-215A	J-K9	FD01-68-920E33	J-N10	B102-68-865A33	J-D4	GASR-69-263 33	J-J10	FD01-69-960A02	J-D6
FD02-67-321	J-N8		J-N4	0208-68-230	J-G10	FD05-68-920E02	J-N10			FD01-69-270C02	J-L10	FD01-69-960A17	J-D6
FD01-67-330	J-N8	H302-67-740	J-D7	B101-68-252	J-D10	FD05-68-920D17	J-N10	B103-68-865	J-D4	FD01-69-270C17	J-L10	FD01-69-960A33	J-D6
FD01-67-330A	J-N8	LA10-67-740	J-D7	B101-68-252 33	J-D10	FD05-68-920D33	J-N10	B455-68-865 00	J-F10	FD01-69-270C33	J-L10	FD01-69-970C02	J-D12
FD03-67-330	J-E9	F100-67-741	J-D7	FD01-68-301 02	J-L5	FD05-68-920E17	J-N10	GJ12-68-865	J-C11	FD03-69-270C02	J-L10	FD01-69-970C17	J-D12
GAD7-67-330	J-N8	FC33-67-830	J-D7	FD01-68-305	J-N12	FD05-68-920E33	J-N10			FD03-69-270C17	J-L10	FD03-69-970C33	J-D12
HG31-67-330	J-N8	FD01-67-980	J-D7	FD05-68-310C02	J-K9	FD01-68-950D17	J-N10			FD03-69-270C33	J-L10	FD03-69-970C02	J-D12
B461-67-331	J-E9	FD01-67-980A	J-D7	EA01-68-315	J-K9	FD01-68-950D33	J-N10			FD01-69-276	J-C11	FD03-69-970C17	J-D12
FD01-67-331	J-N8	FD01-67-981A	J-D7			FD01-68-950D17	J-N10			FD01-69-276A	J-C11	FD03-69-970C33	J-D12
F100-67-331	J-N8												
H381-67-331	J-N8	FD01-67-9C1	J-D7	FD01-68-351	J-K9	FD01-68-950E02	J-N10	GJ21-68-865	J-I9	GASR-69-277 02	J-J10	EA01-69-973	J-D12
LA02-67-331A	J-N8	*****		FD01-68-352	J-L9	FD01-68-950E17	J-N10	G032-68-865A00	J-F10	GASR-69-277 17	J-J10	EA05-69-973	J-D12
FD01-67-340	J-N8	* 68-000 *		FD01-68-353	J-L9	FD01-68-950E33	J-N10	FD01-68-870C02	J-M9	GASR-69-277 33	J-J10	FD02-69-973	J-D12
FD02-67-340	J-N8	*****		FD03-68-356	J-K9	FD05-68-950D02	J-N10	FD01-68-870D02	J-M9	FD01-69-320C02	J-L10	FD05-69-973	J-D12
FD01-67-351	J-O9			FD01-68-357	J-L9	FD05-68-950D17	J-N10	FD01-68-870E02	J-M9	FD01-69-320C17	J-L10	FD01-69-98X	J-I9
FD02-67-351	J-O9			FD01-68-371A02	J-L9	FD05-68-950D33	J-N10	FD01-68-870E17	J-M9	FD01-69-320C33	J-J10	FD01-69-981 02	J-C6
F063-67-354	J-O9			FD01-68-371A17	J-L9	FD05-68-950E02	J-N10	FD01-68-877 02	J-N9	FD03-69-320C02	J-J10	FD01-69-981 17	J-C6
FD01-67-360	J-N8	LA10-68-AA1	J-I10	FD01-68-371A33	J-L9	FD05-68-950E17	J-N10	GJ21-68-885B00	J-M9	FD03-69-320C17	J-J10	FD01-69-981 33	J-C6
FD02-67-360	J-N8	LA10-68-AA2	J-I10	FD01-68-391A02	J-L9	FD05-68-950E33	J-N10			FD03-69-320C33	J-J10	FD01-69-981A02	J-C6
FD01-67-361	J-C9	FD01-68-AB1A	J-K9	FD01-68-391A17	J-L9	FD01-68-950E02	J-N10	GJ21-68-885B02	J-M9	B316-69-361	J-N3	FD01-69-981A17	J-C6
FD01-67-362	J-C9	FD01-68-AB1B	J-K9	FD01-68-391A33	J-L9	FD01-68-9A1	J-E10	FD01-69-44XA00	J-L3	FD01-69-44XB00	J-L3	FD01-69-981A33	J-C6
FD01-67-363	J-N8	G350-68-AB1	J-K3	FD01-68-4H0 02	J-K3	FD01-68-6A2	J-E10	FD01-69-67Y	J-G10			*****	
FD02-67-363	J-N8	8467-68-AC3	J-O2	FD01-68-4H0 17	J-K3	FD01-68-6A2A02	J-D10	FD01-69-67YA	J-G10	* 70-000 *		*****	
FD01-67-364	J-C9			FD01-68-4H0 33	J-K3	FD01-68-6F6A33	J-D10	FD01-69-67YB02	J-G10			*****	
FD02-67-364	J-C9			FD01-68-41Y 00	J-K3	FD01-68-6L1A	J-D10	FD01-69-760B02	J-G10			*****	
FD01-67-366	J-E9			FD01-68-4M0A00	J-L3	FD01-68-6L2A	J-D10	FD01-69-760B17	J-G10			*****	
LA01-67-395A	J-N8	B467-68-AC3	J-17	FD01-68-4M0B00	J-L3	FD01-68-6L3A	J-D10	G030-68-885C00	J-I12	FD01-69-760B33	J-C10	FD01-70-020B	J-D13
FD01-67-402	J-O9	8467-68-AC3 33	J-M10	FD01-68-4M0C00	J-L3	FD01-68-6N6	J-E10	UB54-68-885 02	J-F10	FD01-69-760C02	J-C10	FD01-70-030C	J-E13
FD01-67-407	J-F9	FD01-68-AC3	J-G10	FD01-68-4W0 02	J-L3	FD01-68-6N7	J-E10	UB54-68-885 82	J-F10	FD01-69-760C17	J-C10		
FD01-67-421	J-E9	8499-68-AD1A	J-L5	FD01-68-4W0 17	J-L3	FD01-68-6018	J-I12	FD01-68-89X 02	J-N9	FD01-69-760C33	J-C10		
				FD01-68-4W0 33	J-L3								
FD01-67-450A	J-E9	B455-68-AD2	J-L5	H380-68-402	J-L3	B100-68-615	J-I12	FD01-68-911A02	J-F3	FD01-69-768 02	J-C10	FD01-70-030D	J-E13
FD01-67-451	J-G9	H380-68-AD3	J-K9	FD01-68-406 02	J-L3			FD01-68-912A02	J-G3	FD01-69-768 17	J-C10	FD01-70-050	J-D13
FD01-67-480B	J-L8	FD01-68-AD4A	J-K9	FD01-68-406 17	J-L3			FD01-68-930A02	J-M5	FD01-69-768 33	J-C10	FD01-70-1X1	J-E13
FD02-67-480	J-E9	FD01-68-AD4B	J-K9	FD01-68-406 33	J-L3			FD01-68-940B02	J-M5	FD01-69-768A02	J-C10	FD01-70-11Y	J-D13
FD01-67-481A	J-M8	FD01-68-DDXC00	J-K3	FD01-68-411	J-L3			FD01-68-950B02	J-M5	FD01-69-768A17	J-C10	FD01-70-11ZA	J-D13
FD02-67-481	J-F9	FD01-68-DDXD00	J-K3	FD01-68-412A	J-L3	FD01-68-63XD	J-D10	FD01-68-960B02	J-M5	FD01-69-768A33	J-C10	FD01-70-11ZB	J-D13
FD01-67-482	J-M8	FD01-68-DDYC00	J-K3	FD01-68-413A	J-M3	FD01-68-63XE	J-E10	FD01-68-960C02	J-M5	FD01-69-771A02	J-C10	FD01-70-11ZC	J-D13
FD02-67-482	J-F9	FD01-68-DDYD00	J-K3	FD01-68-414A	J-M3	FD05-68-63XD	J-D10			FD01-69-771A17	J-C10	FDY1-70-110A	J-D13
FD01-67-483	J-M8	FD01-68-DJXB	J-M3	FD01-68-420E02	J-M3	FD05-68-63XE	J-E10			FD01-69-771A33	J-C10	FD01-70-119	J-E13
FD02-67-483	J-F9	FD01-68-DJXC	J-M3	FD01-68-420E17	J-M3	FD01-68-644A	J-D10			FD01-69-781 02	J-C10	FD01-70-12XA	J-D13
FD02-67-484	J-F9	FD01-68-DJYB	J-N3	FD01-68-420E33	J-M3	FD01-68-648	J-E10			FD01-69-781 17	J-C10	FD01-70-120B	J-D13
FD01-67-492	J-F9	FD01-68-DJYC	J-N3	FD01-68-420F02	J-M3	FD05-68-648	J-E10	* 69-000 *		FD01-69-781 33	J-C10	FD01-70-130A	J-E13
FD01-67-5A0B	J-N15	FD01-68-D21	J-J9	FD01-68-420F17	J-M3	FD01-68-649A	J-D10	*****		FD01-69-810A	J-C6	FD01-70-15XB	J-F13
FD01-67-5A0C	J-N15			FD01-68-420F33	J-M3	FD01-68-670E02	J-E10			FD01-69-810B	J-C6	FD01-70-15XC	J-F13
FD0													



PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

FD01-70-242B	N-D13	FD01-76-202	N-D10	FD05-88-161	02 2-J16	99655-90030	2-H5
FD01-70-252A	N-E13	FD01-76-210	N-C10	FD05-88-161	17 2-J16	99655-90035	2-H5
FD01-70-272B	N-E13	FD01-76-250	02 2-C10	FD05-88-161	33 2-J16	99655-90040	2-H5
FD01-70-274A	N-E13	FD01-76-260	N-C10	FD01-88-162	2-N16	99655-90045	2-H5
FD01-70-311A	N-E13	FD01-76-290	N-C10	FD01-88-174	2-N16	99655-90050	2-I5
FDY1-70-400B	N-H13	FD02-76-290	N-C10	FD01-88-180	02 2-J16	99655-90055	2-I5
FD01-70-440B	N-E13	8093-76-605	N-E9	FD03-88-180	02 2-K16	99655-90060	2-I5
FD01-70-490B	N-E13	8002-76-619A	N-G9	FD05-88-180	02 2-K16	99700-5080	2-N12
0187-70-491	N-D7	8043-76-619A	N-D9	FD05-88-180	17 2-K16	99700-7180	2-N11
FD04-70-600B	N-I13	8093-76-641	N-F9	FD05-88-180	33 2-K16	99701-3270	2-N11
FD01-70-601A	N-I13	8094-76-662	N-D9	FD01-88-181	02 2-K16	99701-4278	2-N11
FD01-70-610A	N-C13	8094-76-663	N-D9	FD03-88-181	02 2-K16	99701-6030	2-E15
FD01-70-640	N-I13	8084-76-677	N-M8	FD05-88-181	02 2-K16	99701-6040	2-N15
		HA14-76-707	N-J5	FD05-88-181	17 2-K16	99701-6049	2-N11
FD01-70-651A	N-D13	HD01-76-714	N-J5	FD05-88-181	33 2-K16	99701-6050	2-N12
FD01-70-661	N-I13	HD01-76-717	N-J5	FD01-88-6D0	02 2-K16		
FD01-70-700B	N-I13	8001-76-725	N-E5	FD03-88-6D0	02 2-K16		
			N-O5	FD05-88-6D0	02 2-K16		
FD01-70-750C	N-F13	8001-76-734	N-E5	FD05-88-6D0	17 2-K16	99703-4350	2-E11
			N-O5	FD05-88-6D0	33 2-K16	99703-8605	2-M10
*****		*****		FD01-88-6D2	02 2-K16	99705-1115	3-C8
* 71-000 *		* 88-000 *		FD03-88-6D2	02 2-L16		3-H8
*****		*****		FD05-88-6D2	02 2-L16	99705-1130	3-C8
				FD05-88-6D2	17 2-L16		3-H8
FD01-71-020B	N-F13	FD01-88-005	N-H16	FD05-88-6D2	33 2-L16	99963-6930	1-J7
FD01-71-030C	N-G13	FD01-88-004	N-H16	8456-88-815	2-L16	99963-6940	1-J7
FD01-71-030D	N-G13	FD01-88-062	N-G16	B260-88-818	2-L16	99963-6950	1-J7
FD01-71-050	N-F13	FD01-88-072	N-G16	EA01-88-818	2-L16	99963-6960	1-J7
FD01-71-180A	N-F13	FD01-88-073	N-G16	*****		99963-6970	1-J7
FD01-71-100	N-F13	FD01-88-101	02 2-G16	* 90-000 *			
FD01-71-1X1	N-G13	FD01-88-101	17 2-G16	*****			
FD01-71-11Y	N-F13	FD01-88-101	43 2-G16	90620-17636	2-H5		
FD01-71-11Z	N-F13	FD01-88-105	02 2-G16	90620-55726	2-H5		
FD01-71-11ZB	N-F13	FD01-88-105	17 2-G16	90620-75726	2-H5		
FDY1-71-11ZC	N-F13	FD01-88-103	02 2-G16	90621-65726	2-H5		
FD01-71-110A	N-F13	FD01-88-103	17 2-G16	90621-85726	2-H5		
FD01-71-119	N-F13	FD01-88-106	N-H16				
FD01-71-120B	N-F13	FD01-88-106	N-H16	90622-65726	2-H5		
		FD01-88-108	N-H16	90701-7270	2-E11		
FD01-71-131A	N-E13	FD01-88-110	02 2-H16	*****			
FD01-71-15XB	N-H13	FD03-88-110	02 2-H16	* 99-000 *			
FD01-71-15XC	N-H13	FD05-88-110	02 2-H16	*****			
FD01-71-15XD	N-H13	FD05-88-110	17 2-H16	99236-0571	1-J3		
FD01-71-150C	N-G13	FD05-88-110	33 2-H16	99324-07200	1-L6		
FD01-71-150D	N-G13	FD05-88-110	17 2-H16	99324-07400	1-L6		
FD01-71-150E	N-G13	FD01-88-111	02 2-H16	99328-04010	3-F9		
FDY1-71-200	N-G13	FD03-88-111	02 2-I16	99340-05540	1-H9		
FD01-71-230A	N-G13	FD05-88-111	02 2-I16	99351-04999	1-E6		
FDY1-71-24X	N-G13	FD05-88-111	17 2-I16	99351-06999	2-C7		
FDY4-71-24X	N-G13	FD05-88-111	33 2-I16	99351-08999	1-I4		
FD01-71-242B	N-D13	FD01-88-112	2-N16	99359-0814	1-I4		
FD01-71-252A	N-G13	FD01-88-124	2-F16	99359-0815	2-F8		
FD01-71-272B	N-G13						
FD01-71-274A	N-G13	FD01-88-130	02 2-I16	99359-0815M	2-H8		
FD01-71-311A	N-G13	FD03-88-130	02 2-I16	99359-0819	2-F8		
FDY1-71-400B	N-H13	FD05-88-130	02 2-I16	99541-00603	2-I7		
FD01-71-440B	N-G13	FD05-88-130	17 2-I16	99541-01105	1-K3		
FD01-71-490B	N-G13	FD05-88-130	33 2-I16	99541-01201	1-J9		
FD01-71-651A	N-F13	FD01-88-131	02 2-I16	99541-01252	1-J4		
		FD03-88-131	02 2-I16	99541-01401	2-K4		
*****		FD05-88-131	02 2-I16	99541-01601	1-D6		
* 76-000 *		FD05-88-131	17 2-I16		1-M9		
*****		FD05-88-131	33 2-I16	99606-23030	1-M6		
0208-76-071	3-F9	FD01-88-152	2-J16	99611-2500	1-O8		
	3-F10	FD01-88-153	2-J16	99636-04130	2-H5		
FD01-76-120 J9	3-H10	FD01-88-155	2-I16	99650-28060	2-I5		
FD01-76-120 M8	3-H10	FD01-88-160	02 2-J16	99650-58060	2-I5		
FD01-76-120 NU	3-H10	FD03-88-160	02 2-J16	99651-94060	2-I5		
FD01-76-120 PZ	3-H10	FD05-88-160	02 2-J16	99655-90005	2-H5		
FD01-76-120 3L	3-H10	FD05-88-160	17 2-J16	99655-90010	2-H5		
FD01-76-180 J9	3-H10	FD05-88-160	33 2-J16	99655-90015	2-H5		
FD01-76-180 M8	3-H10	FD01-88-161	02 2-J16	99655-90020	2-H5		
FD01-76-180 NU	3-H10	FD03-88-161	02 2-J16	99655-90025	2-H5		
FD01-76-180 PZ	3-H10						
FD01-76-180 3L	3-H10						
FD01-76-190	2-D10						
FD01-76-201	2-D10						

ALPHABETICAL INDEX MM# ENGLISH MM#

***** A *****	BEARING, PINION----- 2-J3 2-K3 1-J7 2-E3 1-M6 2-K7 2-N7 2-M16 2-M16 2-M16 1-M9 1-C8 1-H8 1-M6 3-C11 3-C11 3-D10 3-N8 3-N8 3-N8 3-E9 3-G7 3-K7 3-C8 3-D8 3-C9 3-C9 2-D5 2-C5 2-D5 2-C5 3-E4 3-E4 3-E9 3-N8 3-N8 1-L8 3-E5 3-G5	BOLT, COMPRESSOR-AIR CON.- 3-D5 3-F5 BOLT, CONNECTOR----- 1-D6 2-H6 2-H7 2-K7 2-N7 BOLT, CONTROL VALVE----- 1-E10 1-M9 BOLT, DAMPER-REAR----- 2-L4 BOLT, DUST COVER----- 2-M6 BOLT, FLANGE----- 1-H8 BOLT, FUEL DISTRIBUTOR----- 1-C4 BOLT, FUEL INJECTION PUMP----- 1-J4 BOLT, HUB----- 2-F3 2-L4 2-C15 3-C7 1-E4 2-C14 2-H6 2-F16 1-C6 3-E5 3-O5 2-D11 2-K13 2-L12 1-M9 1-J3 2-E3 2-C8 2-K3 1-C6 2-C10 3-D3 3-D3 2-H4 2-F11 2-N12 1-H3 2-M12 2-F4 2-H12 2-D3 2-D3 2-D5 2-C5 2-L5 1-E8 2-D11 2-L4 2-G4 2-L12 2-L12 1-C9 3-C7 2-H15 3-E8 3-C10 3-G10 BRACKET----- 1-F10 1-G9 1-K6 2-L7 3-D7 2-N7 2-N7 2-H3 2-G16 2-G13 2-G11 3-L9 3-M10 2-H10 3-K7 3-E11 2-H13 3-M9 2-H3 2-G11 2-F16 2-E13	BRACKET(R), LOWER-F. SIDE-- 3-K9 BRACKET(R), QUARTER TRIM-- 3-M10 BRACKET(R), RR. BUMPER----- 2-H10 BRACKET(R), SPOILER----- 3-E11 BRACKET(R), TRIM-QTR PANEL 2-E13 BRACKET(R), TRUNK SIDE----- 3-M9 BRACKET(R), TUNER----- 3-G7 BRACKET, A. C. C.----- 3-F7 BRACKET, A. C. C. BOX----- 3-C7 BRACKET, ACCEL CABLE----- 1-N3 1-N9 1-N3 3-C3 1-L4 1-M4 3-I6 2-H7 1-L8 2-O15 2-G15 1-M6 3-K4 3-N4 2-M15 3-J6 2-F4 1-F8 3-J7 3-F8 1-C4 2-L13 BRACKET, FRONT----- 2-E11 BRACKET, HANGER----- 2-E6 BRACKET, HARNESS----- 3-C8 3-D8 3-G8 2-M10 3-F8 2-K7 1-D4 2-N11 2-D11 3-F6 BRACKET, OIL PIPE----- 1-F9 BRACKET, OVERHEAD CONSOLE-- 1-G9 BRACKET, PIPE----- 1-M8 BRACKET, REAR----- 3-G7 BRACKET, REAR FINISHER----- 2-I11 BRACKET, RELAY----- 3-D7 BRACKET, STABILIZER----- 2-G5 BRACKET, STOPPER----- 2-D7 BRACKET, SUN ROOF-FRONT----- 3-F6 BRACKET, TANK----- 3-K4 BRACKET, TRIM----- 3-L3 3-M3 1-E10 1-F10 1-H4 3-H8 2-J3 1-D9 1-H7 1-C5 2-M12 2-M12 3-K9 3-J7 3-K7 1-L8 1-N8 2-C12 2-C13 3-E11 2-E15 2-F15 2-G15 3-H11 3-I11 2-L13 2-M10	BULB----- 3-L6 BULB & SOCKET----- 2-A15 BULB, INTERIOR MIRROR----- 2-D12 2-H11 2-N11 3-G4 3-G7 2-C5 2-H10 2-H10 1-C7 1-G8 1-K11 1-M6 2-E7 2-H6 1-E8 2-F4 2-F4 2-I7 2-H16 3-G9 3-F9 2-F4 2-D5 2-D4 2-F5 2-E4 2-D5 2-F4 2-D5 1-L8 2-G4 2-G4 ***** * C * ***** CABLE(L), R.-PARK----- 2-E8 CABLE(R), R.-PARK----- 2-E8 CABLE, ACCEL----- 2-K6 CABLE, OPENER----- 2-D7 CABLE, PARKING-FRT----- 2-F8 CALIPER(L), FRT BRAKE----- 2-M4 CALIPER(L), PADLESS-FR----- 2-M4 CALIPER(L), PADLESS-RR----- 2-I3 CALIPER(L), RR BRAKE----- 2-H3 CALIPER(L), FRT BRAKE----- 2-M4 CALIPER(R), PADLESS-FR----- 2-M4 CALIPER(R), PADLESS-RR----- 2-H3 CALIPER(R), RR BRAKE----- 2-H3 CAM, FIRST IDLE----- 1-C5 CANISTER----- 1-14 CAP----- 1-E3 2-D7 2-E5 2-F12 2-G4 2-M13 3-D10 3-J7 3-K8 2-H7 3-M9 3-M9 3-K3 2-I3 1-I5 1-N3 1-H3 2-H5 3-I3 2-M4 2-L4 1-D3 3-L6 1-K6 2-M4 3-E9 1-G7 1-L6 3-F9			
ACTUATOR, A. C. C.----- 3-F7 ACTUATOR, EXHAUST VALVE----- 1-C4 ACTUATOR, MODE-HEATER UNIT 1-H4 ACTUATOR, RECYCLE & FRESH- 1-E4 ACTUATOR, TEMP----- 1-E4 ADAPTER, SUN VISOR----- 1-J10 ADJUSTER NO. 3----- 1-J16 ADJUSTER NO. 4----- 1-J16 ADJUSTER, NO. 1----- 1-H16 ADJUSTER, NO. 2----- 1-H16 ALTERNATOR----- 1-L8 AMP, POWER-FRONT----- 3-G7 ANTENNA, RADIO----- 3-K7 ANTILOCK BRAKE----- 3-C8 3-D8 3-C9 3-C9 2-D5 2-C5 2-D5 2-C5 3-E4 3-E4 3-E9 3-N8 3-N8 1-L8 3-E5 3-G5	BEARING, ROLLER----- 1-J7 BEARING, WHEEL----- 2-E3 BELT, V----- 1-M6 BELT 'A' (L), FRT SEAT----- 2-M16 BELT 'A' (R), FRT SEAT----- 2-M16 BELT 'B' (L), FRT SEAT----- 2-M16 BELT 'B' (R), FRT SEAT----- 1-M9 BELT 'V'----- 1-C8 1-H8 1-M6 3-C11 3-C11 3-D10 3-N8 3-N8 3-N8 3-E9 3-G7 3-K7 3-C8 3-D8 3-C9 3-C9 2-D5 2-C5 2-D5 2-C5 3-E4 3-E4 3-E9 3-N8 3-N8 1-L8 3-E5 3-G5	BOLT SET----- 1-M7 1-M8 2-H7 3-J6 1-F8 1-M6 2-D5 2-F4 1-L4 3-K4 3-N4 1-J9 2-M4 1-C9 2-M4 1-K3 1-K3 1-K7 1-L7 1-L10 1-M7	BOLT, AIR CLEANER----- 1-L4 BOLT, AIR CON.----- 3-K4 3-N4 1-J9 2-M4 1-C9 2-M4 1-K3 1-K3 1-K7 1-L7 1-L10 1-M7	BRACKET & RELAY----- 3-D7 BRACKET NO 1, A. B. S.----- 2-N7 BRACKET NO 2, A. B. S.----- 2-N7 BRACKET(L), CABLE----- 2-H3 BRACKET(L), FRT SEAT----- 2-G16 BRACKET(L), LAMP----- 2-G13 BRACKET(L), LAMP-F. FOG----- 2-G11 BRACKET(L), LOWER-F. SIDE-- 3-L9 BRACKET(L), QUARTER TRIM-- 3-M10 BRACKET(L), RR. BUMPER----- 2-H10 BRACKET(L), SPEAKER----- 3-K7 BRACKET(L), SPOILER----- 3-E11 BRACKET(L), TRIM-QTR PANEL 2-H13 BRACKET(L), TRUNK SIDE----- 3-M9 BRACKET(L), UPPER-F. SIDE-- 3-K9 BRACKET(R), CABLE----- 2-H3 BRACKET(R), F. FOG LAMP----- 2-G11 BRACKET(R), FRT SEAT----- 2-F16 BRACKET(R), LAMP----- 2-E13	BLOWER UNIT----- 3-F8 BOARD(C), TRUNK----- 3-F10 BOARD, PARTITION----- 3-F10 BODY & PISTON(L), CALIPER-- 2-O3 2-O3 3-D3 3-D3 1-J6 3-K5 1-E10 1-D6 1-D5 1-H10 1-D7 1-D9 1-D10 1-E9 1-E10 1-F7 1-F9 1-G9 1-G11 1-I7 1-J9 1-J11 1-L9 1-M8 1-M9 1-N3 2-C3 2-C5 2-C6 2-C14 2-D5 2-E4 2-E10 2-F6 2-G5 2-G16 2-H3 2-H4 2-J3 2-K3 2-L16 3-G10 1-M7 1-M8 2-H7 3-J6 1-F8 1-M6 2-D5 2-F4 1-L4 3-K4 3-N4 1-J9 2-M4 1-C9 2-M4 1-K3 1-K3 1-K7 1-L7 1-L10 1-M7	BRACKET, CENTER PANEL----- 2-O15 BRACKET, COMPRESSOR----- 1-M6 BRACKET, CONDENSER----- 3-N4 BRACKET, CONSOLE-NO. 3----- 2-M15 BRACKET, CONTROL UNIT----- 3-J6 BRACKET, DIFF. MOUNTING----- 2-F4 BRACKET, DIST. MODULE----- 1-F8 BRACKET, DUCT SPEAKER----- 3-J7 BRACKET, ENGINE HARNESS----- 3-F8 BRACKET, EX. MANIFOLD----- 1-C4 BRACKET, FLOOR----- 2-L13 BRACKET, FRONT----- 2-E11 BRACKET, FRONT COMB. LAMP-- 2-E6 BRACKET, HANGER----- 3-C8 BRACKET, HARNESS----- 3-D8 BRACKET, HEAD LAMP----- 2-M10 BRACKET, HOLE-ENG. WIRING-- 3-F8 BRACKET, HOSE----- 2-K7 BRACKET, INTER COOLER----- 1-D4 BRACKET, LICENCE LAMP----- 2-D11 BRACKET, MOTOR----- 3-F6 BRACKET, OIL COOLER----- 1-I6 3-C8 1-F9 1-G9 1-M8 3-G7 2-I11 3-D7 2-G5 2-D7 3-F6 3-K4 3-L3 3-M3 1-E10 1-F10 1-H4 3-H8 2-J3 1-D9 1-H7 1-C5 2-M12 2-M12 3-K9 3-J7 3-K7 1-L8 1-N8 2-C12 2-C13 3-E11 2-E15 2-F15 2-G15 3-H11 3-I11 2-L13 2-M10	BUSH----- 1-C7 1-G8 1-K11 1-M6 2-E7 2-H6 1-E8 2-F4 2-F4 2-I7 2-H16 3-G9 3-F9 2-F4 2-D5 2-D4 2-F5 2-E4 2-D5 2-F4 2-D5 1-L8 2-G4 2-G4 ***** * C * ***** CABLE(L), R.-PARK----- 2-E8 CABLE(R), R.-PARK----- 2-E8 CABLE, ACCEL----- 2-K6 CABLE, OPENER----- 2-D7 CABLE, PARKING-FRT----- 2-F8 CALIPER(L), FRT BRAKE----- 2-M4 CALIPER(L), PADLESS-FR----- 2-M4 CALIPER(L), PADLESS-RR----- 2-I3 CALIPER(L), RR BRAKE----- 2-H3 CALIPER(L), FRT BRAKE----- 2-M4 CALIPER(R), PADLESS-FR----- 2-M4 CALIPER(R), PADLESS-RR----- 2-H3 CALIPER(R), RR BRAKE----- 2-H3 CAM, FIRST IDLE----- 1-C5 CANISTER----- 1-14 CAP----- 1-E3 2-D7 2-E5 2-F12 2-G4 2-M13 3-D10 3-J7 3-K8 2-H7 3-M9 3-M9 3-K3 2-I3 1-I5 1-N3 1-H3 2-H5 3-I3 2-M4 2-L4 1-D3 3-L6 1-K6 2-M4 3-E9 1-G7 1-L6 3-F9
ARM NO. 1, LINK----- 3-C9 ARM NO. 2, LINK----- 3-C9 ARM(L), LOWER----- 2-D5 ARM(L), UPPER----- 2-C5 ARM(R), LOWER----- 2-D5 ARM(R), UPPER----- 2-C5 ARM, LOWER-REAR----- 3-E4 ARM, UPPER-REAR----- 3-E4 ARM, WIPER----- 3-E9 ARM, WIPER-CO DRIVER SIDE-- 3-N8 ARM, WIPER-DRIVER SIDE----- 3-N8 ARMATURE----- 1-L8 ARMATURE, MAGNETIC CLUTCH-- 3-E5 3-G5	BOARD(C), TRUNK----- 3-F10 BOARD, PARTITION----- 3-F10 BODY & PISTON(L), CALIPER-- 2-O3 2-O3 3-D3 3-D3 1-J6 3-K5 1-E10 1-D6 1-D5 1-H10 1-D7 1-D9 1-D10 1-E9 1-E10 1-F7 1-F9 1-G9 1-G11 1-I7 1-J9 1-J11 1-L9 1-M8 1-M9 1-N3 2-C3 2-C5 2-C6 2-C14 2-D5 2-E4 2-E10 2-F6 2-G5 2-G16 2-H3 2-H4 2-J3 2-K3 2-L16 3-G10 1-M7 1-M8 2-H7 3-J6 1-F8 1-M6 2-D5 2-F4 1-L4 3-K4 3-N4 1-J9 2-M4 1-C9 2-M4 1-K3 1-K3 1-K7 1-L7 1-L10 1-M7	BRACKET, CENTER PANEL----- 2-O15 BRACKET, COMPRESSOR----- 1-M6 BRACKET, CONDENSER----- 3-N4 BRACKET, CONSOLE-NO. 3----- 2-M15 BRACKET, CONTROL UNIT----- 3-J6 BRACKET, DIFF. MOUNTING----- 2-F4 BRACKET, DIST. MODULE----- 1-F8 BRACKET, DUCT SPEAKER----- 3-J7 BRACKET, ENGINE HARNESS----- 3-F8 BRACKET, EX. MANIFOLD----- 1-C4 BRACKET, FLOOR----- 2-L13 BRACKET, FRONT----- 2-E11 BRACKET, FRONT COMB. LAMP-- 2-E6 BRACKET, HANGER----- 3-C8 BRACKET, HARNESS----- 3-D8 BRACKET, HEAD LAMP----- 2-M10 BRACKET, HOLE-ENG. WIRING-- 3-F8 BRACKET, HOSE----- 2-K7 BRACKET, INTER COOLER----- 1-D4 BRACKET, LICENCE LAMP----- 2-D11 BRACKET, MOTOR----- 3-F6 BRACKET, OIL COOLER----- 1-I6 3-C8 1-F9 1-G9 1-M8 3-G7 2-I11 3-D7 2-G5 2-D7 3-F6 3-K4 3-L3 3-M3 1-E10 1-F10 1-H4 3-H8 2-J3 1-D9 1-H7 1-C5 2-M12 2-M12 3-K9 3-J7 3-K7 1-L8 1-N8 2-C12 2-C13 3-E11 2-E15 2-F15 2-G15 3-H11 3-I11 2-L13 2-M10	BUSHING, LOWER ARM----- 2-F4 BUSHING, RUBBER----- 2-D5 BUSHING, RUBBER-FRT----- 2-D5 BUTTON(L), HORN----- 2-G4 BUTTON(R), HORN----- 2-G4 ***** * C * ***** CABLE(L), R.-PARK----- 2-E8 CABLE(R), R.-PARK----- 2-E8 CABLE, ACCEL----- 2-K6 CABLE, OPENER----- 2-D7 CABLE, PARKING-FRT----- 2-F8 CALIPER(L), FRT BRAKE----- 2-M4 CALIPER(L), PADLESS-FR----- 2-M4 CALIPER(L), PADLESS-RR----- 2-I3 CALIPER(L), RR BRAKE----- 2-H3 CALIPER(L), FRT BRAKE----- 2-M4 CALIPER(R), PADLESS-FR----- 2-M4 CALIPER(R), PADLESS-RR----- 2-H3 CALIPER(R), RR BRAKE----- 2-H3 CAM, FIRST IDLE----- 1-C5 CANISTER----- 1-14 CAP----- 1-E3 2-D7 2-E5 2-F12 2-G4 2-M13 3-D10 3-J7 3-K8 2-H7 3-M9 3-M9 3-K3 2-I3 1-I5 1-N3 1-H3 2-H5 3-I3 2-M4 2-L4 1-D3 3-L6 1-K6 2-M4 3-E9 1-G7 1-L6 3-F9				
AUDIO SET----- 3-G7 ***** * B * *****	BACK(C), FRT SEAT----- 2-K16 BACK(L), FRT SEAT----- 2-J16 2-K16 2-I16 2-C13 2-F12 1-G7 2-E4 1-D8 1-M8 3-N4 2-N6 2-N6 1-C9 1-L10 2-K12 3-I10 3-H10 3-N5 1-C9 1-M6 2-G3 2-K3 2-L4 1-L7 1-I8 1-I8 1-J7 1-J7 2-M10 1-D11 1-F11 1-G11 1-H11 1-J3 1-K3 1-K3 1-K7 1-L7 1-L10 1-M7	BOLT, SETTING-HINGE LOWER-- 3-D3 BOLT, SHAFT----- 2-H4 BOLT, SPECTAL----- 2-F11 BOLT, STRUT BAR----- 2-N12 BOLT, TENSION----- 1-H3 BOLT, TIE DOWN HOOK-FRONT-- 2-M12 BOLT 'A', LINK----- 2-F4 BONNET----- 2-H12 BOOT SET, INNER JOINT----- 2-D3 BOOT SET, OUTER JOINT----- 2-D3 BOOT, BALL JOINT-LWR ARM----- 2-D5 BOOT, BALL JOINT-UP. ARM----- 2-C5 BOOT, CHANGE----- 2-L5 BOOT, DUST-CHANGE LEVER----- 1-E8 BOOT, MOTOR-RETRACT H/L----- 2-D11 BOOT, RACK----- 2-L4 BOSS, STEERING WHEEL----- 2-G4 BOX(L), TORQUE----- 2-L12 BOX(R), TORQUE----- 2-L12 BOX, BATTERY----- 1-C9 BOX, CONTROL-A. B. S.----- 3-C7 BOX, GLOVE----- 2-H15 BOX, RELAY-FRONT HARNESS-- 3-E8 BOX, STORAGE----- 3-C10 BOX, TOOL----- 3-G10 BRACKET----- 1-F10 1-G9 1-K6 2-L7 3-D7 2-N7 2-N7 2-H3 2-G16 2-G13 2-G11 3-L9 3-M10 2-H10 3-K7 3-E11 2-H13 3-M9 2-H3 2-G11 2-F16 2-E13	BRACKET, CENTER PANEL----- 2-O15 BRACKET, COMPRESSOR----- 1-M6 BRACKET, CONDENSER----- 3-N4 BRACKET, CONSOLE-NO. 3----- 2-M15 BRACKET, CONTROL UNIT----- 3-J6 BRACKET, DIFF. MOUNTING----- 2-F4 BRACKET, DIST. MODULE----- 1-F8 BRACKET, DUCT SPEAKER----- 3-J7 BRACKET, ENGINE HARNESS----- 3-F8 BRACKET, EX. MANIFOLD----- 1-C4 BRACKET, FLOOR----- 2-L13 BRACKET, FRONT----- 2-E11 BRACKET, FRONT COMB. LAMP-- 2-E6 BRACKET, HANGER----- 3-C8 BRACKET, HARNESS----- 3-D8 BRACKET, HEAD LAMP----- 2-M10 BRACKET, HOLE-ENG. WIRING-- 3-F8 BRACKET, HOSE----- 2-K7 BRACKET, INTER COOLER----- 1-D4 BRACKET, LICENCE LAMP----- 2-D11 BRACKET, MOTOR----- 3-F6 BRACKET, OIL COOLER----- 1-I6 3-C8 1-F9 1-G9 1-M8 3-G7 2-I11 3-D7 2-G5 2-D7 3-F6 3-K4 3-L3 3-M3 1-E10 1-F10 1-H4 3-H8 2-J3 1-D9 1-H7 1-C5 2-M12 2-M12 3-K9 3-J7 3-K7 1-L8 1-N8 2-C12 2-C13 3-E11 2-E15 2-F15 2-G15 3-H11 3-I11 2-L13 2-M10	BUSHING, LOWER ARM----- 2-F4 BUSHING, RUBBER----- 2-D5 BUSHING, RUBBER-FRT----- 2-D5 BUTTON(L), HORN----- 2-G4 BUTTON(R), HORN----- 2-G4 ***** * C * ***** CABLE(L), R.-PARK----- 2-E8 CABLE(R), R.-PARK----- 2-E8 CABLE, ACCEL----- 2-K6 CABLE, OPENER----- 2-D7 CABLE, PARKING-FRT----- 2-F8 CALIPER(L), FRT BRAKE----- 2-M4 CALIPER(L), PADLESS-FR----- 2-M4 CALIPER(L), PADLESS-RR----- 2-I3 CALIPER(L), RR BRAKE----- 2-H3 CALIPER(L), FRT BRAKE----- 2-M4 CALIPER(R), PADLESS-FR----- 2-M4 CALIPER(R), PADLESS-RR----- 2-H3 CALIPER(R), RR BRAKE----- 2-H3 CAM, FIRST IDLE----- 1-C5 CANISTER----- 1-14 CAP----- 1-E3 2-D7 2-E5 2-F12 2-G4 2-M13 3-D10 3-J7 3-K8 2-H7 3-M9 3-M9 3-K3 2-I3 1-I5 1-N3 1-H3 2-H5 3-I3 2-M4 2-L4 1-D3 3-L6 1-K6 2-M4 3-E9 1-G7 1-L6 3-F9			

ALPHABETICAL INDEX MM ENGLISH MM

CAP, TANK-----3-M8  
 CAP, VANE PUMP TANK-----2-K4  
 CAP, WATER INLET-THERMO C.-----1-K6  
 CARRIER, DIFFERENTIAL-----2-K3  
 CARRIER, FRONT-----1-D11  
 CARRIER, REAR-----1-E11  
 CARTRIDGE OIL FILTER-----1-D6  
 CASE(L), BLOWER-----1-H4  
 CASE(L), HEATER UNIT-----1-E4  
 CASE(R), BLOWER-----1-H4  
 CASE(R), HEATER UNIT-----1-E4  
 CASE, CHANGE CONTROL-----1-E8  
 CASE, HEATER-----1-E4  
 CASE, LAMP-----1-C15  
 CASE, METER-----1-F9  
 CASE, RELAY BOX-----1-F7  
 CASE, T/MISSION-----1-F9  
 CASE, WARNING UNIT-----1-E15  
 CASE 'A', COOLING UNIT-----1-H5  
 CASE 'B', COOLING UNIT-----1-H5  
 CASE 'C', COOLING UNIT-----1-E15  
 CASE 'C', HEATER UNIT-----1-E4  
 CATALYST, TREE WAY-----3-N9  
 CEILING, TOP-----3-N9  
 CHAIN, OIL PUMP-----1-C6  
 CHAMBER, EXTRACTOR-----2-G12  
 CHAMBER, VACUUM-----1-K5  
 CHANGE COMPLETE-----1-E3  
 CHANNEL(L), GLASS-----1-E3  
 CHANNEL(R), GLASS-----1-E3  
 CHARGE, AIR COOLER-----1-D4  
 CHECKER, DOOR-----1-H3  
 CLAMP-----1-K4  
 CLAMP, BATTERY-----1-C9  
 CLAMP, HOSE-----1-E5  
 CLAMP, SPARE TIRE-----1-I5  
 CLAMP, WATER HOSE-----1-J6  
 CLIP-----1-F7  
 CLIP, AIR BAG-----2-M7  
 CLIP, BELTLINE MOULD-----3-C3  
 CLIP, C.S.D. WIRE-----2-E7  
 CLIP, COOLING UNIT-----3-15  
 CLIP, DRAIN HOSE-REAR-----3-E6  
 CLIP, DRAIN HOSE-SUN ROOF-----3-E6  
 CLIP, FENDER GRILLE-----2-G12  
 CLIP, FLEXIBLE HOSE-----2-J6  
 CLIP, HARNESS-----1-E10  
 CLIP, HEATER UNIT-----1-E4  
 CLIP, HOSE-----1-M4  
 CLIP, HOSE-SUB T. & WATER H-----1-L6  
 CLIP, M. OIL TUBE-----1-M6  
 CLIP, MUD GUARD-----2-M12  
 CLIP, OIL TUBE-----1-H6  
 CLIP, PARKING CABLE-----2-E6  
 CLIP, PIPE-----2-O8  
 CLIP, PROTECTOR-----3-C8  
 CLIP, RR BRAKE PIPE-----2-H12  
 CLIP, RR WINDOW MOULD-----2-J10  
 CLIP, SCUFF PLATE-----3-K9  
 CLIP, SLIDE-----3-L5  
 CLIP, SPOILER-----3-E11  
 CLIP, STEP MOULD-----2-F12  
 CLIP, TOP CEILING-----3-H9  
 CLIP, TRIM-----3-C11  
 CLIP, WASHER HOSE-----3-E9  
 CLIP, WIRE-BONNET-----2-I12  
 CLIP 'A', BELTLINE MOULD-----2-K10  
 CLUTCH-----2-D3  
 CLUTCH & ONE WAY-----2-E8  
 CLUTCH, HIGH-----2-E10  
 CLUTCH, MAGNET-----2-F8  
 CLUTCH, ONE WAY-----2-P12  
 CLUTCH, REAR-----2-G11  
 CLUTCH, REVERSE-----2-G12  
 COCK, DRAIN-----2-G16  
 COIL, FIELD-MAGNET CLUTCH-----2-J15  
 COIL, IGNITION-LEADING-----2-K4  
 COIL, IGNITION-TRAILING-----2-K10  
 COLLAR-----2-N10  
 COLLAR, CLUTCH REL.-----3-C3  
 COLLAR, COMP. BRKT-----3-C6  
 COLLAR, WEDGE-----3-D4  
 COMPRESSOR-----3-E6  
 COMPRESSOR, AIR CON.-----3-H3  
 CONDENSER-----3-H10  
 CONNECTOR, HOSE-----3-Y3  
 CONNECTOR, HOSE-----3-I6  
 CONNECTOR, HOSE-----3-J3  
 CONNECTOR, HOSE-----3-L4  
 CONNECTOR, HOSE-----3-L5  
 CONNECTOR, HOSE-----3-K4  
 CONNECTOR, OIL COOLER-----3-K5  
 CONNECTOR, SHORT-----3-K8  
 CONNECTOR, WATER HOSE-----3-L7  
 CONSOLE, OVERHEAD-----3-L8  
 CONSOLE, REAR-----3-L9  
 CONTROL UNIT-----3-M4  
 CONTROL UNIT-----3-N4  
 CONTROL UNIT-----3-N4  
 CONTROL UNIT-----3-H3  
 CONTROL UNIT-----3-J4  
 CONVERTER, CATALYST-----3-D3  
 CONVERTER, TORQUE-----2-D3

CLIP, AIR BAG-----2-M7  
 CLIP, BELTLINE MOULD-----3-C3  
 CLIP, C.S.D. WIRE-----2-E7  
 CLIP, COOLING UNIT-----3-15  
 CLIP, DRAIN HOSE-REAR-----3-E6  
 CLIP, DRAIN HOSE-SUN ROOF-----3-E6  
 CLIP, FENDER GRILLE-----2-G12  
 CLIP, FLEXIBLE HOSE-----2-J6  
 CLIP, HARNESS-----1-E10  
 CLIP, HEATER UNIT-----1-E4  
 CLIP, HOSE-----1-M4  
 CLIP, HOSE-SUB T. & WATER H-----1-L6  
 CLIP, M. OIL TUBE-----1-M6  
 CLIP, MUD GUARD-----2-M12  
 CLIP, OIL TUBE-----1-H6  
 CLIP, PARKING CABLE-----2-E6  
 CLIP, PIPE-----2-O8  
 CLIP, PROTECTOR-----3-C8  
 CLIP, RR BRAKE PIPE-----2-H12  
 CLIP, RR WINDOW MOULD-----2-J10  
 CLIP, SCUFF PLATE-----3-K9  
 CLIP, SLIDE-----3-L5  
 CLIP, SPOILER-----3-E11  
 CLIP, STEP MOULD-----2-F12  
 CLIP, TOP CEILING-----3-H9  
 CLIP, TRIM-----3-C11  
 CLIP, WASHER HOSE-----3-E9  
 CLIP, WIRE-BONNET-----2-I12  
 CLIP 'A', BELTLINE MOULD-----2-K10  
 CLUTCH-----2-D3  
 CLUTCH & ONE WAY-----2-E8  
 CLUTCH, HIGH-----2-E10  
 CLUTCH, MAGNET-----2-F8  
 CLUTCH, ONE WAY-----2-P12  
 CLUTCH, REAR-----2-G11  
 CLUTCH, REVERSE-----2-G12  
 COCK, DRAIN-----2-G16  
 COIL, FIELD-MAGNET CLUTCH-----2-J15  
 COIL, IGNITION-LEADING-----2-K4  
 COIL, IGNITION-TRAILING-----2-K10  
 COLLAR-----2-N10  
 COLLAR, CLUTCH REL.-----3-C3  
 COLLAR, COMP. BRKT-----3-C6  
 COLLAR, WEDGE-----3-D4  
 COMPRESSOR-----3-E6  
 COMPRESSOR, AIR CON.-----3-H3  
 CONDENSER-----3-H10  
 CONNECTOR, HOSE-----3-Y3  
 CONNECTOR, HOSE-----3-I6  
 CONNECTOR, HOSE-----3-J3  
 CONNECTOR, HOSE-----3-L4  
 CONNECTOR, HOSE-----3-L5  
 CONNECTOR, HOSE-----3-K4  
 CONNECTOR, OIL COOLER-----3-K5  
 CONNECTOR, SHORT-----3-K8  
 CONNECTOR, WATER HOSE-----3-L7  
 CONSOLE, OVERHEAD-----3-L8  
 CONSOLE, REAR-----3-L9  
 CONTROL UNIT-----3-M4  
 CONTROL UNIT-----3-N4  
 CONTROL UNIT-----3-N4  
 CONTROL UNIT-----3-H3  
 CONTROL UNIT-----3-J4  
 CONVERTER, CATALYST-----3-D3  
 CONVERTER, TORQUE-----2-D3

COOLER, OIL-----1-F9  
 CORD-----1-G9  
 CORD-----1-H6  
 CORD-----3-E8  
 CORD SET, HI. TENSION-----3-K7  
 CORD, EARTH-----1-G8  
 CORD, EARTH-RADIO-----3-M7  
 CORD, HIGH TENSION-----1-G3  
 CORD, HIGH TENSION (L-1)-----1-G8  
 CORD, HIGH TENSION (L-2)-----1-G8  
 CORD, HIGH TENSION (T-1)-----1-G8  
 CORD, HIGH TENSION (T-2)-----1-G8  
 CORD, LAMP-----2-L11  
 CORD, SHORT-----3-D8  
 CORE, HEATER-----3-E4  
 COVER-----3-C8  
 COVER NO. 1, ADJ-FRT-----2-F16  
 COVER NO. 1, SIDE-F. SEAT-----2-G16  
 COVER NO. 4, SIDE-F. SEAT-----2-G16  
 COVER SET-----1-M8  
 COVER(L), BUMPER-----2-G10  
 COVER(L), DUST-----2-L4  
 COVER(L), FOG LAMP-----2-G11  
 COVER(L), GLOVE-----2-H15  
 COVER(L), QTR. TRIM-----3-C11  
 COVER(L), RETRACTOR-----2-N16  
 COVER(L), RR COMB.-----2-K11  
 COVER(L), SIDE-----2-I15  
 COVER(L), TRUNK SIDE-----3-N9  
 COVER(R), BUMPER-----2-E10  
 COVER(R), DUST-----2-L4  
 COVER(R), FOG LAMP-----2-G11  
 COVER(R), GLOVE-----2-H15  
 COVER(R), QTR. TRIM-----3-C11  
 COVER(R), RETRACTOR-----2-N16  
 COVER(R), RR COMB.-----2-J11  
 COVER(R), SIDE-----2-I15  
 COVER(R), SIDE NO. 2-----2-I15  
 COVER(R), TRUNK SIDE-----3-N9  
 COVER, ACTUATOR-----3-F7  
 COVER, AIR CLEANER-----1-N4  
 COVER, BEARING-----1-F7  
 COVER, BLIND-----1-G7  
 COVER, BLIND-EXTENSION HOU-----1-H7  
 COVER, BOX-BATTERY-----1-C9  
 COVER, CASE-----2-G3  
 COVER, CENTER ADAPTER-----3-J10  
 COVER, CLUTCH-----1-C7  
 COVER, COLUMN-LOWER-----2-C15  
 COVER, COLUMN-UPPER-----2-C15  
 COVER, DAMPER STAY-----3-K5  
 COVER, DUST-----1-C7  
 COVER, F. FOG LAMP-----2-H11  
 COVER, FRONT-----1-C3  
 COVER, FRONT CLUTCH-----1-C7  
 COVER, FRONT-ALTERNATOR-----1-I8  
 COVER, FUSE BLOCK-----3-H8  
 COVER, GRILLE-----2-F10  
 COVER, HOLE-----2-K15  
 COVER, HOLE (C)-----2-M13  
 COVER, HOLE-ANTENNA-----2-N13  
 COVER, HOLE-BELT-----3-H9  
 COVER, HOLE-DOOR BODY-----3-J3  
 COVER, HOLE-LIFT GATE-----3-J3  
 COVER, HOLE-RR WIPER-----3-F9  
 COVER, INJECTOR-----1-J4  
 COVER, LAMP-----2-H15  
 COVER, LICENSE LAMP-----2-N11  
 COVER, MAIN FUSE BLOCK-----3-C8  
 COVER, OIL PUMP-----1-E9  
 COVER, PEEPING HOLE-----1-C7  
 COVER, REAR-----2-K3  
 COVER, REAR-ALTERNATOR-----1-I8  
 COVER, RELAY BOX-F. HARNESS-----3-E8  
 COVER, RR FINISHER-----2-L11  
 COVER, SERVICE HOLE-----2-N13  
 COVER, SOCKET-HEAD LAMP-----2-M10  
 COVER, SUN VISOR-----3-J10  
 COVER, T/MISSION-----2-C14  
 COVER, THERMOSTAT-----1-J6  
 COVER, UNDER-----1-G7  
 COVER, UNDER-FRONT-----2-C14  
 COVER, UNDER-MAIN FUSE BLK-----3-C8  
 COVER, UNDER-REAR-----2-C14  
 COVER, UNDER-RELAY BOX-----3-C8  
 COVER, VENT.-----2-G4  
 COVER, WHEEL CORE-----2-G4  
 COVER, WIPER ARM-FRONT-----3-N8  
 COVER, WIPER ARM-REAR-----3-F9  
 COVER 'A', FRAME-SLIDE ROOF-----3-D6  
 COVER 'A', HOLE-----3-D10  
 COVER 'B', FRAME-SLIDE ROOF-----3-D6  
 COVER 'B', HOLE-----3-D10  
 COVER 'C', HOLE-----3-D10  
 COVER 'L', HYDRAULIC UNIT-----2-C8  
 COWLING, RADIATOR-----1-K6  
 CUP, SECONDARY-----2-I7  
 CUSHION(L), FRT SEAT-----2-J16  
 CUSHION(R), FRT SEAT-----2-H16  
 CUSHION, RUBBER-----3-C10  
 CYL., CLUTCH MASTER-----2-H6  
 CYL., CLUTCH RELEASE-----2-H6  
 CYL., TANDEM MASTER-----2-I7

COVER, OIL PUMP-----1-E9  
 COVER, PEEPING HOLE-----1-C7  
 COVER, REAR-----2-K3  
 COVER, REAR-ALTERNATOR-----1-I8  
 COVER, RELAY BOX-F. HARNESS-----3-E8  
 COVER, RR FINISHER-----2-L11  
 COVER, SERVICE HOLE-----2-N13  
 COVER, SOCKET-HEAD LAMP-----2-M10  
 COVER, SUN VISOR-----3-J10  
 COVER, T/MISSION-----2-C14  
 COVER, THERMOSTAT-----1-J6  
 COVER, UNDER-----1-G7  
 COVER, UNDER-FRONT-----2-C14  
 COVER, UNDER-MAIN FUSE BLK-----3-C8  
 COVER, UNDER-REAR-----2-C14  
 COVER, UNDER-RELAY BOX-----3-C8  
 COVER, VENT.-----2-G4  
 COVER, WHEEL CORE-----2-G4  
 COVER, WIPER ARM-FRONT-----3-N8  
 COVER, WIPER ARM-REAR-----3-F9  
 COVER 'A', FRAME-SLIDE ROOF-----3-D6  
 COVER 'A', HOLE-----3-D10  
 COVER 'B', FRAME-SLIDE ROOF-----3-D6  
 COVER 'B', HOLE-----3-D10  
 COVER 'C', HOLE-----3-D10  
 COVER 'L', HYDRAULIC UNIT-----2-C8  
 COWLING, RADIATOR-----1-K6  
 CUP, SECONDARY-----2-I7  
 CUSHION(L), FRT SEAT-----2-J16  
 CUSHION(R), FRT SEAT-----2-H16  
 CUSHION, RUBBER-----3-C10  
 CYL., CLUTCH MASTER-----2-H6  
 CYL., CLUTCH RELEASE-----2-H6  
 CYL., TANDEM MASTER-----2-I7  
 \*\*\*\*\*  
 \* D \*  
 \*\*\*\*\*  
 DAM, AIR-SKIRT-----3-D11  
 DAM, FRT. WGLHD GLASS-----3-N5  
 DAMPER(L), FRONT-----2-F5  
 DAMPER(L), REAR-----2-C4  
 DAMPER(R), FRONT-----2-F5  
 DAMPER(R), REAR-----2-C4  
 DAMPER, DYNAMIC-----2-F6  
 DAMPER, PULSATION-----1-K4  
 DASH POT-----1-O5  
 DIFFERENTIAL-----2-K3  
 DISC, CLUTCH-----1-C7  
 DISPLAY, SECURITY-ALARM-----2-N15  
 DISTRIBUTOR, FUEL-----1-J4  
 DOWEL, TUBULAR-----1-D3  
 DRIVING & DIFF.-----2-J3  
 DRUM, HIGH CLUTCH-----1-M10  
 DRUM, REVERSE-----1-M10  
 DUCT NO. 2(L)-----2-H15  
 DUCT(L), AIR-BRAKE PIPE-----2-J7  
 DUCT(L), LAP-----2-C16  
 DUCT(L), SHOWER-----3-C4  
 DUCT(L), SIDE DEMIST.-----2-C16  
 DUCT(L), VENTILATOR-----2-C16  
 DUCT(R), AIR-BRAKE PIPE-----2-J7  
 DUCT(R), VENTILATOR-----2-C16  
 DUCT, AIR-----3-C4  
 DUCT, AIR-INTER COOLER-----1-D4  
 DUCT, CENTER-----2-C16  
 DUCT, FRESH AIR-----1-L4  
 DUCT, OIL COOLER-----1-D9  
 DUCT 'A', REAR SPEAKER-----3-J7  
 DUCT 'B', RR SPEAKER-----3-J7  
 DUCT 'C', RR SPEAKER-----3-J7  
 \*\*\*\*\*  
 \* E \*  
 \*\*\*\*\*

ELEMENT, AIR CLEANER-----1-M4  
 END, CONTROL LEVER-----1-G7  
 END, S/ROD(1ST&2ND)-----1-D8  
 END, S/ROD(3RD&4TH)-----1-D8  
 END, SHIFT ROD(C/TOP&REV.)-----1-D8  
 ENGINE, SHDRT-----1-C3  
 EVAPORATOR-----3-H5  
 \*\*\*\*\*  
 \* F \*  
 \*\*\*\*\*  
 FACE, FRONT BUMPER-----2-E10  
 FAN DRIVE-----1-K6  
 FAN(L), COOLING-----1-J6  
 FAN(R), COOLING-----1-J6  
 FANREL-----3-F9  
 FASTENER-----1-D4  
 FASTENER-----2-E10  
 FASTENER-----2-F12  
 FASTENER-----2-I10  
 FASTENER-----2-I12  
 FASTENER-----2-L7  
 FASTENER-----2-M13  
 FASTENER-----2-N12  
 FASTENER-----2-N15  
 FASTENER-----3-D4  
 FASTENER-----3-D10  
 FASTENER-----3-D11  
 FASTENER-----3-E10  
 FASTENER-----3-E11  
 FASTENER-----3-F3  
 FASTENER-----3-F10  
 FASTENER-----3-G10  
 FASTENER-----3-H9  
 FASTENER-----3-J9  
 FASTENER-----3-K3  
 FASTENER-----3-K9  
 FASTENER-----3-L5  
 FASTENER-----3-M10  
 FASTENER-----3-N4  
 FASTENER, BONNET-----2-I12  
 FASTENER, CTR. P/UPP.-----3-K9  
 FASTENER-----3-L5  
 FASTENER, DUCT PANEL-----1-H9  
 FASTENER-----1-L6  
 FASTENER, KEY CYL.-----2-C7  
 FASTENER, LAMP-----2-M10  
 FASTENER, REAR BUMPER-----2-F10  
 FASTENER, SEAL-TRIM-----2-I10  
 FASTENER, TRIM-SLIDE ROOF-----3-E6  
 FASTENER, TRK. S. TRIM-----2-G10  
 FEEDER-ANTENNA-----3-K7  
 FELT-----3-L7  
 FILTER, AIR-----1-J5  
 FILTER-----1-K5  
 FILTER, FUEL-----1-I4  
 FILTER, FUEL PUMP-----2-L6  
 FILTER, GOVERNOR-----1-D10  
 FINISHER, REAR-----2-I11  
 FLANGE, COMPANION-----2-J3  
 FLANGE, REAR AXLE-----2-E3  
 FOAM(L), ENGY. ABS.-RR BUMP-----2-H10  
 FOAM(R), ENGY. ABS.-RR BUMP-----2-H10  
 FORK, BRAKE-----2-E7  
 FORK, CLUTCH-----1-L4  
 FORK, CLUTCH RELEASE-----1-C7  
 FORK, CLUTCH RELEASE-----1-D7  
 FORK, SHIFT(1ST&2ND)-----1-D8  
 FORK, SHIFT(3RD&4TH)-----1-D8  
 FORK, SHIFT-5TH & REVERSE-----1-E8  
 FRAME(L), REAR SIDE-----2-K13  
 FRAME(L), SIDE-FRONT-----2-L12  
 FRAME(L), SIDE-OUTER-----2-G13  
 FRAME(R), REAR SIDE-----2-K13  
 FRAME(R), SIDE-FRONT-----2-L12  
 FRAME(R), SIDE-OUTER-----2-D13  
 FRAME, CENTER-REAR SIDE-----2-K13

ALPHABETICAL INDEX \*\*\* ENGLISH \*\*\*

FRAME, POWER PLANT-----	2-C6	GASKET, SPOILER-----	3-E11	GROMMET, SCREW-----	3-D11	HOLDER, JACK HANDLE-----	1-H9	HOUSING(L), FOG LAMP-----	2-F11
FRAME, SLIDING ROOF-----	3-C6	GASKET, SPRING CAP-----	1-H7		3-E3		2-15	HOUSING(R), BACK UP LAMP-----	2-K11
FRAME, SUB-----	2-F4	GASKET, THERMO-----	1-C5		3-I3	HOLDER, NO. PLATE-----	2-E10	HOUSING(R), FOG LAMP-----	2-F11
FUSE-----	3-H4	GASKET, THERMOSTAT COVER-----	1-J6		3-J3	HOLDER, P. B. VALVE-----	2-C8	HOUSING, AIR CLEANER-----	1-L4
FUSE (120A)-----	4-08	GASKET, THROTTLE BODY-----	1-T5		3-L3	HOLDER, PIPE-----	2-C7	HOUSING, CLUTCH-----	1-C7
FUSE (15A)-----	4-C8	GASKET, TURBO-----	1-Q4	GROMMET, SCREW-R. COMB-----	3-N3		2-08	HOUSING, CONVERTER-----	1-E9
	4-H8	GASKET, TURBOCHARGER-----	1-F4		2-I11		2-L7	HOUSING, EXTENSION-----	1-F7
FUSE (30A)-----	4-C8	GASKET, VAC. POWER ASSIST-----	2-H7		2-J11	HOLDER, PIPE-FRT BRAKE(L)-----	2-L7		1-I9
	4-F8	GASKET, VAPOR VALVE-----	2-C7		3-H3	HOLDER, PLATE-----	2-G7	HOUSING, FRONT-----	1-03
	4-H8	GASKET, WATER DRAIN-INTER-----	1-D3	GROMMET, SCUFF PLATE-----	3-K9	HOLDER, SPINDLE-----	1-H7	HOUSING, GEAR-----	2-4
FUSE (40A)-----	4-F8	GASKET, WATER PUMP-----	1-T6	GROMMET, SIDE GARNISH-----	2-I11	HOLDER, 'B' PIPE-----	2-C8	HOUSING, INTERMEDIATE-----	1-E3
FUSE (60A)-----	4-F8	GASKET, 'A' REINFORCEMENT-----	2-M6	GROMMET, WASH-COOLING-----	3-K4	HOLDER 'C' PIPE-----	2-08	HOUSING, REAR-----	1-03
*****		GASKET 'B' DUST COVER-----	2-M6	GROMMET, WATER TANK-----	3-M8	HOLDER 'E' PIPE-FUEL-----	2-08	HOUSING, ROTOR-FRONT-----	1-D3
* * * * *		GAUGE UNIT, OIL PRES-----	3-H6	GUARD(L), MUD-----	2-M12	HOLDER 'F' PIPE-----	2-08	HOUSING, ROTOR-REAR-----	1-D3
* * * * *		GAUGE, FUEL TANK-----	2-C7	GUARD(R), MUD-----	2-M12	HOLDER 'G' PIPE-----	2-08	HOUSING, WAX-----	1-C5
* * * * *		GAUGE, OIL LEVEL-----	1-E3	GUIDE(L), REAR-----	3-D6	HOLDER 'H' PIPE-----	2-08	HUB-----	1-F11
			1-M9	GUIDE(R), REAR-----	3-C6	HOLDER 'K' PIPE-FUEL-----	2-08	HUB SET, CLUTCH-O.T. & REV-----	1-M7
GARNISH(L)-----	2-L10	GEAR-----	1-N8	GUIDE, AIR-----	2-E10	HOOD, METER-----	2-D15	HUB SET, CLUTCH-1ST & 2ND-----	1-K7
	3-H10	GEAR SET-----	1-N8	GUIDE, CHANGE-----	1-H7	HOOK(L), TIE DOWN-----	2-L13	HUB SET, CLUTCH-3RD & 4TH-----	1-J7
GARNISH(L), DOOR-----	3-N3	GEAR SET, DRIVEN-SPEED-----	1-G7	GUIDE, PARKING ROD-----	1-J11	HOOK(L), TIE DOWN-FRONT-----	2-M12	HUB(L), SUPPORT-----	2-E3
GARNISH(L), SAIL-INN-----	3-N3		1-J9	GUIDE 'A' (L), GLASS-----	3-E3	HOOK(R), TIE DOWN-----	2-L13	HUB(R), SUPPORT-----	2-E3
GARNISH(R)-----	3-K10	GEAR SET, FINAL-----	2-J9	GUIDE 'A' (R), GLASS-----	3-E3	HOOK(R), TIE DOWN-FRONT-----	2-M12	HUB, CLUTCH-----	1-N7
	3-H10	GEAR, COUNTER-----	1-L7	GUIDE 'B' (L), GLASS-----	3-E3	HORN, HIGH TONE-----	3-E7	HUB, FORWARD CLUTCH-----	1-M2
GARNISH(R), DOOR-----	3-M3	GEAR, COUNTER REVERSE-----	1-L7	GUIDE 'B' (R), GLASS-----	3-E3	HORN, LOW TONE-----	3-E7	HYDRAULIC UNIT, A B S-----	2-N7
GARNISH(R), SAIL-INN-----	3-N3	GEAR, COUNTER SHAFT-----	1-L7	GUSSET(L), RR PILLAR-----	2-F13		1-E6		
GASKET-----	1-D9	GEAR, DRIVE-----	1-G11	GUSSET(L), SIDE SILL OUTER-----	2-E13		1-H9	*****	
	1-F7	GEAR, DRIVE-OIL PUMP-----	1-K3				1-14	* * * * *	
	1-H6	GEAR, DRIVEN-----	1-D6	*****			1-N5	* * * * *	
	1-J5	GEAR, INTERNAL-----	1-E11	* * * * *			2-C7	* * * * *	
	1-J6	GEAR, INTERNAL-STARTER-----	1-L8	* * * * *			2-H8	* * * * *	
	1-K9	GEAR, MAIN DRIVE-----	1-J7	* * * * *			3-C4		
	1-L6	GEAR, OVER TOP-----	1-M7				3-C4		
	1-N8	GEAR, PARKING-----	1-G11	HANDLE(L), INNER-----	3-I3	HOSE NO. 1, WATER-----	3-C4	IGNITER, IG. COIL-TRALING-----	1-G8
	2-D6	GEAR, REVERSE-----	1-L7	HANDLE(L), OUT-----	3-I3	HOSE NO. 2, WATER-----	3-C4	INDICATOR-----	2-I8
	2-E7	GEAR, REVERSE IDLE-----	1-M7	HANDLE(R), INNER-----	3-H3	HOSE NO. 3, WATER-----	3-C4	INDICATOR, ECONOMY-METER-----	2-E15
	2-F6	GEAR, RING-FLY WHEEL-----	1-J3	HANDLE(R), OUT-----	3-I3	HOSE NO. 4, WATER-----	3-C4	INDICATOR, LEVEL-----	2-H7
	2-F11	GEAR, SHAFT-----	3-D9	HANDLE, JACK-----	2-I5	HOSE, AIR-----	1-E5	INJECTION, FUEL-M.P. ELECT-----	1-J4
	2-G7	GEAR, SMALL SUN-----	1-F11	HANDLE, SLIDING ROOF-----	3-D6		1-H4	INSULATOR-----	1-D4
	2-L6	GEAR, SPEEDO.DRIVE-----	1-M7	HANGER-----	2-E6		1-J5		1-M4
GASKET & SEAL KIT-----	1-L11	GEAR, STATIONARY-FRT-----	1-E3	HANGER, ENGINE-----	1-H3	HOSE, BREATHER-----	2-M6		2-C14
GASKET KIT, COMPRESSOR-----	3-D5	GEAR, STATIONARY-RR-----	1-F3	HANGER, ENGINE-REAR-----	1-H3	HOSE, CLUTCH FLEXIBLE-----	2-J6	INSULATOR(L), COWL SIDE-----	3-E10
	3-F5	GEAR, STEERING-----	2-14	HANGER, SILENCER-----	2-E6	HOSE, DRAIN-----	2-F8	INSULATOR(L), F.FLOOR-----	3-E10
	1-N3	GEAR, SUN-----	1-E11	HANGER, STRAP-----	3-L5		3-J4	INSULATOR(R), COWL SIDE-----	3-E10
GASKET NO. 2, IN. MANIFOLD-----	1-C3	GEAR, 1ST-----	1-K7	HARNESS-----	2-K4	HOSE, DRAIN-REAR-----	3-F6	INSULATOR(R), F.FLOOR-----	3-E10
GASKET SET, ENGINE-----	1-C3	GEAR, 2ND-----	1-K7	HARNESS NO. 2, REAR-----	3-D8	HOSE, DRAIN-SUN ROOF FRONT-----	3-E6	INSULATOR, BONNET-----	2-I12
GASKET SET, SUB-ENG-----	1-C3	GEAR, 3RD-----	1-J7	HARNESS NO. 3, REAR-----	3-D8	HOSE, EVAPORATION-----	1-14	INSULATOR, BOOT-----	2-M15
GASKET(C), SPOILER-----	3-E11	GENERATOR, SPEED PULSE-----	3-K6	HARNESS, BLOWER UNIT-----	3-H4	HOSE, FLEXIBLE-----	2-K7	INSULATOR, CONVERTER-----	2-E6
GASKET(L)-----	2-G11	GLASS(L), DOOR-FRT-----	3-D3	HARNESS, COOLING UNIT-----	3-H5	HOSE, FLEXIBLE-HIGH-----	3-J4	INSULATOR, DASHBOARD-----	3-D10
GASKET(L), REAR SIDE-----	2-L11	GLASS(L), MIRROR-----	3-I10	HARNESS, DASHBOARD-----	3-I8		3-M4	INSULATOR, EX. MANIFOLD-----	1-C4
GASKET(L), SPOILER-----	3-D11	GLASS(R), DOOR-FRT-----	3-D3	HARNESS, DOOR-DRIVER SIDE-----	3-J8	HOSE, FLEXIBLE-LOW-----	3-J4	INSULATOR, EXH. MANIFOLD-----	1-E4
GASKET(R), REAR SIDE-----	2-L11	GLASS(R), MIRROR-----	3-I10	HARNESS, DOOR-PASSENGER SI-----	3-J8	HOSE, FUEL-----	3-M4	INSULATOR, FRONT-----	2-C14
GASKET(R), SPOILER-----	3-D11	GLASS, BACK WINDOW-----	3-M5	HARNESS, ENGINE-----	3-G8		1-14	INSULATOR, FUEL DIST.-----	1-J4
GASKET, A.C.V-----	1-E5	GLASS, FRONT-WARNING UNIT-----	2-F15	HARNESS, FRONT-----	3-D8		2-F8	INSULATOR, HEAT-----	1-E4
GASKET, B.A.C. VALVE-----	1-N5	GLASS, WINDSHIELD-----	3-M5	HARNESS, INST-----	3-H8		2-G8	INSULATOR, HEAT-FRONT-----	2-C14
GASKET, BLIND COVER-----	1-G7	GRILLE(C), VENTILATOR-----	2-C16	HARNESS, INSTRUMENT-----	3-H8	HOSE, FUEL MAIN-----	2-N6	INSULATOR, INJECTION-----	1-K4
GASKET, BODY-LWR-----	1-H10	GRILLE(L), DEF. NOZZLE-----	2-H15	HARNESS, INT. LAMP-----	3-E8	HOSE, FUEL-MAIN PIPE-----	2-F8	INSULATOR, MASTER VAC-----	2-D8
GASKET, BODY-UPP-----	1-H10	GRILLE(L), FENDER-----	2-G12	HARNESS, LOGICAL CONTROL-----	3-I8	HOSE, FUEL-SEPARATOR-----	2-F8	INSULATOR, ROD-ANTENNA-----	3-J7
GASKET, CAP-----	2-H6	GRILLE(L), FENDER-----	2-G12	HARNESS, REAR-----	3-D8	HOSE, JOINT-FILLER PIPE-----	2-M6	INSULATOR, ROOF-----	3-H9
GASKET, CHAMBER-EXTRACTOR-----	3-B12	GRILLE(R), DEF. NOZZLE-----	2-H15	HARNESS, SLIDING ROOF-----	3-D6	HOSE, OIL-----	1-F9	INSULATOR, SUB-----	1-E4
GASKET, COMPRESSOR-----	3-F5	GRILLE(R), FENDER-----	2-G12	HEAD, CYL.-COMPRESSOR-----	3-D5		1-G9		
	3-F5	GRILLE(R), SPEAKER-----	3-K3		3-F5		1-H6	*****	
GASKET, COVER PLATE-----	1-E8	GRILLE(R), SPEAKER-----	3-M10	HEADER, FRONT-----	2-I13		1-I6	* * * * *	
GASKET, DRAIN PLUG-----	3-L6	GRILLE, COWL-----	2-F12		2-J13	HOSE, PRESSURE-----	2-K4	* * * * *	
GASKET, DRUM SUPPORT-----	1-I10	GRILLE, EXTRACT.-T.S. TRIM-----	3-N9	HEADER, REAR-----	2-J13	HOSE, RESERVE-----	2-H6	* * * * *	
GASKET, E.G.R. VALVE-----	1-K5	GRILLE, SPEAKER-----	2-G15		3-E4	HOSE, RETURN-----	2-K4	*****	
GASKET, EX. MANIFOLD-----	1-C4	GRIP, FRT ASSIST-----	3-L3	HEATER UNIT-----	2-N12	HOSE, SIDE-DEMISTER-----	2-C16		
GASKET, EXTENSION-----	1-M9	GROMMET-----	2-H10	HINGE-----	2-H12	HOSE, SUB TANK-----	1-L6	JACK-----	2-I5
GASKET, FILLER PIPE/TANK-----	2-L6		2-K10	HINGE(L), BONNET-----	2-H12	HOSE, VACUUM-----	1-15	JOINT SET, BALL-----	2-J4
GASKET, FRONT COVER-----	1-I3	GRILLE, COWL-----	2-F12	HINGE(L), DOOR-LOWER-----	3-D3		2-H7	JOINT SET, INNER-----	2-D3
GASKET, GOVERNOR-----	1-L9	GRILLE, EXTRACT.-T.S. TRIM-----	3-N9	HINGE(L), DOOR-UPPER-----	3-D3		2-I7	JOINT SET, OUTER-----	2-D3
GASKET, HINGE-LIFT GATE-----	3-K5	GRILLE, SPEAKER-----	2-G15	HINGE(L), LID-LAMP-----	2-D11	HOSE, VENTILATION-----	1-14	JOINT(L), STRUT BAR-----	2-N12
GASKET, IN. MANIFOLD-----	1-N3	GRIP, FRT ASSIST-----	3-L3	HINGE(R), BONNET-----	2-H12	HOSE, WATER-----	1-15	JOINT, BACK WINDOW MOULD-----	2-J10
GASKET, JOINT PIPE-----	2-D6	GROMMET-----	2-H10	HINGE(R), DOOR-LOWER-----	3-D3		1-J6	JOINT, BALL-----	3-F6
GASKET, LICENSE-----	2-M11		2-K10	HINGE(R), DOOR-UPPER-----	3-D3		1-K6	JOINT, DRAIN HOSE-REAR-----	3-E6
GASKET, METERING OIL-----	1-D3	GRILLE, COWL-----	2-F12	HINGE(R), LID-LAMP-----	2-D11		1-L6	JOINT, FUEL PIPE-----	2-L7
GASKET, OIL CAP-----	1-O3	GRILLE, EXTRACT.-T.S. TRIM-----	3-N9	HINGE, GLASS HATCH-----	3-K5	HOSE, WATER SUB TANK-----	1-K6	JOINT, HOSE-----	3-E9
GASKET, OIL FILLER PIPE-----	1-E3	GRILLE, SPEAKER-----	2-G15	HOLDER SET, THROTTLE BODY-----	1-C5	HOSE, WATER-T/C WATER-PIPE-----	1-E4		3-L8
GASKET, OIL PAN-----	1-H3	GROMMET, ACTUATOR-----	3-F7	HOLDER, BONNET STAY-----	2-H12	HOSE, WATER-TURBOCHARGER-----	1-E4		1-E3
	1-M9	GROMMET, REAR COOLER-----	3-N4	HOLDER, BONNET STAY-SHROUD-----	2-H12	HOUSING SET, BRG WATER PUM-----	1-I6		2-H6
GASKET, OIL PIPE-----	1-F4	GROMMET, REAR FLOOR-----	2-N13	HOLDER, BRUSH-----	1-N8	HOUSING(L), BACK UP LAMP-----	2-K11		
GASKET, OIL PUMP-----	1-E9	GROMMET, SCREW-----	2-E10		2-J6				
GASKET, OIL STRAINER-----	1-C6		2-F12						
GASKET, SOLENOID VALVE-----	1-J5		2-I11						









ALPHABETICAL INDEX WWW ENGLISH WWW

UNIT(L) HEAD LAMP-----	2-M10	UNIT,DIAGNOSIS-AIR BAG----	5-C7	WASHER, SLEAVE-REAR BRAKE--	2-C5
UNIT(R) HEAD LAMP-----	2-M10	UNIT, DOOR LOCK & TIMER----	5-D7	WASHER, SLEEVE-REAR BRAKE--	2-E3
UNIT, A. C. CONTROL-----	5-C7	UNIT, DRIVE-----	5-D6	WASHER, SPEAKER-----	5-J7
UNIT, CENTRAL PROCESSING--	5-M5	UNIT, FOG LAMP-----	2-F11	WASHER, SPRING-----	2-G3
UNIT, COOLING-----	5-I5	UNIT, HEAT GAUGE-----	5-I6	WASHER, STOP-----	2-H4
UNIT, DIAGNOSIS-AIR BAG----	5-C7	*****		WASHER, THRUST-----	1-I11
UNIT, DOOR LOCK & TIMER----	5-D7	* U *		*****	
UNIT, DRIVE-----	5-D6	* * *		WASHER, THRUST LOCK-OVER T	1-N7
UNIT, FOG LAMP-----	2-F11	* V *		WASHER, THRUST-REVERSE IDL	1-M7
UNIT, HEAT GAUGE-----	5-I6	*****		WASHER, TOOTHED-----	5-D9
*****		* * *		WASHER, TRUST-----	1-L10
* U *		* * *		WASHER, WAVE-CHANGE CONT. C	1-E8
* * *		*****		WAX, THERMO-----	1-E5
*****				WEATHERSTRIP(L), DOOR-----	5-GF3
VACUUM POWER ASSIST-----	2-I7			WEATHERSTRIP(L), DOOR-LOW.	5-GF3
VALVE-----	1-H10			WEATHERSTRIP(L), INN.-----	5-K3
VALVE, ACCUMULATOR-----	1-D10			WEATHERSTRIP(R), DOOR-LOW.	5-GF3
VALVE, AIR-----	1-H5			WEATHERSTRIP(R), DOOR-LOW.	5-GF3
VALVE, AIR BYPASS-----	1-H4			WEATHERSTRIP(R), INN.-----	5-K3
VALVE, AIR CONTROL-----	1-H4			WEATHERSTRIP, BONNET-REAR--	2-I12
VALVE, CHECK-----	1-E5			WEATHERSTRIP, S/ROOF-----	5-E6
VALVE, CONTROL-----	1-D10			WEDGE, LIFTGATE-----	5-K5
VALVE, CONVR RELIEF-----	1-H10			WEIGHT, BALANCE-----	1-K3
VALVE, DUTY SOLENOID-----	1-N3			WEIGHT, COUNTER-----	1-K3
VALVE, E. G. R.-----	1-K5			WEIGHT, DISC WHEEL-ALUMI--	2-H5
VALVE, EXPANSION-----	3-H5			WELT(L), SEAMING-----	5-G3
VALVE, EXTRACT CHAMBER----	2-G12			WELT(R), SEAMING-----	5-F3
VALVE, FUEL VAPOR-----	2-N6			WELT, SEAMING-----	5-C6
VALVE, IDLE AIR CONTROL----	1-M5			WHEEL, DISC-ALUMI.-----	2-I5
VALVE, LOCK UP CONTROL-----	1-J10			WHEEL, FLY-----	1-J3
VALVE, MANUAL-----	1-D10			WHEEL, SPROCKET-----	1-C6
VALVE, MODIFIER-----	1-D10			WIRE-----	2-I5
VALVE, NON RETURN-----	2-M6			WIRE, A. C. C.-----	5-F7
VALVE, ORIFICE CHECK-----	1-D10			WIRE, EARTH-----	5-G8
VALVE, P. B.-----	2-D8			WIRE, EARTH-FILLER PIPE----	2-M6
VALVE, P. C. V.-----	1-J5			WIRE, EARTH-HYD. UNIT-----	2-C8
VALVE, RELIEF-----	3-D5			WIRE, EARTH-REAR DEFFOGER--	3-D8
VALVE, SHIFT-----	1-G10			WIRE, RELEASE-----	2-H16
VALVE, SOL. -AIR BLEED EXTE	1-H10			WIRE, RELEASE-BONNET-----	2-H12
VALVE, SOLENOID-----	1-F5			WIRING, ENGINE-----	5-F8
VALVE, SOLENOID-A. C. VALVE	1-J5			WIRING, FLOOR-----	3-J8
VALVE, SPOOL-----	1-E5			WRENCH, HUB NUT-----	3-G10
VALVE, ST. GEAR-----	1-I10			WTHSTP, LIFT GATE-----	3-L5
VALVE, 3RD LOCK UP-----	2-J4			WTHSTP(L), GLASS-F. DOOR---	3-F3
VALVE, 3WAY-----	1-I10			WTHSTP(R), GLASS-F. DOOR---	3-F3
*****				*****	
* W *				* Y *	
* * *				* * *	
*****				*****	
WALL(L), SIDE-----	2-L15	YOKE-----	1-L8		
WALL(R), SIDE-----	2-L15	YOKE SET, SUPPORT-ST. GEAR	2-I4		
WARNING, HEAT-----	2-K15				
WASHER-----	1-E10				
	2-C11				
	2-F6				
	2-H16				
	2-I4				
	2-I8				
	2-J3				
	5-D9				

# MODEL IDENTIFICATION

This parts catalog has been compiled to cover the following models.

(1/1)

Model No.	Specifications of vehicles																				VIN (Chassis No.)						
	Basic spec.	Eng line	Turbo	T/mission	Speed		Body	Roof	Suspension	Diff.	Brake	Air bag	Production period	Model year	California & Federal			Guam & Saipan									
	U.S.A.	RE 13B	Turbo	Manual Transmission	Automatic Transmission	4 speed	5 speed	Coupe	W/O sun roof	Sun roof	Normal suspension	Hard suspension	Limited slip diff.	A. lock brake	Air bag	From	To	1993	Production for California & Federal	Grade		Production for Guam & Saipan	Grade				
	(US)	(13)	(TR)	(MT)	(AT)	(4S)	(5S)	(CP)	W/O SR	(SR)	(NS)	(HS)	(LS)	(AL)	(AB)	Dec '91	Aug '93	→	Yes	BS		(R1)	(TR)	Yes	BS	(R1)	(TR)
FD01	US	13	TR	MT		5S	CP	W/O SR		SR	NS		LS	AL	AB	Dec '91	Aug '93	→	Yes	BS			Yes	BS			FD3+++ - 200001-300000
FD02	US	13	TR		AT	4S	CP	W/O SR			NS		LS	AL	AB	Dec '91	Aug '93	→	Yes	BS			Yes	BS			FD3+++ - 200001-300000
FD03	US	13	TR	MT		5S	CP	W/O SR			HS		LS	AL	AB	Dec '91	Aug '93	→	Yes		R1		Yes		R1		FD3+++ - 200001-300000
FD04	US	13	TR	MT		5S	CP		SR		NS		LS	AL	AB	Dec '91	Aug '93	→	Yes			TR	Yes			TR	FD3+++ - 200001-300000
FD05	US	13	TR		AT	4S	CP		SR		NS		LS	AL	AB	Dec '91	Aug '93	→	Yes			TR	Yes			TR	FD3+++ - 200001-300000

## BODY PAINTS AND INTERIOR COLORS

THIS LIST SHOWS COMBINATION OF BODY PAINT AND INTERIOR COLOR. USING THIS LIST YOU WILL BE ABLE TO FIND OUT NECESSARY COLOR CODE OF PART YOU NEED IN THE TEXT.

BODY PAINT		INTERIOR COLOR CODE		
NAME	CODE			
Competition yellow	J9	F E 2		
Montego blue metallic	M8	F E 2	F E 3	
Vintage red hiref cort	NT	F E 2	F E 3	
Vintage red	NU	F E 2	F E 3	
Brilliant black hiref cort	PX	F E 2	F E 3	F E 4
Brilliant black	PZ	F E 2	F E 3	F E 4
Crystal white	UC	F E 2	F E 3	F E 4
Montego blue mica hiref cort	2A	F E 2	F E 3	
Silver stone metallic	3L	F E 2		F E 4
Silver stone metallic hiref cort	4G	F E 2		F E 4

NOTE  
COLORS OF INTERIOR CODES  
ARE AS FOLLOWS.

FE2	Black
FE3	Tan
FE4	Red



## COMPLETE ASSEMBLY PARTS NUMBERS

### Engine

Specifications of vehicles		Parts number
T/mission	Suspension	
Manual T/mission	Normal	N3A5 - 02 - 000
	Hard	N3A1 - 02 - 000
Automatic T/mission	※	N3A2 - 02 - 000

### Cabin

(1/1)

Specifications of vehicles		Parts number
Roof	Suspension	
W/O sun roof	Normal	FD01 - 07 - 000
	Hard	FD03 - 07 - 000
Sun roof	※	FD04 - 07 - 000


### T/mission

Specifications of vehicles	Parts number
T/mission	
Manual T/mission	R564 - 03 - 000
Automatic T/mission	BV65 - 19 - 090G

The ※ mark in the above chart does not affect on part number selection.  
Complete assemblies are available and manufactured in accordance with current production specifications only.


## VEHICLE IDENTIFICATION SYSTEM FOR RX-7 SERIES (1993)

VIN (= Vehicle Identification Number) for RX-7series (1993 Year Model) consists of WMI(= World Manufacturer Identifier), VDS(= Vehicle Description Section) and VIS(= Vehicle Identification Section). VDS consisting of six alphanumeric characters denotes the "MODEL SERIES". VIS consisting of eight alphanumeric characters denotes the serial unit number of vehicle and is sequentially numbered within each VDS.



### LOCATION OF VIN PLATE

The plate is attached to the top ledge of the dash panel under the bonnet(engine hood), refer to the illustration shown right.



\* Check digit is included as a VIN security feature to permit law enforcement verification of the authenticity of a suspected illegal VIN plate. This single digit number is determined, based upon a complex mathematical formula which is applied to each vehicle's VIN number.

\*\* Miscellaneous Identification Code identifies major components such as engine, brake system, cab type, etc.

(Note)

If the VIN(Chassis) reference number in the PCM(Parts Catalog Microfiche) appeared as:

FD3 \*\*\* - 200001

...the vehicle's VIN would be e.g. JM1FD331\*P0200001.

# ABBREVIATIONS

The following abbreviations are used throughout Mazda Microfiche parts catalog: in the illustration, text, section number index, alphabetical index.

Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition
1ST	First	B.S.V.	Bleed Solenoid Valve	DIFF	Differential	H	Head	L/EM	Loss Emission Controls	P	Panel
2ND	Second	BTHR	Breather	DISC/B	Disc Brake	HARN.	Harness	L.H.D.	Left Hand Drive	(P)	Primary
2D.	2-Door	BUMP	Bumper	DIST	Distributor	H.A.C.	High Altitude Compensator	LH SIDE	Left Hand Side	PARK or PARKG	Parking
2-SEAT	2-Seater	BURG.	Burglar	DMPR	Dumper	H.A.COMPENSATOR	High Altitude Compensator	LKOUT	Lockout	PASS.	Passenger
3D.	3-Door	BY A.C.V.	Bypass Air Control Valve	DOHC	Double Overhead Camshaft	H.B.	Hatchback	L.NOSE	Long Nose	P.B.	Proportioning Brake
3RD	Third	[C]	Center	D.P.	Dual Proportioning	H.B. RE	Hatchback Release	L/NVGT. CPU	Loss Navigation Computer	P.C.V.	Positive Crankcase Ventilation
3-SP	3-Speed	C. or (C)	Center	DRUM/S	Drum Brake	HC-AT	Hydro Control Automatic T/Mission	LO	Low	PHILPNS	Philippines
4D.	4-Door	CALIF.	California	D/TIRE or D.TIRE	Double Tire (-Dual Tire)	HEAT	Heater	L.S. VALVE	Load Sensing Valve	PILR	Pillar
4-SP or 4 SPD	4-Speed	C/AREA	Cold Area	D.T. TOP	Detachable Top	HEDUTY	Heavy Duty	L/PARTITION	Less Partition	PIV	Pivot
4.5-SP	4-Speed 5-Speed	CAN.	Canada	DRUMP	Dump Truck	HEA. or HEAT.	Heater	L.P.G.	L.P. Gas (=Liquefied Petroleum Gas)	PKG.	Package
4TH	Fourth	CARB.	Carburetor	DX.	Deluxe	HL -	High -	L.S.D or L.S. DIFF	Less Slip Differential	PNEUMA.	Pneumatic
5D	5-Door	CAT	Catalyst	D. YLW	Dark Yellow	HIAI T	High Altitude	..LITER(s) TANK	..Liter(s) Tank	PNL	Panel
5-LINK	5-Link Suspension	C.DISC	Compact Disc	ICE	Conventional Engine (-Reciprocating Gasoline Engine)	H.I.C.	Head Injury Criteria	L/TAILGATE	Less Tailgate	PNT	Point
5-SP or 5-SPD	5-Speed	CE	Conventional Engine (-Reciprocating Gasoline Engine)	ECE	Economic Commission for Europe	HIGHT	High-Tension	LVR	Lever	POSI.	Position
10TH-ANNIV	10th Anniversary	C.U.R.	Constant Gear Ratio	ECON.	Economy	HL or H.L. or HLAMP	Head Lamp	LWR	Lower	POSIT.	Positive
[A]	.Amps	CH	Coach	E.C.P.S. SYS	Electric Control Power Steering System	H.KONG	Hong Kong	LRG.	Large	POW. WINDOW	Power Window
A.A.S. or A.A. SUSP	Automatic Adjustment Suspension	CHG	Change	EGI	Electric Gasoline Injection	HNGR	Hanger	LX-P	LX with Performance Package	P.P.	Polypropylene (Plastics)
ABS.	Absorber	CHMBR	Chamber	EGR	Exhaust Gas Recirculation	..HP	..Horsepower(s)	[M]	..Meter(s)	PRESS	Pressure
A.B.S.	Anti lock Brake System	CHK	Check	E.G.R.	Exhaust Gas Recirculation	H.P.R.	High Penetration Resisted	..M	..Master Cylinder	PROTN	Protection
A.B.S.V.	Air Bleed Solenoid Valve	CLG.	Cooling	ELECT	Electric	HT, HET or HTOP	Hardtop	MA. CYL	Maintain or Maintenance	PROTR	Protector
A.C.	Air Conditioner	CLNR	Cleaner	EM.	Emission Controls	HWI	Naval	MAINT.	Maintain or Maintenance	PORTGL	Portugal
A.C.C.	Automatic Cruise Controls	CLTR	Cigarette Lighter	ENGY	Energy	[I]	Inner Diameter	MAP	Manifold Absolute Pressure	P.S.	Power Steering
ACCEL.	Accelerator	CM	..Centimeter (s)	ENEG or ENGY	Engine	IG or IGH.	Ignition	M.A. SUSP	Multi-Adjustable Suspension	P.SOUND	Premium Sound
ACTR	Actuator	C.MEMBER	Crossmember	ENG.	Engine	IG or IGH.	Ignition	M.EAST	Middle East	PSTN	Postion
A.C.V	Air Control Valve	CNTNR	Container	EOLZR	Equalizer	IL	Island	M. EAST	Middle East	PTC	Positive Temperature Coefficient
ADJ.	Adjuster or Adjustable or Adjusting	COBIB	Combination	EQUIP.	Equipment	ILLUM.	Illumination	M. F	Maintenance Free	P.T.O.	Power Take Off
ADJ.SUSP	Adjustable Suspension	COMP.	Compass	EX.	Exhaust	IN.	Inlet	M/F	Mirror	PU	Pickup
AIR P.	Air Pipe	COMPR	Compressor	EXC.	Except	IND.	Indicator	M.:	Mirrored	PW or P. WINDOW	Power Window
AIR CON	Air Conditioner	COMPS.	Compressor	EXC. 10TH-ANNIV.	EXC. 10th Anniversary	INH.	Inhibitor	ML	Mainland	PWRGT LIF. R	Power Gate Lifter
ALTR	Alternator	CONDNR	Condenser	EXT.	Extension	INHIB.	Inhibitor	MLD. or MLDG.	Moulding	PWT	Powertrain
ALUMI.	Aluminum	CONN.	Connector or Connecting	EXTRACT.	Extractor	INN.	Inner	..MM	..Millimeter(s)	[Q]	Quarter
AMP.	Amplifier	CONS.	Console	(F)	Fr. 2-	INS.	Insulation	M.P.	..Millimeter(s)	QTR.	Quarter
ANALOG	Analogue	CONT.	Control	F. -	Fr. 2-	INST.	Inspection	M.P.	..Millimeter(s)	QTY	Quantity
ANNIV.	10th Anniversary	CONV.	Conventional	..F	..feet (.Foot)	INT.	Instrument	MT	Mounting	[R]	Right
ANT	Antenna	CONVR	Converter	FED.	Federal	INT. COOLER	Inter Cooler	MT & MTG.	Mounting	R	Right
ARG	Argent	COVR	Cover	FINIS	Finisher	INTER	Intermediate	MT	Mounting	R or (R)	Right
A.S. ABSORBER	Adjust Shock Absorber	CPE	Coupled	F.I.P.	Fuel Injection Pump	INTMT. or INTERMIT.	Intermittent	[N]	Number of Teeth	RE	Rotary Engine
ASH	Ashray	CPT.	Complete Assembly	FLEX	Flexible	I.R.S. or I.R. SUSP	Independent Rear Suspension	N.	Narrow	RECIPRO	Reciprocating Engine (=Conventional Engine)
ASSY	Assembly	CPU	Computer	F.I.MIXER	Fuel Injection Mixer	I.S.C.	Idle Speed Control	N.C.	Normal Close	REFRIGER.	Refrigerator Van
AT	Automatic Transmission	CRK	Crank	FX.	Fixing	NO.	Normal	N.O.	Normal Open	REG. GAS	Regular Gasoline
ATT	Attachment	C.P.UNIT	Central Processing Unit	F.LID	Filler Lid	NON-SP	Non-Special Equipment	NO.	Number	REGUL.	Regulator
AUS	Austria	CRK	Crank	F.L.DICK	Full Logic Deck	NON-TILT	Non-Tilting	NOZ.	Nozzle	REL	Release
AUST.	Australia	CRUST	Crusher	FOLD.	Folding	NOR	Normal	N.S.W.	New South Wales (Aust.)	REM. CON.	Remote Controlled
AUTO.	Automatic	C/SHIFT	Column Shift	FRA	France	NOZ.	Nozzle	NYGT. CPU	Navigation Computer	RET	Return
[B]	Balance	CTR.	Center	FRT	Front	N.S.W.	New South Wales (Aust.)	NYGT. CPU	Navigation Computer	RETRACT	Retractable
BAL.	Balance	CUSH.	Cushion	F/SHIFT	Floor Shift	[K]	..Kilogram(s)	NYZ.	New Zealand	REV.	Reverse
BAL.	Balance	CYL	Cylinder	FULL CON.	Fully Controlled	[K]	..Kilogram(s)	[O]	Outer	R.H.D.	Right Hand Drive
BAT	Battery	[D]	Door	[G]	..Gram(s)	[L]	..Liter(s)	[O]	Outer	RICO	Rubber
B.COLOR	Body Color	D. or DR	Door	GARN	Garnish	[L]	..Liter(s)	[O]	Outer	R.H. SIDE	Right Hand Side
B/DOOR	Back Door	D..	Diameter...	GAS.	Gasoline	[L]	..Liter(s)	[O]	Outer	REINFORC	Reinforcement
BDY	Body	DBI CAB	Double Cab (-Crew Cab)	GASOH	Gasohol	[L.T.	..Liter(s) Tank	[O]	Outer	R.H. SIDE	Right Hand Side
BELT.	Beltline	D. BLUE	Dark Blue	GEN	General	[L. (-Without.)	Less. (-Without.)	[O]	Outer	R.H. SIDE	Right Hand Side
BLK	Black	D. BRN	Dark Brown	G.HATCH	General Hatch	[L.S.W.	Less Automatic	[O]	Outer	R.H. SIDE	Right Hand Side
BLU	Blue	DE	Diesel Engine	G.L.D. M	Glass Metallic	[L.S.W.	Less Automatic	[O]	Outer	R.H. SIDE	Right Hand Side
BLU/GRY	Bluish Gray	DEF.	Defroster	G.L.D. M	Glass Metallic	[L.S.W.	Less Automatic	[O]	Outer	R.H. SIDE	Right Hand Side
BLU. M	Blue Metallic	DEFG	Defogger	G.L.S	Glass	[L.S.W.	Less Automatic	[O]	Outer	R.H. SIDE	Right Hand Side
BLVA	Bolevia	DES	Design	G.L.S	Glass	[L.S.W.	Less Automatic	[O]	Outer	R.H. SIDE	Right Hand Side
BRG.	Bearing	DESBST.	Demister	GOV.	Governor	[L.S.W.	Less Automatic	[O]	Outer	R.H. SIDE	Right Hand Side
BRKT.	Bracket	D. GRY	Dark Gray	GRN	Green	[L.S.W.	Less Automatic	[O]	Outer	R.H. SIDE	Right Hand Side
BRN	Brown	DAHP	Diaphragm	GRY	Gray	[L.S.W.	Less Automatic	[O]	Outer	R.H. SIDE	Right Hand Side
BRT	Britan (=Great Britain)			GRYGRN	Greish Green	[L.S.W.	Less Automatic	[O]	Outer	R.H. SIDE	Right Hand Side

Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition
SDN	Sedan	U LONG	Ultra Long		
S.DUTY	Standard Duty	UND	Under		
SELECT	Selective Use	UP	Upper		
SEN	Sensor	URETANE	Urethane Rubber		
SERV	Service	U.S	Undersize		
S FORK	Shift Fork	(V)			
SG, SQN or SIG	Signal	V	Volt(s)		
SHFT	Shift	V	Valve		
SHRD	Shroud	VAC	Vacuum		
SHTR	Shutter	V CHAMBER	Vacuum Chamber		
SILV M or SILVER M	Silver Metallic	Vent	Ventilator or Ventilation		
SING	Singapore	V.G.R.	Variable Gear Ratio		
SP.2H	Speaker	VNL	Very!		
SLIN	Sliding	(W)			
S LN	Saloon	W	Watt(s)		
SML	Small	W or WIND	Window		
S. NOSE	Short Nose	W-	Width-		
SOL	Solenoid	W!	With or Use with		
SP	Spand	W/O LOAD SENSING	Without Load Sensing		
SPEC	Specification	VALVE	Valve		
SPEEDO	Speedometer	W/O OIL CONSUMPT	Without Oil Consumption		
SPG	Spring	W/O P T O	Without Power Take-Off		
SPK	Speaker (- Loud-speaker)	WARN	Warning		
SPLR	Spooler	WAS	Washer		
S1	Steering	W/AUTO BELT	With Automatic Shoulder Belt		
STAB	Stabilizer	W CHASSIS	Windshield Chassis		
STD	Standard	WAT	Water		
S.TIRE or S. TIRE	Single Tire	WGN	Wagon		
STYL	Style!	WHL	Wheel		
SUB-TRNS	Sub-transmission	WHT	White		
SUN SHLD	Sun Shield	WIND	Window		
SURGT.	Surge Tank	WIP	Wiper		
SUP GAS	Super Gasoline	W/O AUTO BELT	Without Automatic Shoulder Belt		
SUSP	Suspension	W/O.	Without.		
S.V	Solenoid Valve	WOOF	Wooler		
SW	Switch	W PUMP	Water Pump		
S. WASHER	Screen Washer (Windshield Washer)	WSHLD or WINDSHLD	Windshield		
SWD.	Sweden	WSTR or WTHSTP	Weatherstrip		
SYNC	Synchronizer	W/T	With Tube (Tire)		
(T)		(Y)			
.T	Ton(s)	YLW	Yellow		
T..	Thickness-	YLW/GRN	Yellowish Green		
TACH & TACHOM	Tachometer	YLW/WHT	Yellowish White		
T.ADJUST	Time Adjusting	(Z)			
TACHOM TACHOM.	Tachometer	Z.TEMP	Zone Temperature		
T.BELT	Timing Belt				
T.CEILING	Top Ceiling				
TEMP.	Temperature				
T/F	Transfer				
TH	Throttle				
THAI	Thailand				
THERM.	Thermostat				
THROT.	Throttle				
T/L	Tubeless				
T.MISSION	Transmission				
TRD CLMT	Tropical Climates				
TRK	Truck				
TRQ. GLIDE	Torque Glide				
T. TOBAGO	Trinidad and Tobago				
TURB	Turbocharge				
TWN	Twin				
(U)					
U.K.	The United Kingdom				